

SunShot CSP Program Review 2013 Hilton Phoenix East/Mesa | Phoenix, AZ | April 23-25, 2013

Reversible Metal Hydride Thermal Energy Storage for High Temperature Power Generation Systems

PNNL: EWA RÖNNEBRO (PI), GREG WHYATT, MICHAEL POWELL, KEVIN SIMMONS

UNIVERSITY OF UTAH: ZAK FANG

HEAVYSTONE LAB: RON WHITE

ARPA-E: JAMES KLAUSNER







Presentation Outline



- Objective and goal of our ARPA-E HEATS seedling project
- State of the art vs PNNL innovation
- Project team
- Approach
- Key technical results
- Key accomplishments
- Near term scope
- Path forward after seedling project

Show Proof of Concept of High Temperature Reversible Metal Hydride for TES



Objective: Demonstrate Proof of Concept of a New Durable High-Energy Density Thermal Energy Storage (TES) for Efficient High-Temperature Applications



Motivation: High-temperature material for TES >600°C is needed with sufficient energy density, efficiency, lifetime and low cost

Quantitative Objectives: Our Metal Hydride (MH) can increase energy density 10x relative to molten salts and exceeds ARPA-E volumetric capacity 8x

ARPA-E targets:

✓ Temperature for power generation >600°C

✓ Charging time <6 hours

√ Volumetric capacity >25kWh/m³

✓ Exergetic efficiencies >95%

Our metal hydride:

650°C

<6 hours

200kWh/m³ (system)

We have shown feasibility of our metal hydride for TES!

Our Metal Hydride TES vs State of the Art



- State of the art is molten salt
- Our Metal Hydride (MH) operates at HIGHER TEMPERATURES than previously explored MHs, and LOWER PRESSURE

TES Material	Operation Range	Gravimetric Energy Density	Volumetric Energy Density
PNNL MH	650°C, 1 bar H ₂	1200kJ/kg	1000kWh/m ³
Molten Salt	565°C 670°C (Phase change)	153kJ/kg	100kWh/m³
MgH ₂	450°C, >40 bar H ₂	3000kJ/kg	1000kWh/m ³

Note: Approximate energy densities for material (theoretical), not system

Pacific Northwest NATIONAL LABORATORY Proudly Operated by Ballelle Since 1965

Team and Project Tasks

- Task 1: Materials Development & Characterization
- Task 2: Design & Build 3kWh TES Prototype
- Task 3: Demonstrate & Validate TES Prototype

ARPA-E HEATS Project start date: December 2011

-2 years seedling project

Key Roles of Project Team

Pacific Northwest National Laboratory

- Project Management
- Client communications / interface
- ❖ Cycle life, isotherms and kinetics studies at >600°C
- ❖Thermal management
- System design and fabrication
- Safety
- System demonstration / validation

University of Utah

- Materials synthesis
- Materials performance optimization
- Materials Characterization

Heavystone Lab (Industry partner)

Large scale materials synthesis

Pacific Northwes

Metal Hydrides vs. Complex Metal Hydrides Materials Options


Proudly Operated by Baffelle Since 1965

Complex metal hydrides

- high wt% H₂
- high enthalpy
- operation T typically <600°C</p>
- high pressures
- complex reaction mechanism
- seldom reversible

Metal hydrides

- low wt% H₂
- can be tuned for T range >600°C
- high enthalpy
- low pressures
- reversible



Solution: Choose metal hydride that operates reversibly >600°C and at ambient H₂-pressure

Pacific Northwest NATIONAL LABORATORY Proudly Operated by Ballelle Since 1965

Materials Development of High-T Alloys Materials Tuning

- Explored high-temperature alloys in order to
 - 1) increase reversible hydrogen content, thus, increase thermal energy storage capacity
 - 2) decrease operation pressure to 1 bar H₂-pressure

Results:

- Synthesized several alloys
 - By alloying, plateau pressures can be shifted up or down as hydrogen content changes.
- Optimized performance at 650°C and 1 bar H₂-pressure
- Showed 60 cycles! Exceeded our initial target

Materials Development – Break Through Performance of Reversible Metal Hydride



Performance goals:

- 10x higher gravimetric energy density than molten salt
 - Demonstrated feasibility for 1200-1600kJ/kg
- Charge within 6 hours
 - Demonstrated feasibility to meet ARPA-E target < 6 hours

Experiments:

- Performed isotherms to determine best operation pressure and temperature
 - ~650°C and 1 bar established
- Cycle life tests
 - ~60 cycles accomplished

Approach to Design of Hydride Bed




- Hydride powder is expected to size reduce over multiple hydride cycles
- Small particles lead to low bed thermal conductivity; two options examined for design
 - Use small diameter hydride beds (i.e. ¾")
 - Enhance the thermal conductivity of the bed
- Our approach is to enhance thermal conductivity using copper

Pacific Northwest NATIONAL LABORATORY


Proudly Operated by Baffelle Since 1965

TES 3kWh Prototype Design Concept Selected

- Accomplished numerical modeling of physical properties and hydrogen uptake data based on experimental data
- Provided performance predictions with COMSOL Multiphysics



Volumetric energy density is 200kWh/m³ for system (ARPA-E target is 25kWh/m³)



Design 1: Close-packed array of 56 tubes for storage

Design 2: Storage cylinder with internal structure of Cu-foam

Copper Foam Fill for Hydride Cylinder




- Use open cell Duocel copper foam with interstitial spaces filled with hydride powder.
 - Allows simple construction of test cylinder
 - Easy to fill with hydride powder
 - Low sensitivity to errors in estimate of hydride bed thermal conductivity
 - Foam enhances conductivity in both radial and axial directions.

Pacific Northwest NATIONAL LABORATORY

Modeling of Bed Cycling to Determine Loading Swing for Bed Sizing

Proudly Operated by Baffelle Since 19

- Repeating Cycle:
 - 6h accept heat
 - 6h rest
 - 6h return heat
 - 6h rest



High Temperature Test Bed Design




- Control shell temperature by balancing heat loss with heat input via electrical heater.
- Heat/cool cylinder by adjusting heat input
 - Heat loss through insulation ~constant
 - Temperature change on plateau region is very small
 - Heating accomplished by increasing power input to level above steadystate heat loss
 - Cooling accomplished by reducing heat input to a level below steady state heat loss.

Hydride Test Bed Design Details



oudly Operated by Battelle Since 1965

- •Column is made from S40 pipe (316SS)
- •Bed consists of Copper Foam, filled wtih metal hydride powder
- •Cylindrical section is wrapped with a Ni-80 heater insulated with ceramic "Salamander" beads.
- •Heater is covered by controlled thickness insulation layer, ends well insulated
- •Porous metal tube at bed centerline to add/remove H₂ from bed



Pacific Northwest NATIONAL LABORATORY Proudly Operated by Battelle Since 1965

Design Concept: If Copper Foam Cost Is Too High for Commercial Application


- Use thin copper disks with Hydride powder filling the space between disks.
- Conduction in radial direction dominated by copper, axial conduction must occur in powder
- Advantages
 - Material cost of sheet copper is lower than foam
- Disadvantages
 - More difficult to fabricate bed compared to foam




Scale-Up of Hydride Powder Industry Partner: Heavystone Lab

Designed and fabricated new planetary milling machine for preparation of kilograms of metal powders

Drawing of milling machine





Pacific Northwest NATIONAL LABORATORY Proudly Operated by Baffelle Since 1965

Summary Key Results in Year 1

- ► Task 1: Materials Development & Characterization
 Demonstrated metal hydride's feasibility for high-T TES
 - 10x higher energy density than molten salt
 - Volumetric energy density 200kWh/m³ for system, i.e.8x ARPA-E target
 - Established operation range of ~650°C and ~1 bar H₂ pressure
 - >60 cycles demonstrated: exceeded goal
- ► Task 2: Design & Build 3kWh TES Prototype
 - Two design concepts evaluated by COMSOL modeling
 - Recommend a stainless steel cylinder with Cu-foam
 - Build prototype in Year 2

Pacific Northwest NATIONAL LABORATORY Proudly Operated by Baffelle Since 1965

Decisions Made for Go/No-go Decision December 2012

- Go on optimized hydride as TES material
 - Hydride exceeds ARPA-E performance targets on gram size scale
 - Operation range: 1 bar and 600-800°C
- Go on scale up of hydride powder
 - Heavystone Lab to make ~15kg for 7.4 liter container
 - Verify scale up reproducibility
- Go on building 3kWh prototype
 - Design: Stainless steel container with internal Cu-structure for enhanced heat transfer
- Go on build thermal diffusivity device
 - Study thermal conductivity during cycling in hydrogen atmosphere
 - Study cycle life and oxidation mitigation if needed
 - Study materials engineering properties

Year 2 ARPA-E HEATS Scope



- Design and build bench-scale TES of ~3kWh (PNNL)
 - One bed, "half", system is the current scope
 - Final drawing of high-T prototype accomplished
 - Fabrication in progress
- Scale up to kilogram quantities of TES material (Heavystone Lab)
 - Confirm reproducibility (U. of Utah and PNNL)
- **▶** Demonstrate and validate prototype (PNNL)
 - Evaluate concept and calculate efficiencies
 - Obtain 'one day-one night' cycles at 650°C and 1 bar H₂-pressure
 - Show proof of concept and feasibility for meeting ARPA-E targets of 95% exergetic efficiencies

Path Forward after ARPA-E HEATS Seedling



- Next step is to accomplish a full dual bed system with both a HThydride and a LT-hydride
 - Need to explore interplay between HT and LT hydrides to optimize performance
 - Demonstrate full system with on-sun testing

Path Forward for Metal Hydride TES



Phase 1: Proof of concept of HT-hydride for TES

 Metal Hydride exceeds ARPA-E targets Phase 2: Design, build, demo TES system

 Demonstrate efficiencies and cycle life of full system Phase 3: Integrate TES system with end application

 On-sun testing for high-T power generation



Proudly Operated by Battelle Since 1965

Acknowledgement: Award from ARPA-E HEATS program