
Project ID BAT384



BAT384: APPROACHES TO DETECTING Li DEPOSITION DURING FAST CHARGE



MICHAEL F TONEY
SLAC National Accelerator Laboratory
DANIEL ABRAHAM
Argonne National Laboratory

Other Major Contributors:
Donal Finegan (NREL), Dan Steingart (Princeton),
Nitash Balsara & Bryan McCloskey (LBNL),
Johanna Nelson Weker & Hans Georg-Steinrück
(SLAC)

This presentation does not contain any proprietary, confidential, or otherwise restricted information













June 12, 2019 AMR Arlington, VA

OVERVIEW

Timeline

Start: October 1, 2017

End: September 30, 2021

Percent Complete: 37%

Barriers

- Cell degradation during fast charge
- Low energy density and high cost of fast charge cells

Budget

- Funding for FY19 6390k
 - ANL 2400k
 - NREL 1600K
 - INL 440K
 - SLAC 1000K
 - LBNL 950K





Partners


- Argonne National Laboratory
- Idaho National Laboratory
- Lawrence Berkeley National Lab
- National Renewable Energy Laboratory
- SLAC National Accelerator Lab

2

RELEVANCE

- Fast charge is major issue impacting widespread adoption of EVs
- Better understand what limits fast charging
 - o Li plating is a critical issue limiting fast charge
- Develop methods to directly detect and characterize (space and time) Li metal plating during fast charging
- Understand what cell factors (graphite, electrolyte, ...) impact tendency for Li plating
- Apply Li-detection methodologies within XCEL
- Challenges: fast (few seconds), heterogeneous (2D, 3D, cm < µm (?)), aggressive environments, "buried" interface,








ENERGY Energy Efficiency & Renewable Energy
VEHICLE TECHNOLOGIES OFFICE


OBJECTIVES

- develop approaches to accurately detect and quantify Li deposition during fast charge conditions
- provide information on Li deposition to XCEL teams to develop methods enabling fast charge

APPROACH

- Explore and develop several complementary techniques
 - o what works well and not!
- X-Ray diffraction & tomography
- Raman Spectroscopy
- Mass Spectroscopy
- Acoustic Analysis
- Feedback to the XCEL teams










MILESTONES

Li detection related milestones in XCEL

Milestone	End Date	Status
Detect lithium metal deposits using in situ x-ray characterization and correlate results to smart-separator detection data.	6/30/2020	On Track
Preliminary results acquired for each diagnostic tool (tomography, spectroscopy, scattering, impedance spectroscopy, heat transfer)	3/30/2019	Completed
Rationalize performance and degradation experimental findings from NREL, Argonne and Idaho National Labs using models to explain underlying mechanisms behind observed electrochemical performance and degradation	6/30/2019	On Track
Perform initial proof-of-concept experiments to identify the impacts of fast charging at the cell level using non- destructive, in operando techniques including acoustics	3/31/2019	Completed







X-RAY **DIFFRACTION & TOMOGRAPHY DETECTION OF LI DEPOSITION**

Michael Toney, Johanna Nelson Weker & Hans Georg-Steinrück (SLAC National **Acceleratory Laboratory**) **Donal Finegan (NREL)**





Qualitative Measurement of Li Plating


6C - charged



6C - discharged



4C - discharged




- Qualitatively: Different charging conditions → Different electrode conditions after cycling
- How can we *quantify* changes spatially within the cell and connect it to loss of cell capacity?







X-ray based Characterization of Single Layer Pouch Cell: spatially resolved XRD and micro-tomography

Spatially resolved 2D mapping by X-ray diffraction (XRD) Micro-tomography (micro-CT) imaging














Coupled, Multiscale Approach to Li detection





2D mapping – XRD cells cycled at INL

"Round 2" – 3.0 mAh/cm² All cells at 10% SOC Details - BAT383 & 339










Reference cell:
Pristine (Unformed)

Li Plating Inhomogeneity at the mm-Scale










Lithium Intensity from 110 peak

Correlating Li intensity to other Phases at the mm-scale


Cycling: 6C, CCCV, 450 cycles



- Intensities of Li and Gr anti-correlated
- Intensities of Li and LiC₆/LiC₁₂ correlated
- NMC shows pattern; no obvious correlation with Li



Li Plating and Capacity Fade at the mm-scale









Li heterogeneity at the µm-scale

Round 1 cell (2.0 mAh/cm²), 100 cycles at 6C

- Mm-scale scans (powder diffraction):
 - Heterogeneities at the full cell level
 - Washes over local (µm-scale) heterogeneities
- µm-scale scans (microdiffraction):
 - Obtain local variations in Li intensity → size of plated Li 'clusters'
- Average size of highlighted clusters → ~1.5µm
 - Comparable with past SEM studies [1]


[1] Feifei Shi et. al., 2017.







Li (110) ntensity




7.8µm

Micro-cell design for operando XRD

High speed and high resolution XRD:

- Maximize X-ray transparency and signal/noise ratio
- Minimize performance loss







■ 148 XRD points at 100 Hz


■ 13 s between line scans


■ 1.5 s per line scan

Cell: 4.7 mm dia

Spacer: 0.2 mm Al

Operando depth-profiling XRD of anode





RAMAN SPECTROSCOPY

Daniel Abraham Argonne National Laboratory




ENERGY Energy Efficiency & Renewable Energy VEHICLE TECHNOLOGIES OFFICE


Lithium acetylide band in the Raman spectra of graphite electrodes is a spectroscopic marker for metallic lithium

Graphite electrode from a highly aged cell (360, C/3 cycles, **no Li plating**)

Graphite electrode after fast charging (6C charge, **Li plating**)



Extensive SEI growth does not produce Raman signals



Very intense SEI and acetylide (Li₂C₂) bands are visible in Raman spectra of electrodes containing metallic Li nuclei






Li plating enhances Acetylide (carbide) band

Origin: small carbide clusters form by reduction of SEI species by plated Li, becoming part of its SEI


SEI or
$$+ \text{Li}_{(s)} \rightarrow \text{Li}_2\text{C}_2$$

Mechanism: plated Li enhances the signal from its immediate SEI through surface-enhanced Raman scattering (SERS)




Result: Li₂C₂ band is only detected when metallic Li is present

Sensitive and specific to Li




9

Spatially-resolved detection of plated Li










MASS SPECTROMETRY


Bryan McCloskey & Nitash Balsara (LBNL)



In situ Li plating detection: Does Li plating evolve gases?

<u>Approach:</u> In situ differential electrochemical mass spectrometry





Bottom Line:

- Gas evolution is within detection limits.
- Less than 0.01 mol per mol of Li plated!
- Conclusion is that Li plating will not cause swelling of pouch cells.

Ex situ Li plating detection

Procedure

- 1. Extract fully delithiated graphite electrodes from cells
- 2. Place in sealed vial, attach to Mass Spec
- 3. Inject H₂O/H₂SO₄, monitor/quantify gas evolution

Plausible reactions


After H₂O addition:

$$H_2O + Li(s) \rightarrow LiOH + \frac{1}{2}H_2$$

 $H_2O + LiC_6 \rightarrow LiOH + \frac{1}{2}H_2 + C_6$

After H₂SO₄ addition:

$$H_2SO_4 + Li_2CO_3 \rightarrow CO_2 + H_2O + Li_2SO_4(aq)$$




μmol H ₂ (Li)	μmol CO ₂ (LiRCO ₃)	Calculated cap. loss (assume 1 e ⁻ per Li)	Cap. loss from cycling data
1.43 (2.86)	4.1 (4.1)	0.29 mAh	0.28 mAh = (0.23 + 0.03 + 0.02)

<u>Bottom Line:</u> Titration captures all of the Li plated in a composite electrode without interacting with intercalated Li.





Impedance signatures of Li plating



Unique mode associated with plating



PART D: ACOUSTIC ANALYSIS

Dan Steingart (Princeton)



ENERGY Energy Efficiency & Renewable Energy VEHICLE TECHNOLOGIES OFFICE

Acoustic Signatures of Li plating

Objectives:

- Look for acoustic signatures of Li deposition in CAMP cells
- Assess non-destructive confirmation routes


Basic Acoustics

Sound speed
$$c=\sqrt{rac{K+rac{4}{3}G}{
ho}}$$

Longitudinal/Shear Modulus
Density

Acoustic impedance

$$Z = \rho \cdot c$$







Hypothesis:


Cycling affects the behavior of sound traveling through a battery

GENTLE START


- "Round 2" 3.0 mAh/cm²
- C/2 Cycling
- Held at 25°C (+/- 0.5 °C)
- SoC shift as expected at both wave arrivals
- SoH "break—in" shift correlates well with previous work
- No apparent damage








ABUSIVE FINISH



After 10 - 10 C Cycles








ABUSIVE FINISH

- "Round 2" 3.0 mAh/cm²
- 1C -> 2C -> 5C -> 10 C
- Held at 25°C (+/- 0.5 °C)
- SoC shift as expected at both wave arrivals at first
- SoH "break—in" shift correlates well with previous work
- Significant Pattern Shift at 10 C change -> Lithium?







RESPONSE TO PREVIOUS YEARS REVIEWERS' COMMENTS

Not previously reviewed






COLLABORATION ACROSS LABS AND UNIVERSITIES











- National User Facilities involved in this work presented include the Advanced Photon Source, & Stanford Synchrotron Radiation Lightsource. International Facilities include the European Synchrotron Radiation Facility.
- This effort is part of a broad range of unified studies (BAT338, BAT339, BAT340, BAT 341, BAT371, BAT383, BAT384, BAT386).




















REMAINING CHALLENGES AND BARRIERS

- What SOC does Li plating start; dependence on charge rate/profile?
- What are initiation sites of Li plating (e.g., edge vs basal)?
- Establish detection limits & quantification for Li plating
- What dictates observed heterogeneity in Li plating?
- Find solutions!









FUTURE WORK

- Transition to Operando Measurements
 - ☐ At what SOC does Li plating start; dependence on charge rate/profile?
 - □ XRD, Raman Spectroscopy Li-plating (Li-acetylide) detection on graphite
 - □ Correlate results to micro-tomography to 2D & 3D XRD & develop unique anode and cell design to enable high resolution imaging
- Quantify amount of plated Li → relate to capacity lost
 - ☐ Impedance assess sensitivity
 - ☐ Acoustic Analysis refine approach to increase sensitivity
- Understand spatial heterogeneity
 - ☐ What dictates observed heterogeneity in Li plating?
 - □ 3D XRD → depth resolution & surface layers of Li
 - Operando Optical Video Microscopy
- What are initiation sites of Li plating (e.g., edge vs basal)?
 - □ Near-field FTIR model electrodes if plating occurs on graphite planes or edges
- Temperature increases
 - ☐ Thermal Signatures of temperature increases 4 sensors integrated into full cells.
 - "smart" trilayer separator & RTD






Any proposed future work is subject to change based on funding levels.

SUMMARY

- Explore and develop complementary techniques for Li detection what works well and not!
- Develop methods to directly detect and characterize (2D and 3D space and time) Li metal plating during fast charging
 - Spatial Inhomogeneities in Li-plating over a range of length scales from: microns to mm
 - Initial quantification of Li-plating extent correlate with capacity fade (qualitative)
 - Spatial correlation between Li-Plating & graphite staging







CONTRIBUTORS AND ACKNOWLEDGEMENTS

Aashutosh Mistry Andy Jansen Abhi Raj Alison Dunlop Andrew Colclasure Antony Vamvakeros Aron Saxon Bryan McCloskey Bryant Polzin Chuntian Cao **Daniel Abraham Daniel Steingart** Dave Kim David Robertson David Wragg Dean Skoien Dennis Dees Donal Finegan Eongyu Yi Eric Dufek Francois Usseglio-Viretta

Ira Bloom Jiayu Wan Jianming Bai Johanna Nelson Weker John Okasinski Juan Garcia Kamila Wiaderek Kandler Smith Kaushik Kalaga Kevin Gering Marca Doeff Marco DiMichiel Marco Rodrigues Matt Keyser Michael Evans Michael Toney Nancy Dietz Rago Nitash Balsara Olaf Borkiewicz Partha Mukherjee Partha Paul Paul Shearing Pavel Shevchenko Pierre Yao Ravi Prasher

Ilya Shkrob

Ren Yang Robert Kostecki Ruging Xu Ryan Jackman Sang Cheol Kim Sangwook Kim Sean Wood Seoung-Bum Son Shabbir Ahmed Shriram Santhanagopalan Steve Trask **Tanvir Tanim** Uta Ruett Venkat Srinivasan Victor Maroni Vince Battaglia Vivek Thampy Wei Tong Weijie Mai Wenxiao Huang William Huang Yanying Zhu Yi Cui Zhenzhen Yang











Support for this work from the Vehicle Technologies Office, DOE-EERE – Samuel Gillard, Steven Boyd, David Howell













Francesco De Carlo

Hans-Georg Steinrück

Guoying Chen

Hansen Wang

Hakim Iddir









VEHICLE TECHNOLOGIES OFFICE

















Multiscale Phenomena





- o Characterization of heterogeneity of Li plating at multiple length scales
- Fast data acquisition at synchrotron allows *in-situ/operando* measurement

8

Anode:

- o ~3.0 mAh/cm²
- o Foil (Cu) thickness:10μm
- Electrode Thickness: 80μm
- o Porosity: 34.5%

Polymer separator Graphite anode NMC cathode Polyamide polymer with Al laminated film X-rays in

Single layer pouch cell

Cathode:

- o ~2.7 mAh/cm²
- Foil (Al) thickness:20μm
- Electrode Thickness: 91 μm
- o Porosity: 35.4%

Composition (wt%):

- o 91.83% Graphite
- o 2% Timcal C45
- o 6% PVDF
- o 0.17% Oxalic acid

Composition (wt%):

- o 90% NMC532
- o 5% Timcal C45
- o 5% PVDF

Special thanks to: Andy Jensen, Ira Bloom, Eric Dufek, CAMP and XCEL teams


9





Correlating Li-Plating to other Phases






- o Intensities of Li and Gr Anti-Correlated
- Intensities of Li and LiC₆/LiC₁₂ Correlated
 NMC shows Patterns but no Obvious Correlation with NMC



Correlating Li-Plating to other Phases






- o Intensities of Li and Gr Anti-Correlated
- Intensities of Li and LiC₆/LiC₁₂ Correlated
 - NMC shows Patterns but no Obvious Correlation with NMC



Another look at Phase Correlations



- o Intensities of Li and Gr Anti-Correlated
- Intensities of Li and LiC₆/LiC₁₂
 Correlated
- No Obvious Correlation with NMC

What leads to this spatial inhomogeneity?

Porosity / Tortuosity / Texture / Cracks ...?