

# CELL ANALYSIS, MODELING, AND PROTOTYPING (CAMP) FACILITY RESEARCH ACTIVITIES

**Project ID: BAT030**

**STEVE TRASK**

Andrew Jansen (PI), Daniel Abraham, Shabbir Ahmed, Eva Allen, Zonghai Chen, Alison Dunlop, Marco Rodrigues, Donghyeon Kang, Kewei Liu, Wenquan Lu, Bryant Polzin, Sanpei Zhang

ARGONNE NATIONAL LABORATORY, CHEMICAL SCIENCES AND ENGINEERING

# OVERVIEW

## Timeline

- Start: October 1, 2014
- Finish: September 30, 2021
- Percent complete: 80 %

## Budget

- \$950K
  - 100% DOE-EERE-VTO

## Barriers

- Need a high energy density battery for Electric Vehicle (EV) use that is safe, cost-effective, has long cycle life, and meets or exceeds DOE / U.S. Drive goals
  - Independent validation analysis of newly developed battery materials are needed in cell formats with at least 0.2 Ah before larger scale industrial commitment

## Partners

- Coordinated effort with DOE-EERE-VTO BTMS, Next Generation Anodes, Next Generation Cathodes, ReCell, XCEL (INL, LBNL, NREL, ORNL, PNNL, SLAC, SNL)
- Argonne Facilities: MERF, EADL, CNM & PTF
- See Collaboration list at end

# RELEVANCE / OBJECTIVES

- Transition new high energy battery chemistries invented in research laboratories to industrial production through independent validation and analysis in prototype cell formats
  - xx3450 & xx6395 pouch cells & 18650 cells; ranging from 20 to 3,000 mAh capacity



- Researchers are often not able to provide the quantities of novel materials needed to make a full size EV cell to demonstrate the merits of their discoveries. The CAMP Facility is specifically designed to explore new materials with quantities as small as 50 grams for active materials, and even less for electrode/electrolyte additives



# FY20 PROGRESS MEASURES & MILESTONES

| Milestone   | Planned End Date | Type               | Status      |
|---|------------------|--------------------|-------------|
| Develop methods to fabricate pre-lithiated high-energy electrode couples on pilot-scale coater in dry room ( <b>see BAT028</b> )          | 9/30/2019        | Quarterly Progress | Completed   |
| Measure electrochemical performance of LLZO ceramic in symmetric lithium cells as a function of temperature ( <b>see BAT028</b> )         | 3/30/2020        | Annual Progress    | In progress |
| Deliver needed experimental electrodes from the CAMP Facility's Electrode Library to research organizations involved in DOE-EERE projects | 9/29/2020        | Quarterly Progress | On-schedule |
| Develop methods to direct coat hybrid polymer ceramic coatings/electrolyte membranes onto electrodes and test electrochemically           | 9/29/2020        | Quarterly Progress | On-schedule |
| Support development of advanced cell systems for Behind The Meter Storage   | 9/29/2020        | Annual Progress    | On-schedule |

COVID-19 has reduced lab time and may cause delays in completing FY20 milestones

# APPROACH / RESOURCES

- Researchers submit materials with promising energy density
  - Small hand-coated electrodes are made
  - Coin cells are made and tested
- } Glove box  
Benchtop
- Larger material samples are obtained (MERF, partnerships, etc.)
  - Longer lengths of electrode are made from scaled materials
  - Pouch cells or 18650s are made and tested
- } Dry Room  
Pilot scale
- Extensive diagnostics & electrochemical modeling on promising technologies




# TECHNICAL ACCOMPLISHMENTS (NOT ALL PRESENTED AT AMR)

- Completed method development for pre-lithiation of electrodes & graphite powder via electrochemistry (**see BAT028**)
- Demonstrated successful ultra-thin Li-metal electrodeposition onto copper foil technique in dry room
- Performed molten lithium soldering onto LLZO disk with mixed results (**see BAT028**)
- Initiated solid-state-electrolyte and hybrid composite polymer scale-up design for roll to roll coating
- Identified mechanisms of cell performance improvement resulting from oxide nanoparticle addition to electrolyte
- Continued process development and post-test analysis of ceramic coatings (as sole electronic insulator) on anode electrodes in preparation for solid-state-electrolyte coatings
- Purchased new multi-functional coating system that enables a variety of advanced coating techniques to perform uniform thin coatings
- Supported numerous DOE projects with prototype electrodes & cells (**see BAT251, BAT252, BAT253, BAT386, BAT422, BAT436, BAT456, BAT457, BAT458, BAT459, BAT460, BAT461, BAT462, BAT463, BAT467, BAT469, BAT471**)




# PRE-LITHIATION OF ELECTRODES IN DRY ROOM

SUCCESSFUL LITHIATION OF GRAPHITE AND SILICON-BASED ELECTRODES IN OPEN CONTAINER,  
→ CONTINUOUS PROCESS WOULD REQUIRE LARGE FOOTPRINT

See BAT028



+ Gen2




Pristine

5% lithiation

Implies that for an industrial coating rate of 40 m/min, a continuous 60 meter electrode stretch would need to be immersed in electrolyte to achieve 5% SOC at 2C rate

## Coin cell verification of pre-lithiated graphite electrode



SEI formation peaks absent in 5% and 10% pre-lithiation and improved 1<sup>st</sup> cycle coulombic efficiencies suggest the electrode SEI survived DMC washing and handling in the dry room




Pre-lithiated electrodes integrity were not compromised, resulting in no pouch cell assembly process changes

# PRE-LITHIATION OF GRAPHITE POWDER IN DRY ROOM

## POOR RESULTS FOR LITHIATION OF GRAPHITE POWDER IN BEAKER


Superior Graphite  
1506T powder  
with [Gen2] 1.2 M  $\text{LiPF}_6$   
EC:EMC (3:7 wt.%)

Li metal ribbon on nickel  
rod wrapped in separator,  
copper beaker with stir bar,  
2 grams of graphite powder



Voltmeter readings during experiment  
and in open circuit, suggest that  
some amount of lithiation is occurring

See BAT028



Pre-lithiated graphite powder -> rinsed with DMC, dried,  
then made into an electrode for coin cell evaluation


10% lithiation

dQ/dV SEI formation peaks present in both the pristine and the 10% pre-lithiation  
powder, suggesting this method of pre-lithiation needs to be further optimized



# LITHIUM METAL ELECTRODEPOSITION PROCESS

THE CAMP FACILITY DRY ROOM WAS USED IN THE DEVELOPMENT OF A NEW ULTRA-FAST LITHIUM METAL ELECTRODEPOSITION PROCESS THAT CAN PRODUCE A SUB-20-MICROMETER THIN LITHIUM METAL ANODE




A photo (left) and SEM image (right) of electrodeposited Li-metal

Artificial protective SEI layer is simultaneously generated on the top of Li-metal during this process

Data will be fit to semi-empirical model to provide correlation for use in BatPaC

3 to 4.25 V, cycling test:  
vs. LCO cathode, Gen2 electrolyte,  
0.2C charge/0.5C discharge



# SOLID-STATE-ELECTROLYTE CANDIDATES

Solid-state-electrolyte (SSE) effort within the CAMP Facility is focused on conductivity, stable voltage window, and fabrication scalability.

- Conductivity of solid state electrolytes at room temperature:  
 $\text{Li}_3\text{ClO} > \text{sulfide} > \text{Li}_3\text{N} > \text{LLZO(Garnet)} \sim 10^{-3}$

|  | LLZO                          | Sulfide   | Ba-Li <sub>3</sub> ClO |
|--|-------------------------------|---|------------------------|
| Conductivity (RT, mS/cm)                   | 1~1.5                         | 1~40  | > 10                   |
| Voltage Window (V vs. Li/Li <sup>+</sup> ) | 0.05~2.9 (3.3)                | 1.7~2.1 (2.5)   | 0~8                    |
| Pros                                       | Stable in ambient environment | High conductivity   | Easy scale-up          |
| Cons                                       | Li dendrites grow inside      | Unstable with O <sub>2</sub> , H <sub>2</sub> O<br>H <sub>2</sub> S formation | Corrosive              |



Coating of ceramic slurry over anode



CAMP Facility FY19 AMR

# COATING SOLID-STATE-ELECTROLYTE MEMBRANES

## LLZO Free-standing Membrane

- Mix and ball-mill: LLZO / polyvinyl butyral / benzyl butyl phthalate / acetone / ethanol to make slurry.
- Tape cast the slurry on Mylar substrate
- Dry and peel off the green films
- Sinter the film at 1080°C in N<sub>2</sub>

## LLZO Casting on Cathode


- *Cathode prepare*: casting the slurry of NMP, LLZO, LFP, Super P and PVDF onto Al foil, dried at 80°C overnight
- *SSE slurry*: LiTFSI/LLZO/SPEEK-PSI-Li (adhesives) in NMP and surfactant
- *SSE film direct casting*: Tape cast the slurry onto a cathode electrode and dry it at 80°C in argon atmosphere for overnight

## Li<sub>6</sub>PS<sub>5</sub>Cl Free-standing Membrane

- Mix Li<sub>6</sub>PS<sub>5</sub>Cl and acrylate-type binder (1 wt%) in xylene and anhydrous isobutyl isobutyrate
- Coat the slurry on polyethylene terephthalate film and dry the film at 50°C

## LiZO-coated NMC Cathode

- Mixing lithium methoxide, zirconium and NMC powder in propanol to prepare LiZO coated NMC powder
- The composite cathode was fabricated by mixing LiZO-coated NMC, SSE, carbon nanofibres and PTFE in dehydrated xylene followed with dry film process



# HYBRID COMPOSITE POLYMER SCALE-UP

## TRIAL ROLL-TO-ROLL COATING OF SOLID-STATE-ELECTROLYTE

|   | Monomer | Initiator | Li Salt      | (Solid) Plasticizer |
|---|---------|-----------|--------------|---------------------|
| 1 | PEGDA   | AIBN      | LiTFSI       | SN                  |
| 2 | PEGDA   | BAPOs     | LiTFSI/LiBOB | GN                  |

PEGDA = Poly(ethylene glycol) diacrylate

AIBN = 2,2'-azobisisobutyronitrile


BAPOs = Phenylbis(2,4,6-trimethylbenzoyl)phosphine oxide

SN= Succinonitrile

GN= Glutaronitrile

### Advantages for Solid Polymer Electrolyte

- High energy input process can be avoided such as high temperature sintering
- The technique of thin polymer membrane fabrication and coating on the electrode laminate aligns well with the current CAMP Facility capabilities
- The polymer based solid electrolyte provides the flexibility in the formulation to be compatible with different electrode materials






*Kewei et al. Joule 2018, 2, 1–19*

- Initial coating effort will use PEGDA, a thermal initiator, and LiTFSI salt
- Materials have been acquired and trial coating will be made when we resume lab operations
- Coating results will provide valuable information for continued studies to incorporate other variables such as single-ionic conducting solid-state-electrolytes, UV initiators, crosslinkers, and plasticizers

# PROCESS CONSIDERATIONS WHEN USING LLZO

ELECTROCHEMICAL COMPATIBILITY OBSERVED FOR LLZO CO-SINTERED WITH NMC622, HOWEVER DIRECT USE OF LLZO REQUIRED THERMAL PROCESSING



- In situ high energy diffraction was carried out during the thermal processing of Ta, Al, and Ga doped LLZO
- All as-received doped LLZO samples exist as a cubic form
- LLZO powders potentially convert to a low temperature cubic form (H intercalation phase) after storage
- All materials experience irreversible phase transformation between 300°C and 700°C
- Ta-LLZO can recover after the initial thermal processing. However, both Al-LLZO and Ga-LLZO only partially recover after the thermal processing
- **Thermal processing should be considered for LLZO powders before direct use**

# ALTERNATIVE SLURRY POLYMER & SOLVENTS EXPLORED

## SLURRY PROCESSING ISSUES HAVE BEEN OBSERVED WITH SOME HIGHER Ni CONTENT CATHODES, SOLID-STATE-ELECTROLYTES, AND SILICON

### Polymers


- PVDF
- CMC
- SBR emulsion
- PAA
- LiPAA
- EVOH
- PVA
- PEG
- Xanthan gum

### pH Adjustment Additives

- LiOH
- $\text{NH}_4\text{OH}$  solution
- Oxalic acid

### Solvents

- NMP
- Water
- Cyrene



5 wt.% LiOH in Cyrene changed notably in color and gelled, indicating the combination in a slurry should be avoided






# ELECTROLYTE MODIFICATION BY CERAMIC NANOPARTICLES

## SCAVENGING WATER FROM THE ELECTROLYTE (AND NOT HF) LIMITS ASI RISE OF NMC811

NMC811/graphite after accelerated aging tests (3 – 4.4 V)



- Ceramic nanoparticles added to Gen2 electrolyte (30 mg/mL)
- Electrolyte “aged” for 7 days
- Tests in NMC811/graphite cells


NMR analyses of electrolyte + ceramics exposed to 8,300 ppm water for one week

varying degree of success in controlling electrolyte hydrolysis

| Electrolyte/ceramic            | % LiPF <sub>6</sub> hydrolyzed | % HF yield |
|--------------------------------|--------------------------------|------------|
| baseline                       | 4.0                            | 9.7        |
| SiO <sub>2</sub>               | 10.4                           | 4.1        |
| ZnO                            | 9.9                            | 9.0        |
| ZrO <sub>2</sub>               | 7.4                            | 13.5       |
| TiO <sub>2</sub>               | 7.1                            | 11.9       |
| Al <sub>2</sub> O <sub>3</sub> | 6.5                            | 9.4        |
| CeO <sub>2</sub>               | 4.8                            | 9.0        |
| <b>MgO</b>                     | <b>0.1</b>                     | <b>0.0</b> |

MgO is a more efficient drying agent than other ceramics, scavenging moisture before it can react with LiPF<sub>6</sub> to form HF

Solely harvesting HF will release H<sub>2</sub>O in the electrolyte, which **generates more HF**. Water scavenging, on the other hand, can mitigate HF generation. This is what makes MgO an effective additive, protecting NMC811 particles from HF attack




Rodrigues et al., ACS Appl. Energy Mater. 2019, 2, 8, 5380-5385

# POST-TEST FACILITY ION MILL OF CERAMIC COATINGS

## INITIAL RESULTS INDICATE CLEAR CERAMIC COATING // GRAPHITE ELECTRODE INTERFACE




- Intriguing scoping results of half and full cells made with a range of ceramic coatings (see FY19 BAT030) prompted post-test analysis of the **ceramic coating (sole electronic insulator)** // graphite electrode interface



- Post-Test Facility's new Gatan ion mill is located in the CAMP Facility (dry room)
  - Enables the analysis of moisture sensitive samples
- Ceramic-based slurry appears to be laying on the graphite electrode, and not filling anode porosity
- Technique able to provide views of graphite plane edges (useful for examining the SEI)
- **Sets the stage for efforts to acquire ceramic materials with more favorable particle sizes and morphologies that result in uniform thin (>20 μm) ceramic coatings to continue post-test investigations**




- Interchangeable coating heads
- Gravure and dual slot die methods provide greater flexibility for layered coatings



### Additional Capabilities Available:



- Progressive cavity pump
- Corona treatment
- Thermal laminate module
- Dry Thickness gauge



# SUPPORT OF BEHIND THE METER STORAGE PROGRAM

## INVESTIGATED IMPACT OF ELECTRODE THICKNESS ON PERFORMANCE AND PROVIDED COST MODELING CALCULATIONS FROM BATPAC


Average coin cell data,  $2\sigma$  SD, 30°C, Gen2 electrolyte, legends indicate coating thickness



- Demonstrated high areal capacities at slower rates, however faster rates for thicker coatings resulted in loss of electrode utilization
- BatPaC calculations, incorporating slow rate data generated from increasing coating thicknesses, suggest increased energy densities and cost savings for thicker electrodes

# REVIEWER COMMENTS FROM 2019 ANNUAL MERIT REVIEW

- “The reviewer commented that the program is very important for new materials innovation and evaluation and fills the gap between industry and academia.”
- This was a common response among the 5 reviewers.
- “The reviewer recommended looking at expanding the library into higher areal capacity electrodes.”
- While the present electrode library is intentionally designed to be ~2 mAh/cm<sup>2</sup> to minimize thickness effects for novel materials that require validation and provide baseline standardization, the CAMP Facility regularly coats electrodes at higher areal capacities when warranted for larger cell demonstration and provides these electrodes as needed for programmatic research (examples include BAT422 [BTMS], BAT436 [Silicon], BAT386 [XCEL], BAT467 [ReCell]).
- “The coating work is also interesting to the reviewer, but given the challenges in producing a uniform quality coating, it is too early to determine its benefits.”
- We find the ceramic coating work intriguing, as well, and look forward to applying and examining these uniform coatings using the recently purchased coater that will enhance our coating technique capabilities (see slide 17). The initial efforts have been informative and the new multi-functional coater will be critical in the development of solid-state-electrolyte cells at the CAMP Facility.
- Several of the reviewers commented that “list of collaborators is impressive; however, the inclusion of some major battery manufacturers, if possible, would be desirable.”
- We agree and welcome collaborations with battery manufacturers.



2019 Annual Merit Review, Vehicle Technologies Office  
Results Report, February 2020

# CAMP FACILITY'S ELECTRODE LIBRARY

## SUPPORTING THE EERE-VTO R&D BATTERY COMMUNITY

- The Electrode Library serves as a supply of standard electrode samples that are designed to be interchangeable with one another (capacity matched)
- Electrodes can be made with as little as 50 g of experimental material, and can be made to match an existing counter electrode

Currently Available:


- 15 anodes
- 19 cathodes
- Neg:Pos balanced
- Anodes at 2 mAh/cm<sup>2</sup>
- 220 mm x 110 mm of coating per sheet

|                     | FY17        |      | FY18       |        | FY19        |        | FY20<br>(as of April 2020) |        |
|---------------------|-------------|------|------------|--------|-------------|--------|----------------------------|--------|
| Argonne             | 142         | 9 %  | 140        | 14.3 % | 160         | 15.0 % | 125                        | 24.1 % |
| Other National Labs | 172         | 11 % | 172        | 17.5 % | 224         | 21.0 % | 174                        | 33.6 % |
| Universities        | 151         | 10 % | 175        | 17.8 % | 296         | 27.7 % | 137                        | 26.5 % |
| Industry            | 1083        | 70 % | 495        | 50.4 % | 388         | 36.3 % | 82                         | 15.8 % |
| <b>Total:</b>       | <b>1548</b> |      | <b>982</b> |        | <b>1068</b> |        | <b>518</b>                 |        |

# CAMP FACILITY'S POUCH CELL DELIVERIES

## SUPPORT OF VTO PROGRAMS CONTINUES TO INCREASE

- Pouch cells provide critical information on the scalability of newly developed battery materials
- CAMP pouch cell format capabilities of xx3450 and xx6395, as well as customized designs to enable specialized scoping methods
- xx3450 cells range from single-layer (~20 mAh) to multi-layer (~600 mAh)
- xx6395 cells range from single-layer (~70 mAh) to multi-layer (~3000 mAh)



|                          | FY17 | FY18 | FY19 | FY20<br>(as of April 2020) |
|--------------------------|------|------|------|----------------------------|
| Pouch Cells<br>Delivered | 55   | 162  | 300  | 175                        |

# CAMP FACILITY COLLABORATIONS

Majority of these collaborations over the past several years are centered on the CAMP Facility providing electrodes and cells

## Universities



## Industry



## National Laboratories



# REMAINING CHALLENGES AND BARRIERS

- Resolve non-ideal rheological slurry/coating behavior when they are encountered (gelation, phase separation, agglomerates, aggregates, etc.)
  - Use learned processing knowledge from high pH ( $>12$ ) cathode powders and from specialty coatings to other materials such as active materials or polymer films
- Apply direct coating roll-to-roll options needed to effectively coat ceramic materials onto (solid-separator) and in electrodes (solid-state-electrolyte)
  - Application of films via single slot die, dual slot die, gravure, knife-over-roll, etc. are needed to be demonstrated with the new multi-functional coating system
- Increased electrode thicknesses may impact electrode utilization at higher rates
  - Electrode design optimization at the CAMP Facility is restrained in scope of work but warranted to select programs and materials where potential performance improvements are promising

# PROPOSED FUTURE RESEARCH

- Leverage the new multi-functional coating system to apply uniform thin ( $<20\text{ }\mu\text{m}$ ) ceramic composite coatings on anodes, on separators, and as free-standing films
- Complete alternative polymer/solvent study to enhance the slurry processing compatibility of ceramics (esp. LLZO)
- Determine if LLZO materials need pre-treatment before coating
- Demonstrate hybrid ceramic-polymer composite scale-up and performance
- Continue coordinating with the Post-Test Facility to examine the ceramic//graphite electrode interface to determine possible failure mechanisms and validity, with the assistance of BatPaC, of relying solely on a ceramic coating as the sole electronic insulator (without polymer separator present)
- Continue to support DOE-EERE-VTO programs
- Any proposed future work is subject to change based on funding levels



# SUMMARY

- Completed study of fabricating pre-lithiated electrodes and graphite powder in the dry room
- Characterized LLZO materials to determine thermal treatment effects on phase purity
- Showed that oxide nanoparticles, which scavenge water from the electrolyte, can lower cell capacity fade and impedance rise
- Purchased a multi-functional coating system
  - System will provide coating method flexibility (i.e. single slot die, dual slot die, gravure, knife-over-roll), enhancing our ability to create uniform solid-state-electrolyte and ceramic separator films/coatings onto electrodes
- Provided support to the Behind The Meter Storage program for development of advanced cell systems
- Supplied numerous experimental electrodes and cells to DOE programs

COVID-19 has reduced lab time and may cause delays in completing FY20 milestones

# CONTRIBUTORS AND ACKNOWLEDGMENTS

## Argonne

- Daniel Abraham
- Shabbir Ahmed
- Eva Allen
- Ira Bloom
- Zonghai Chen
- Lina Chong
- Yanjie Cui
- Dennis Dees
- Nancy Dietz-Rago
- Fulya Dogan
- Alison Dunlop
- Trevor Dzwiniel
- Marco Fonseca Rodrigues
- James Gilbert
- Jihyeon Gim
- Andrew Jansen
- Chris Johnson
- Ozge Kahvecioglu
- Feridun
- Kaushik Kalaga
- Donghyeon Kang
- Ryo Kato
- Dave Kim
- Joel Kirner
- Gregory Krumdick
- Joseph Kubal
- Chen Liao
- Kewei Liu
- Wenquan Lu
- Mei Luo
- Mason Lyons
- Paul Nelson
- Bryant Polzin
- Andressa Prado
- Kris Pupek
- Yan Qin
- Abhi Raj
- YoungHo Shin
- Ilya Shkrob
- Juhyun Song
- Naresh Susarla
- Adam Tornheim
- Steve Trask
- John Zhang
- Sanpei Zhang

## Research Facilities

- Materials Engineering Research Facility (MERF)
- Post-Test Facility (PTF)
- Electrochemical Analysis and Diagnostic Laboratory (EADL)
- Center for Nanoscale Materials (CNM)
- Advanced Photon Source (APS)

## Outside Argonne

- Eric Allcorn (SNL)
- Beth Armstrong (ORNL)
- Tony Burrell (NREL)
- Eric Dufek (INL)
- Andrew Colclasure (NREL)
- Kyle Fenton (SNL)
- Matthew Keyser (NREL)
- Robert KostECKI (LBNL)
- Jianlin Li (ORNL)
- Gao Liu (LBNL)
- Shriram Santhanagopalan (NREL)
- Kandler Smith (NREL)
- Tanvir Tanim (INL)
- Gabriel Veith (ORNL)
- Johanna Weker (SLAC)
- David Wood III (ORNL)
- Jason Zhang (PNNL)

**Support from Peter Faguy, Steven Boyd, and David Howell of the Department of Energy's Vehicle Technologies Office is gratefully acknowledged.**

# TECHNICAL BACK-UP SLIDES

The following slides are available for the presentation and included in the Web PDF files released to the public.

## No Technical Back-up Slides