

NO_x Control & Measurement Technology for Heavy-Duty Diesel Engines

W.P. Partridge, J.A. Pihl
Oak Ridge National Laboratory

S. Joshi, N. Currier, R. Daya, K. Kamasamudram, A. Yezerets
Cummins Inc.

H. Hess, H.-Y. Chen
Johnson Matthey Inc.

DOE Vehicle Technologies Office
Annual Merit Review & Peer Evaluation Meeting
June 13, 2019; Arlington, VA

VTO Program Managers:
Gurpreet Singh & Ken Howden

Overview

Timeline

- ***New Project***
 - 2018 VTO AOP Lab Call
 - AOI-1E: Low Temperature Emissions Control (Heavy Duty)
- Year 1 of 3-year
 - Start Date: Oct. 1, 2018
 - End Date: Sept. 30, 2021
 - Percent Complete: 16%

Budget

- 1:1 DOE:Cummins cost share
- FY19 DOE Funding: \$450k
 - DOE share: \$450k
 - Cummins share: \$450k (in kind)

Barriers

- From **21st CTP Research Blueprint**:
 - Emission control cost
 - Low-temperature emission control
 - Robustness in real-world application
- From **U.S. DRIVE Roadmap**:
 - Low-temperature emission control
 - Compliance via Real Driving Emissions (RDE)
 - Emissions control durability

Partners

- ORNL & Cummins Inc.
- Johnson Matthey (participant)

Milestones

FY	Qtr	Milestone & Objectives	Status
2018	4	Experimentally characterize reaction steps for a commercial SCR catalyst, over a conditions relevant to model development	complete
2019	2	Outline structure for half-cycle-based model	complete
2019	3	Protocol experiments on degreened commercial catalyst	on track

Responses to 2018 Review Comments (*Previous Project*)

- Desire to have more project participants
 - *Catalyst supplier formally incorporated as a participant*
 - *Beyond their traditional contributions via the separate CMI-JMI partnership*
- Integrate kinetic model with a thermal model
 - *Cummins' In-House Detailed Model contains kinetics and heat transfer*

Collaborations and Coordination

- **ORNL:** Bill Partridge
- **Cummins:** Saurabh Joshi
- **Johnson Matthey:** Howard Hess
 - Formally included in CRADA and Project documentation



Teamwork & Roles

<u>ORNL</u>	<u>Cummins</u>	<u>Johnson Matthey</u>
<ul style="list-style-type: none">• Diagnostics• Measurements	<ul style="list-style-type: none">• Modeling• Field ageing	<ul style="list-style-type: none">• Model catalyst samples
<div><u>Joint</u><ul style="list-style-type: none">• Planning• Results interpretation• Monthly+ telecons</div>		

Interactions with technical community

- 1 archival publication

W.P. Partridge, S.Y. Joshi, J.A. Pihl, N.W. Currier (2018). "New Operando Method for Quantifying the Relative Half-Cycle Rates of the NO SCR Redox Cycle Over Cu-Exchanged Zeolites," Applied Catalysis B: Environmental, **236**, 195-204. doi.org/10.1016/j.apcatb.2018.04.071
- 1 invited book chapter
- 3 presentations (1 invited)

Key Challenge Addressed by Project


- Efficient catalyst performance under **Field-Aged** & **Low-Temperature** conditions
 - How does field ageing impact SCR reaction network
 - Mechanistic impact of ‘low-temperature’ SCR formulations
 - Improve catalyst durability under **Real-World Driving Conditions**

Relevance

- Durability advances critical to meeting increasing manufacturer warranty requirements
 - Useful Life: compliance on certification drive cycle
 - Warranty: compliance under real-world-driving conditions
 - E.g., Lower temperatures, higher space velocities, & other real-driving ‘off-cycle’ conditions
- Better catalyst performance allows engine to be optimized for fuel efficiency



Heavy Heavy Duty Emissions Regulations				
Current		2022	Projected '26/'27	
CARB/EPA	CARB			
Useful Life (miles)	Warranty (miles)	Warranty (miles)	Useful Life (miles)	Warranty (miles)
435,000 (10vyr, 22k hr)	100,000 (5vyr, 3k hr)	350,000 (5vyr)	1,200,000	800,000

Rapidly Increasing Warranty & Useful-Life Demands




On-Highway Petroleum Use
(Source: Transportation Energy Data Book)

Using Transients to Improve Catalyst Performance





- Conversion Inflections (CI) can occur with Cu/SCR catalysts at SCR onset
 - Fast conversion onset & Slower conversion degradation to steady state level
- CI nature varies catalyst conditions
 - SCR type and temperature
 - Catalyst location (local concentrations and space velocity)
 - Catalyst age
- *Transient CI can be used to understand kinetic origins of catalyst performance*

CI Transient Shape Reflects SCR Kinetic Parameters





- Cu SCR can be viewed as cyclic Cu reduction and oxidation
 - RHC: Reduction Half Cycle** – oxidized Cu (Cu^{II}) is reduced to Cu^{I}
 - OHC: Oxidation Half Cycle** – Cu^{I} is reoxidized to Cu^{II} completing the cycle
- Half-cycle rate imbalances induce CI at SCR onset
 - CI occurs when the RHC rate is faster than the OHC rate; $r_{\text{RHC}} > r_{\text{OHC}}$
 - r_{RHC} progressively slows to match r_{OHC} at steady state
- Detailed CI Shape depends on half-cycle kinetic parameters**
 - Use to study kinetic impact of catalyst ageing & formulation**

CI Transient Response can be Measured for Each Half Cycle




- Experimental 5-Step protocol probes SCR half-cycle components
- SpaciMS allows for spatial mapping of CI transients
 - Evolution of CI transient
 - Variations with concentrations & space velocity




Cu-Redox Model Shows CI Varies with Kinetic Parameters



Standard SCR





$$r_{\text{RHC}} = k_{\text{RHC}} \cdot [\text{Cu}^{\text{II}}] \cdot [\text{NO}] \cdot (\theta_{\text{NH}_3})^{-0} \cong k_{\text{RHC}} \cdot [\text{Cu}^{\text{II}}] \cdot [\text{NO}]$$





$$r_{\text{OHC}} = k_{\text{OHC}} \cdot [\text{Cu}^{\text{I}}]^2 \cdot [\text{O}_2] \cdot [\text{NO}]$$



- Half-cycle models formulated for Standard & Fast SCR
 - Correct formulation & kinetic parameter set will accurately predict CI transient
- Predicted CI more distinct with increasing r-ratio & Temperature ($r\text{-ratio} = r_{\text{RHC}} / r_{\text{OHC}}$)
 - Influence of specific E_a & A factors for RHC & OHC ($k = A e^{-E_a/RT}$)



Cu-Redox Model Predicts Experimentally Observed Trends




- NO CI trends consistent with measured trends along catalyst axis***

- Greatest CI at catalyst front (where NO is high)
- CI degrades along catalyst as NO-conversion progresses

- Many other trends predicted by model***

- More distinct CI at higher temperatures
- RHC & OHC rates converge at SS (mainly due to RHC slowing)



- Cu-Redox model accurately describes transient CI nature***

- Spatiotemporal measurements may be used to tune a kinetic model***

Technical Approach

1. Use Transient-Response Method to determine SCR kinetic parameters

2. Measure CI transient shapes

– 5-Step Protocol & spatiotemporal mapping

3. Fit RHC & OHC kinetic parameters

– Using data & Cu-redox model

4. Baseline DeGreened catalyst kinetic parameters

– Steps 2 & 3

5. Study how **Field Ageing** impacts kinetic parameters


– RHC & OHC specific impacts vs. DeG values

– Pathways to improved durability and control




6. Study how Catalyst **Formulation** impacts kinetic parameters

– Mechanistic origin of formulation benefits

– Pathways to improved low-temperature aged performance




	RHC	OHC
E_a		
A		
k		




FY2019 Activities and Plans

- Measure CI for new state-of-the-art Commercial Cu-SSZ-13 SCR
 - DeGreened & Standard SCR conditions
 - 5-Step Protocol; Spatial & temperature sweeps
- Validate Cummins' In-House detailed model at higher local space velocities
 - AVL Boost; includes transport, kinetics, heat transfer



- Develop detailed half-cycle Cu-oxidation-state model (using AVL Boost)
 - Beyond conceptual and simple kinetic model of previous project
 - Use to fit Cu-redox half-cycle kinetic parameters



- Fit half-cycle kinetic parameters
 - DeGreened Cu-SSZ-13 in Standard SCR
 - RHC & OHC parameters

	RHC	OHC
E_a		
A		
k		

- Proof and refinement Pulsed-Response Experimental-Modeling method
 - Use in FY20 & 21 to quantify kinetic-parameter changes
 - Fundamental insights into field-ageing & formulation

Any proposed future work is subject to change based on funding levels


Remaining Challenges & Future Work

Key Challenge:

- Efficient catalyst performance under Field-Aged & Low-Temperature conditions
 - Mechanistic insights of how Ageing & Formulation impact SCR performance
 - Improved catalyst durability under Real-World Driving Conditions

Future Work:

- **FY20:** Kinetic study of Formulation & Field Ageing impacts
 - How **Field Ageing** impacts RHC & OHC vs DeG baseline Cu-SSZ-13
 - SCR-specific improvement concepts (e.g., dosing, formulation)
 - System-level improvement concepts (e.g., upstream oxidation catalyst)
 - Kinetic origins of **Low-Temperature-Formulation** benefits
 - Understanding performance benefits in the context of kinetic changes
 - Pathways for next-level formulation tuning
- **FY21:** Knowledge integration for improved low-temp aged SCR performance
 - Kinetic analysis of next-level low-temperature formulations
 - Assess pathways to improved catalyst durability
 - Using Cu-redox integrated into In-House model
 - Methods for catalyst-state assessment and control



	RHC	OHC
E_a		
A		
k		



Heavy Duty Emissions Regulations		
Current	2022	ca. '26/'27
Warranty (miles)	Warranty (miles)	Warranty (miles)
100,000 (5yr, 3k hr)	350,000 (5yr)	800,000

Any proposed future work is subject to change based on funding levels

Solution Pathway

Summary

- **Relevance**

- Focus is on kinetic origin of low-temperature performance and field aged SCR catalysts
- Project work enables improved catalyst knowledge, models, design, OBD & control
- Advances DOE goals for improved fuel economy, durability, & real-world emissions

- **Approach**

- Apply experimental protocol to probe transient response of Cu-redox half-cycle steps
- Develop and apply model to fit Cu-redox half-cycle kinetic parameters
- Study kinetic impacts of low-temperature formulations and field-aged catalysts

- **Technical Accomplishments**

- New project and CRADA established
- Catalyst supplier, Johnson Matthey, incorporated into project as participant
- FY19 plan to demonstrate pulsed-response method of determining kinetic parameters

- **Collaborations**


- Johnson Matthey incorporated as project and CRADA participant
- Communicate with community via presentations & publications

- **Future Work** (Any proposed future work is subject to change based on funding levels)

- Determine kinetic origins of performance for low-temperature formulations
- Determine impact of field-ageing on kinetics of commercial Cu-SSZ-13 SCR catalyst









Technical Back-Up Slides

5-Step Experimental Protocol for Studying Onset Transients





- Individual RHC, OHC & SCR transitions investigated
 - Step 1 - **Base**: 5% H₂O + 200ppm NO_x in Ar
 - Step 2 - **RHC**: Base + 200ppm NH₃
 - Step 3 - **OHC**: Base + 0.4% O₂
 - Step 4 - **SCR**: Base + O₂ + 200ppm NH₃
 - Step 5 - **OHCb**: Base + O₂
 - Different SCR mixtures investigated
 - Standard, Fast & NO₂
 - 200ppm NO_x
- Commercial SCR
 - Field Aged: FA-2b
 - 400°C
 - 1/8L
 - 40k SV

Measured Half-Cycle Onset Transients







Measurements of Individual Half-Cycle Onset Transients



- 5-Step Experimental Protocol designed to study half-cycle onset transients & CI
 - Allows individual and combined half cycles to be probed (see Tech. Backup Slides)
- Standard SCR Onset Transients
 - RHC onset shows CI
 - Initial fast step-like transients indicates native RHC rate
 - Conversion degrades over $\sim 200\text{s}$ as Cu^{II} is depleted
 - Non-zero SS due to contaminant or bulk oxygen driving OHC
 - For SCR onset
 - CI is smaller & faster, and SS conversion is greater
 - both half-cycles are active
- NO_2 & Fast SCR Onset Transients
 - Identical, fast, step-like transients without CI
 - Suggests OHC occurring via NO_2 , and O_2 not participating
- OHC transients offer additional insights (see Tech. Backup Slides)

Measurements of Individual OHC Half-Cycle Onset Transients



• OHC Onset Transients

- Starts from maximum [Cu^I] following RHC step
 - [Cu^I] greater than at OHCb start
 - Causes greater step-like onset vs. OHCb transient
- NO₂ & Fast SCR transient are identical
 - Initially step-like, then slow over ~100s as Cu^I is depleted
- Standard SCR show NO CI (see 5-Step Protocol figure)
 - Signal-to-noise is too small to resolve similar N₂ CI

• OHCb Onset Transients


- These follow SCR, and thus start from lower [Cu^I] initial condition
- Slower Standard SCR transient (~150s) vs. NO₂ & Fast SCR (~100s)
 - Different OHC mechanism & kinetics for O₂- vs NO₂-driven OHC
- NO₂ & Fast SCR transients are identical as with OHC
 - Suggests OHC driven by NO₂, and O₂ is practically inert

Half-Cycle based Model for Standard & Fast SCR


Standard SCR



$$r_{\text{RHC}} = k_{\text{RHC}} \cdot [\text{Cu}^{\text{II}}] \cdot [\text{NO}] \cdot (\theta_{\text{NH}_3})^{\sim 0} \cong k_{\text{RHC}} \cdot [\text{Cu}^{\text{II}}] \cdot [\text{NO}] \quad (2)$$




$$r_{\text{OHC}} = k_{\text{OHC}} \cdot [\text{Cu}^{\text{I}}]^2 \cdot [\text{O}_2] \cdot [\text{NO}] \quad (4)$$




Fast SCR





$$r_{\text{RHC}} = k_{\text{RHC}} \cdot [\text{Cu}^{\text{II}}] \cdot [\text{NO}] \cdot (\theta_{\text{NH}_3})^{\sim 0} \cong k_{\text{RHC}} \cdot [\text{Cu}^{\text{II}}] \cdot [\text{NO}] \quad (2)$$



$$r_{\text{OHC}} = k_{\text{OHC}} \cdot [\text{Cu}^{\text{I}}] \cdot [\text{NO}_2] \quad (7)$$





Global Model Predicts Consistent CI Nature & Trends





- Half-cycle model exercised to study how kinetic parameters influence CI
 - Model details shown in Tech. Backup Slides
- Ratio of half-cycle rates ($r\text{-ratio} = r_{\text{RHC}} / r_{\text{OHC}}$) increases with temperature
 - CI should be observed when $r\text{-ratio} > \text{unity}$
 - Unity crossing point tuned with RHC & OHC pre-exponential factors
- CI becomes more distinct with increasing r-ratio
 - Taller peak, faster tail
 - SS conversion increases with r-ratio
 - *Temperature trend is consistent with experimental observations*
- *CI nature varies with half-cycle kinetic parameters*

Global Model – CI varies with NO Concentration





- Varying [NO] at constant 200ppm NH₃
 - CI independent of [NH₃], (zeroth order in [NH₃], see Tech. Backup Slides)
- CI becomes increasingly distinct with increasing [NO]
 - Similar for both N_2 & NO CI

Global Model – CI varies with NO Concentration




- Varying [NO] at constant 200ppm NH₃
 - CI independent of [NH₃], (zeroth order in [NH₃], see Tech. Backup Slides)
- CI becomes increasingly distinct with increasing [NO]
 - Similar for both N₂ & NO CI
- **NO CI trends consistent with measured trends along catalyst axis**
 - Greatest CI at catalyst front
 - CI degrades along catalyst as NO-conversion progresses
- **Spatiotemporal measurements may be used to tune a global model**
 - Determine half-cycle kinetic parameters from fitting model to measurement data

Global Model – Half-Cycle Rates vary with NO Concentration





- r-ratio transient becomes faster with increasing [NO]
 - Distinct CI needs both r-ratio>1 and fast r-ratio transient

Global Model – Half-Cycle Rates vary with NO Concentration





- r-ratio transient becomes faster with increasing [NO]
 - Distinct CI needs **both** $r\text{-ratio} > 1$ **and** fast r-ratio transient
- RHC & OHC rates converge at steady state
 - Mainly due to RHC slowing
 - Relatively small r_{OHC} increase associated with increasing Cu^I
 - Greater SS conversion & rates with increasing [NO] (*consistent with SpaciMS*)
 - Rate transient is greater when initial difference is greater
 - **Half-cycle rate behavior is consistent with conceptual model**
- **Model-based studies help advance CI understanding and nature**

Global Model – Stoichiometry Varies Through CI Transient




- Model predicts CI for NO, NH₃ and N₂
- CI leading edge reflects RHC stoichiometry
 - RHC: $\text{Cu}^{\text{II}}(\text{OH})(\text{NH}_3) + 2 \cdot \text{NH}_3 + \text{NO} \rightarrow \text{Cu}^{\text{I}}(\text{NH}_3)_2 + \text{N}_2 + 2\text{H}_2\text{O}$
- Steady state reflects Net Fast SCR stoichiometry
 - Net Fast SCR: $2 \cdot \text{NO} + 2 \cdot \text{NO}_2 + 4 \cdot \text{NH}_3 \rightarrow 4 \cdot \text{N}_2 + 6 \cdot \text{H}_2\text{O}$
- Stoichiometry transient reflects half-cycle balancing
 - As rates converge impact of the individual half cycles balance
- Generally similar results for Standard SCR (see Tech. Backup Slides)
- **Technique can be use to validate model formulation**



Methodology for Formulating & Validating SCR Redox Model



$$r_{\text{RHC}} = k_{\text{RHC}} \cdot [\text{Cu}^{\text{II}}] \cdot [\text{NO}] \cdot (\theta_{\text{NH}_3})^{\sim 0} \cong k_{\text{RHC}} \cdot [\text{Cu}^{\text{II}}] \cdot [\text{NO}]$$







$$r_{\text{OHC}} = k_{\text{OHC}} \cdot [\text{Cu}^{\text{I}}]^2 \cdot [\text{O}_2] \cdot [\text{NO}]$$



- Step-response experiments to characterize CI & onset transients
 - Range of temperatures and concentrations
 - 5-Step Protocol to investigate individual & combined half cycles
 - **Our measurements are the first to resolve half-cycle rate balancing**
- Formulate global SCR model based on the two half cycles
 - CI & transient nature varies with model formulation & kinetic parameters
 - Examples show broad dependence of transient performance on model parameters
 - Model CI trends are consistent with measurements
 - **Our half-cycle model is the first to show this transient SCR nature**
- Use data to formulate, tune & validate the global SCR model – **Next Steps**

Global Model – CI varies with [NO] but not with [NH₃]



Global Model – Stoichiometry Varies Through CI Transient

