U.S. DEPARTMENT OF ENERGY'S (DOE) VEHICLE TECHNOLOGIES OFFICE (VTO) 2020 ANNUAL MERIT REVIEW (AMR)



DIRECT CATHODE RECYCLING: MATERIAL SEPARATION AND PREPARATION

RECELL CENTER FOR ADVANCED BATTERY



ALBERT LIPSON

RECYCLING

Argonne National Laboratory

bat464 Virtual Poster June 1-4, 2020



PROJECT OVERVIEW

Timeline

Project start: October 2018

Project end: September 2021

Percent complete: ~50%

Budget

FY19 \$4,615k

FY20 \$5,150k

Barriers

- Recycling and Sustainability
 - Cost to recycle is currently 5-15% of battery cost
 - Material shortage (Li, Co, and Ni)
 - Varying chemistries result in variable backend value

Partners


- Argonne National Laboratory
- National Renewable Energy Laboratory
- Oak Ridge National Laboratory
- University of California, San Diego
- Worcester Polytechnic Institute
- Michigan Technological University





RELEVANCE

- Lower cost of batteries
- Enable lower environmental impacts
- Increase our country's energy security







APPROACH

Year 1 – Bench scale testing: Powder-to-Cell



Year 2 – Start to scale up unit operations




Year 3 – Finish scale up and show cell-to-cell recycling



DIRECT CATHODE RECYCLING OTHER MATERIAL RECOVERY





DESIGN FOR RECYCLING MODELING AND ANALYSIS



ReCell does not include battery dismantling, transportation, or 2nd use





PROGRAM MILESTONES

FY19 Q1 Complete Establish the battery recycling center's mission and include its targets and goals

FY19 Q2 Complete Provide an initial progress report on roll-to-roll relithiation

FY19 Q3 Complete Provide an initial progress report on design for recycle initiative

FY19 Q4 Complete Establish the ReCell Center's Battery Recycling Laboratory and Scale-up Facility

FY20 Q1 Complete Electron Backscatter Diffraction data comparison of various chemically delithiated NMC-111 versus pristine NMC-111

FY20 Q2 Complete All five relithiation processes added to EverBatt at lab scale and production scale

FY20 Q3 Ongoing Down-select solvent(s) to separate black mass from current collector and optimize the process conditions to achieve >90% recovery of black mass

FY20 Q4 Ongoing Demonstrate recovery of anode and cathode powders using the new pilot scale froth column

Each Individual project has its own milestones that are not listed here.





PREPARING RECYCLED CATHODE MATERIALS FOR RELITHIATION AND UPCYCLING





THE NEED FOR PREPROCESSING

- After shredding and initial separation the cathode material still has issues that need to addressed
 - Removal of the binder and carbon black
 - The cathode could be a mixture of different compositions that need to be separated
 - Contamination of metals or other materials from the previous steps
 - An understanding of the effects can allow for impurity limits to be developed








APPROACHES TO BINDER REMOVAL

- Thermal Decomposition
 - Heat the material to decompose the PVDF and carbon black to HF, H₂O and CO₂
 - Manage the HF to prevent it from reacting detrimentally with the cathode material
- Solvent Extraction
 - Utilize reduced toxicity solvents
 - Recover the used solvent using a process such as Soxhlet extraction
 - Can recover the PVDF for additional revenue



Thermal Decomposition








EXTENDING THERMAL BINDER REMOVAL TO NMC 622

- Previously shown successful thermal binder removal on pristine NMC 111 materials
 - Combining the thermal binder removal process with delamination processes can start to create a more complete recycling process
 - Delamination can be accomplished by either thermal or a solvent X based process
- Higher Ni content NMC materials create a larger challenge due to the increased phase instability
- Requires higher temperatures and additional LiOH·H₂O to reverse any phase changes
 - Further optimization is needed to improve cyclability and initial capacity




NMC 622 mixed with 3 wt.%
PVDF and 3 wt.% carbon
black processed at 750°C with
8 wt.% LiOH·H2O





A ONE-STEP PROCESS FOR BINDER REMOVAL AND RELITHIATION

- Delithiated materials are more unstable than fully lithiated materials
- Without binder the delithiated NMC 111 can be relithiated at 500°C with LiOH·H₂O
- Adding enough LiOH·H₂O for relithiation and binder removal with 500°C process results in poor performance
- Requires higher temperatures to reverse phase changes that occur during the initial binder removal




10% Chemically Delithiated NMC 111 mixed with 3 wt.% PVDF and 5 wt.% carbon black processed at 500°C






CATHODE SEPARATION VIA FROTH FLOTATION

- Froth flotation is a scalable process that separates materials by differences in the hydrophobicity
- A variety of additives, called collectors, can be added to modify the materials hydrophobicity






Multistep Froth Flotation Separation Process


SEPARATION OF LFP AND NMC111 BY FROTH FLOTATION


- Separation of LFP/NMC111 (1:1 by weight) by froth flotation using Kerosene as collector
- The use of collector effectively increase the hydrophobicity of LFP particles, and consequently increase the separation efficiency to about 99%


(# g) # 1 'O	I	LFP	
	Feed	Froth flotation	
	_	Collector(kerosene)	
		NMC11	11

Product	Weight (g)	Composition (wt. %)		
		%LFP	%NMC11	
Froth	9.25	99.18%	0.82%	
Tailing	9.04	1.08%	98.92%	














SEPARATION OF NCA AND NMC111 BY FROTH


FLOTATION


 Froth flotation process produces 98% purity of NCA materials from a binary NCA/NMC111 mixture with a recovery of 90.4%


 The recycling process maintains the original structure and morphology of cathode materials

Structure and morphology of recycled and pristine cathode materials













ENERGY Energy Efficienc Renewable Ener

CATHODE SEPARATION – WET MAGNETIC


- Bench scale separation of mixtures of virgin cathode powders based on differing magnetic characteristics of components.
 - Separation of ternary mixture of LMO/NMC111/LCO
 - Selectivity of separation is highly dependent on magnetic field strength
 - Higher selectivity results in lower amounts of material collected in the magnetic fraction
 - High purity requires multiple passes through the separator







CATHODE SEPARATION – WET MAGNETIC

- Complete separation of multicomponent mixtures
 - Single components extracted at different field strengths
 - LMO at 0.8 T
 - NMC at 1 T
 - NCA at 1.4 T
 - Magnetic fraction recycled to high purity








Final Result			
Component	Final purity		
LMO	97.4%		
NMC	94.7%		
NCA	91.9%		
LCO	98.7%		






UNDERSTANDING EFFECTS OF CONTAMINANTS

- Recovered materials are a complex mixture of materials
- Real materials will have contamination from various materials from the battery components
 - Al (cathode current collector)
 - Cu (anode current collector and connectors)
 - Fe (battery casing)
 - Other cathode materials
- Understanding the impact of these contaminants on the cathode material will enable contamination limits to be established
- Previously tested Al and Cu contaminates effects







EDX Maps of Recovered Materials



NMC622 CONTAMINATION STUDY – EFFECTS OF Fe AND OXIDATION STATE ON CYCLING

- Effects are strongly dependent on the Fe oxidation state
 - Fe²⁺ shows a small decrease in capacity that gets worse with high Fe content
 - Fe³⁺ causes a large reduction in rate performance








NMC622 CONTAMINATION STUDY – EFFECTS OF Fe AND OXIDATION STATE ON CV

- Effects are strongly dependent on the Fe oxidation state
 - Fe²⁺ shows small increase in peak separation and larger changes between 1st and 2nd cycles
 - Fe³⁺ causes a large reduction in current with a large increase in peak separation indicating high impedance to lithiation



PREPROCESSING FOR DIRECT RECYCLING – ACCOMPLISHMENTS AND RESULTS

- Created a one-step thermal process to effectively remove binder and relithiate cathode materials
- Developed separation techniques that can separate cathode materials to high purity
 - Froth flotation using various collector materials
 - Wet magnetic separation varying the magnetic field intensity and multiple passes
- Tested the effects of impurities on the performance of NMC 622 materials including the effects of impurity oxidation state
- For more information please see <u>www.recellcenter.org</u>, where our Quarterly Reports are posted.





COLLABORATION AND ACKNOWLEDGEMENTS

Support for this work from the Office of Vehicle Technologies, DOE-EERE, is gratefully acknowledged –

Samm Gillard, Steven Boyd, and David Howell













Shabbir Ahmed (Argonne) Yaocai Bai (ORNL) Ilias Belharouak (ORNL) Ira Bloom (Argonne) Anthony Burrell (NREL) Zheng Chen (UCSD) Jaclyn Coyle (NREL) Qiang Dai (Argonne) Sheng Dai (ORNL) Erik Dahl (Argonne) Zhijia Du (ORNL) Alison Dunlop (Argonne) Jessica Durham (Argonne) Kae Fink (NREL) Tinu Folayan (MTU) Linda Gaines (Argonne) Daniel Inman (NREL) Andy Jansen (Argonne)

Sergiy Kalnaus (ORNL) Jarod Kelly (Argonne) Matt Keyser (NREL) Greg Krumdick (Argonne) Jianlin Li (ORNL) Albert Lipson (Argonne) Huimin Luo (ORNL) Josh Major (NREL) Margaret Mann (NREL) Tony Montoya (Argonne) Helio Moutinho (NREL) Nitin Muralidharan (ORNL) Andrew Norman (NREL) Lei Pan (MTU) Anand Parejiya (ORNL) Kyusung Park (NREL) Bryant Polzin (Argonne)

Kris Pupek (Argonne)

Vicky Putsche (NREL) Seth Reed (Argonne) Bradlev Ross (Argonne) Shriram Santhanagopalan (NREL) Jeff Spangenberger (Argonne) Venkat Srinivasan (Argonne) Darlene Steward (NREL) Nathaniel Sunderlin (NREL) Jeff Tomerlin (NREL) Steve Trask (Argonne) Jack Vaughey (Argonne) Yan Wang (WPI) Dustin Weigl (NREL) Olumide Winjobi (Argonne) Panpan Xu (UCSD) Zhenzhen Yang (Argonne)

Jiulina Yu (NREL)

Ruiting Zhan (MTU)





RECELL RECYCLING TOWN HALL FRIDAY, JUNE 5, 2020 FROM 1:00 TO 3:00 (CENTRAL)

To continue the discussion the ReCell team will hold an interactive town hall meeting.

Please join us at the BlueJeans session shown below and ask questions through Slido



Take a picture of this slide

For Information about ReCell



BlueJeans Meeting Access information

Computer

https://bluejeans.com/749203749/9534?src=htmlEmail

Phone

(866) 226-4650

Meeting ID: 749 203 749





Slido Q/A website

Computer or Smart Phone www.Slido.com

Event Code "recell"