


BAT338

EXTREME FAST CHARGING CELL DEVELOPMENT OVERVIEW



VENKAT SRINIVASAN Argonne National Lab **SAMUEL GILLARD**Department of Energy

This presentation does not contain any proprietary, confidential, or otherwise restricted information













OVERVIEW

Timeline

Start: October 1, 2017

End: September 30, 2021

Percent Complete: 37%

Barriers

- Cell degradation during fast charge
- Low energy density and high cost of fast charge cells

Budget

- Funding for FY19 6390k
 - ANL 2400k
 - NREL 1600K
 - INL 440K
 - SLAC 1000K
 - LBNL 950K


Partners

- Argonne National Laboratory
- Idaho National Laboratory
- Lawrence Berkeley National Lab
- National Renewable Energy Laboratory
- SLAC National Accelerator Lab





RELEVANCE: FAST CHARGE REMAINS AN ISSUE FOR WIDESPREAD ADOPTION OF EVS





Fast charging a major issue. While fast charge cells exist, they are cost prohibitive or have poor life






RELEVANCE: WHAT LIMITS FAST CHARGE?












RELEVANCE: CHALLENGES AT MULTIPLE





QUESTIONS TO HELP MAP THE PROBLEM

- 1. How does the anode design (loading, porosity...) influence the propensity for Li plating? BAT339
- 2. How does the charging protocol and extended cycling impact degradation (anode *vs.* cathode) during fast charge? **BAT340**
- 3. Can we quantify the bottleneck at the electrode scale? Can we start to examine solutions to enable fast charge? **BAT371**
- 4. How important are local heterogeneities in determine the propensity for Li plating? Does Li transport in graphite depend on charging rates? **BAT383**
- 5. Can we detect Li plating in situ? And at what scale? BAT384





COLLABORATION ACROSS LABS AND UNIVERSITIES



Cell and electrode design and building, performance characterization, post-test, cell and atomistic modeling, cost modeling



Li detection, electrode architecture, diagnostics



Performance characterization, failure analysis, electrolyte modeling and characterization, Li detection



Thermal characterization, life modeling, micro and macro scale modeling, electrolyte modeling and characterization



Li detection, novel separators, diagnostics

















CONTRIBUTORS AND ACKNOWLEDGEMENTS

Aashutosh Mistry Andy Jansen Abhi Raj Alison Dunlop Andrew Colclasure Antony Vamvakeros Aron Saxon Bryan McCloskey

Bryant Polzin Chuntian Cao Daniel Abraham Daniel Steingart Dave Kim

Dave Kim
David Robertson
David Wragg
Dean Skoien
Dennis Dees
Donal Finegan
Eongyu Yi
Eric Dufek

Francois Usseglio-Viretta Francesco De Carlo

Guoying Chen Hakim Iddir

Hans-Georg Steinrück

Hansen Wang

Ilya Shkrob Ira Bloom Jiayu Wan Jianming Bai

Johanna Nelson Weker

Joha Masinski
John Okasinski
Juan Garcia
Kamila Wiaderek
Kandler Smith
Kaushik Kalaga
Kevin Gering
Marca Doeff
Marco DiMichiel
Marco Rodrigues
Matt Keyser
Michael Evans

Michael Toney Nancy Dietz Rago Nitash Balsara Olaf Borkiewicz Partha Mukherjee

Partha Paul Paul Shearing Pavel Shevchenko

Pierre Yao Ravi Prasher Ren Yang Robert Kostecki Ruqing Xu Rvan Jackman

Sang Cheol Kim Sangwook Kim

Sean Wood Seoung-Bum Son Shabbir Ahmed

Shriram Santhanagopalan

Steve Trask Tanvir Tanim Uta Ruett

Venkat Srinivasan Victor Maroni

Vince Battaglia Vivek Thampy

Wei Tong Weijie Mai

Wenxiao Huang William Huang

Yanying Zhu Yi Cui

Zhenzhen Yang











Support for this work from the Vehicle Technologies Office, DOE-EERE – Samuel Gillard, Steven Boyd, David Howell


















APPROACH: COMBINE CUSTOM DESIGNED ELECTRODES WITH ADVANCED CHARACTERIZATION AND MULTISCALE MODELING

Leverage the strengths among the partner institutions



Cells with different designs

- Different graphite's
- Different loading
- Cells with and without reference electrode

Fast charge testing and electrochemical diagnostics

- Different charge rates.
- Short vs. long term cycling
- Coulombic efficiency
- Electrochemical signatures of plating

Characterization: in situ and post test.

- X-ray-based: reaction distribution
- Li detection: SEM, XPS.
- SEI detection: Raman, FTIR, XPS, HPLC
- Particle cracking: XRD, SEM







DETECTING LI PLATING: A CHALLENGE

In situ methods. Question: How close to nucleation can we detect plating?

- Electrochemical (coulombic efficiency, capacity fade, electrochemical signatures)
- Reference electrode methods
- Acoustic
- Thermal
- X-ray-based analysis
- Gas evolution

• ...






Detecting Li plating in situ at its initiation remains a key challenge






MODELING AT DIFFERENT SCALES TO IDENTIFY LIMITATIONS

Electrode level effects




Microstructure scale effects




Extreme Fast Charge Cell Evaluation of Lithium ion Batteries



Particle-scale issues




Graphite layer scale



ANODES CYCLE WELL...EVEN WHEN THEY PLATE


6 C charge on 2 mAh/cm² anode cells



Thin cells cycle well. And fade seems similar with different graphite's and on CMC-SBR and PVDF binder cells


WHAT HAPPENS WHEN WE INCREASE THE LOADING?

Conoco Philips GCP-A12





Results suggest the need to examine the reaction distribution in the porous anode

IN SITU SYNCHROTRON EDXRD DETECTION OF REACTION DISTRIBUTION



MODELS SHOW REASONABLE PREDICTIVE CAPABILITY










MODEL PROVIDES INSIGHTS INTO OBSERVATIONS


Low Electrode Loading

- 1.5 mAh/cm² cathode (42 µm)
- 1.84 mAh/cm² anode (43 µm)



Medium Electrode Loading

2.5 mAh/cm² cathode (71 μ m) 3.07 mAh/cm² anode (87 μ m)




Fast charging will require enhancing the electrolyte transport in the porous electrode





MODELS SHOW IMPACT OF DIFFERENT APPROACHES

4 mAh/cm² (230 Wh/kg cell; 110 micron electrodes)




 Next Gen Electrolyte = 2X ionic conductivity, 4X diffusivity, and transference number increased by 0.15








WE ARE NOW EMBARKING ON TESTING THESE PREDICTIONS





Higher transport property electrolytes


Reducing tortuosity in the anode





HETEROGENEITIES BECOMING A FOCUS AREA


Heterogeneities at all length scales cause early onset of Li plating



VEHICLE TECHNOLOGIES OFFICE

Li DETECTION EFFORTS PROVIDING INSIGHTS

Cycling: 6C, CCCV, 450 cycles




- Intensities of Li and Gr anti-correlated
- Intensities of Li and LiC₆/LiC₁₂ correlated
- · NMC shows pattern; no obvious correlation with Li





WE ARE ALSO SEEING EARLY EVIDENCE OF CATHODE CRACKING







REMAINING CHALLENGES AND BARRIERS

Will be discussed as part of BAT386

PROPOSED FUTURE RESEARCH


Will be discussed as part of BAT386


Any proposed future work is subject to change based on funding levels.






SUMMARY









Cathode fade starting to come to focus

