

Interfacial Processes in EES Systems Advanced Diagnostics

Robert Kostecki

Lawrence Berkeley National Laboratory
Berkeley, California 94720

2019 Annual Merit Review
June 10-13, 2019

Project ID# BAT085

This presentation does not contain any proprietary, confidential, or otherwise restricted information

Overview

Timeline

- This project was recompleted in FY15 and renewed in FY16.
- This project is 70% complete

Barriers Addressed

- Inadequate Lithium and Li-ion battery energy and power density, and calendar/cycle lifetimes for PHV and EV applications
- High cell/electrode/interface impedance that limits power and affects system safety

Budget

- FY19 funding \$320k
- FY18 funding \$440K
- FY17 funding \$440K
- FY16 funding \$440K

Partners

- ABMR Research Groups
 - ANL, LBNL, SUNY, UP, HQ, NREL, URI, UM and UU
 - G. Chen, V. Battaglia, M. Doeff, K. Persson, V. Zorba, W. Yang, C. Martin, C. Ban, B. McCloskey
 - ALS, H. Bechtel, E. Crumlin
- UCL (UK), P. Shearing
- University of Liverpool (UK). L. Hardwick
- Central Laser Facility, Research Complex at Harwell (UK)
- Umicore, Farasis Energy, Inc.

Relevance: Objectives



1. Apply *in situ* and *ex situ* x-ray and optical far- and near-field optical multifunctional probes to obtain detailed insight into the active material structure and the physio-chemical phenomena at electrode/electrolyte interfaces at a spatial resolution that corresponds to the size of basic chemical or structural building blocks.
2. Design new diagnostic techniques and experimental methodologies that are capable to unveil the structure and reactivity at hidden or buried interfaces and interphases that determine material, composite electrode and full cell electrochemical performance and failure modes.
3. Understand the mechanism of operation and degradation of high energy density materials for rechargeable batteries for PHEV and EV applications.
4. Propose effective remedies to address Inadequate Li-metal based battery calendar/cycle lifetimes for PHV and EV applications

Approach

- Develop, apply and couple advanced characterization techniques, such as optical and scanning probe spectroscopy and microscopy with standard electrochemical methods to determine function, operation and degradation of materials, electrodes and battery cells.
 - Design and develop new XAS/XPS experimental setup to characterize in situ solid/solid (e.g., NMC/SSE Li/SSE) interfaces.
 - Characterize the chemistry of solid-state electrolyte/Li and electrolyte/cathode interfaces with *ex situ* and *in situ* near field IR, XAS and XPS.
- Manufacture thin-film and composite electrode/electrolyte model systems for fundamental electrochemical studies of interfacial phenomena in Li-metal battery systems.
 - Characterize the bulk and surface structure of Li anode, NMC cathode electrodes and liquid and solid-state electrolytes and its relation to electrochemical and interfacial properties.
- Work closely with other investigators in the ABMR Program to support development of new electrode materials for high-energy Li-metal based rechargeable cells.

Study of New Co-Block Polymer Binders for Li-S Batteries



Background



- Hydrophilicity of PEO can promote local binding with Li-polysulfides, which can confine these intermediates compounds in the cathode and inhibit active material loss.
- PEO can also dissolved in glyme-based electrolytes e.g., 1,2-dimethoxyethane (DME):1,3-dioxolane (DOL) (1:1, vol).

Study of New Co-Block Polymer Binders for Li-S Batteries

Approach

Sample	Ref. PVdF	Block Copolymer 1801 (Polymer Source, Inc)	Block Copolymer 40890 (Polymer Source, Inc)
Chain Structure	 <p>PVDF</p>		
Weight % of aliphatic chain	100%	82%	65%


- Substitute part of the ethylene oxide unit with polystyrene to prevent dissolution of PEO-Li₂S_x clusters in the electrolyte.
- Assure good mechanical properties of the binder in the composite electrode.

Study of New Co-Block Polymer Binders for Li-S Batteries


Proof of Concept

0.02g of binder was added to 5 ml
5 mmol Li polysulfides solution in
DOL/DME(1/1 vol.)


PVdF



65% PEO




82% PEO



Day 1 Day 3 Day 10



UV-Vis Spectroscopy



Ethylene oxide unit in co-block polymer binds with polysulfides.

Study of New Co-Block Polymer Binders for Li-S Batteries

Electrochemical Testing



2032 coin cell equipped with composite cathode C:S:binder 0.3:0.56:0.1, 50 μl 1M LiTFSI and 2% LiNO_3 in DOL/DME electrolyte, Celgard 2325 separator, Li-foil anode





The sulfur composite cathode with PEO-PS (65:35 wt%) binder shows the improved capacity retention. Lower irreversible capacity loss, and higher coulombic efficiency ca. 99.6% vs. PVdF and PEO-PS (85:15 wt%) electrodes after 150 cycles.

Study of New Co-Block Polymer Binders for Li-S Batteries

In operando X-Ray Absorption Spectroscopy




1st Discharge-Charge Cycle at C/5

In Situ XAS Cell



Ex situ X-Ray Photoelectron Spectroscopy



After 1st Discharge-Charge Cycle at C/5



Sulfur K-edge XAS and XPS measurements of the electrolyte and Li-anode reveal that the presence of PEO-PS (65:35 wt%) binder in the sulfur composite cathode suppresses lithium polysulfides formation and dissolution.


Kerr-Gated Raman Spectroscopy of Fluorescent Species in Li and Li-ion Batteries

- *Fluorescent species are formed during cycling of Li and Li-ion batteries as a result of electrolyte decomposition at the electrode surface.*
- *Strong fluorescence background makes it harder to analyze data due to the spectroscopic overlap of Raman scattering and fluorescence.*




Kerr gate Raman has been proven to be an efficient technique for the suppression of fluorescence emission.

It has never been used to mitigate fluorescence background from Raman studies of Li and Li-ion battery electrode materials and interfaces.



Kerr-Gated Raman Spectroscopy of Fluorescent Species in Li and Li-ion Batteries




Peak	Position/ cm^{-1}	Assignment
1	365	$\delta(\text{PF}_3)$: POF_3
2	481	$\delta(\text{PF}_3)$: POF_3 ; LiPF_6
3	525	PF_5
4	568	$\delta_{\text{as}}(\text{PO}_2\text{F})$: $[\text{P}_2\text{O}_5\text{F}_2]^{2-}$
5	672	--
6	771	$\delta(\text{POP})$: $[\text{P}_2\text{O}_5\text{F}_2]^{2-}$; LiPF_6
7	899	$\nu(\text{PF}_3)$: POF_3 ; $\nu(\text{PF})$: $[\text{P}_2\text{O}_5\text{F}_2]^{2-}$
8	975	$\nu_{\text{asym}}(\text{PF}_3)$: POF_3
9	1167	$\nu_{\text{sym}}(\text{PO}_2)$: $[\text{P}_2\text{O}_5\text{F}_2]^{2-}$
10	1199	$\nu_{\text{asym}}(\text{PO}_2)$: $[\text{P}_2\text{O}_5\text{F}_2]^{2-}$
11	1345	--
12	1596	--

Notation: ν : stretching; δ : bending; Asym: asymmetric; Sym: symmetric

- The PF_6 peaks are observed at 480 and 770 cm^{-1}
- New bands at 365, 525, 568, 672, 899, 975, 1200 and 1595 cm^{-1} are related to the presence of LiPF_6 decomposition products on the surface of pristine particles.

Collaboration with University of Liverpool (L. Hardwick) and Central Laser Facility, Research Complex at Harwell (UK)

Kerr-Gated Raman Spectroscopy of Fluorescent Species in Li and Li-ion Batteries



Kerr gate Raman spectra at 0 ps delay of 1 M LiPF₆ in EC/DMC (1:1w/w); fresh, after 11 minutes exposure to air, after addition of water and after aging for 2 days in water

- Slight shift towards higher frequencies of -C=O band in DMC from 1756 cm⁻¹ to 1760 cm⁻¹ after water addition.
- -C=O EC peak broadening at 1777 cm⁻¹ and a decrease in the relative intensity of the peak at 1805 cm⁻¹.
- These changes could be tentatively associated to the coordination of the water molecule to C=O carbonate group of the solvent via hydrogen bonds.
- No evidence of EC hydrolysis was observed (as suggested in literature).

Summary

1. Ethylene oxide-polystyrene co-block polymer binders can prevent dissolution of Li-polysulfides in the electrolyte and help improve long-term electrochemical performance of Li-S batteries.
 - 65% ethylene oxide unit co-block polymer binder inhibits Li-polysulfides dissolution and maintain mechanical integrity of the sulfur cathode during cycling.
 - High content of ethylene oxide (82%) in the co-block polymer lead to dissolution of the binder and Li-polysulfides into electrolyte and its accumulation on the surface of Li-anode.
2. Carried out proof-of-concept Kerr gated Raman experiments to investigate electrolyte degradation processes Li and Li-ion batteries.
 - The present study shows for the first time that Kerr gate Raman can be applied *ex situ* or *in situ* in the investigation of electrode/electrolyte interfaces of battery systems even in the presence of fluorescent species formed during cycling.

Proposed Future Research

- *Control of the interfacial chemistry of the electrodes in lithium batteries is vitally important to their safe and effective application.*
- *The entire lithium electrode can be completely consumed by reactions with the solvent if the interfacial chemistry does not form self-limiting passive film.*
- *No effective remedy to these problems have been developed despite intense empirical effort to achieve it.*


Approach

- Eliminate the effect of adventitious impurities in the electrolyte and uncontrolled surface layer on lithium foil.
 - Pre-form a surface film on metallic lithium that would be superior to the film formed spontaneously in the electrolyte.
- Develop and apply novel innovative experimental methodologies to study and understand the basic function and mechanism of operation of materials, composite electrodes, and Li-ion cells for PHEV and EV applications.
 - Use a combination of classical electrochemical methods, spectroscopic ellipsometry and UHV methods of surface preparation and characterization.
 - Develop *in situ* XPS and Near-Field IR Spectroscopy to study Li electrode/electrolyte interface Electrode Surface Films
 - Advance beyond steady state measurements towards time-resolved measurements to understand interfacial reactions kinetics and dynamics
- Work closely with ABMR PIs and industry partners to establish clear connections between diagnostics, theory/modelling, materials synthesis, and cell development efforts.

Technical Back-Up Slides



Need to Advance Beyond Steady State towards Time-Resolved Measurements to Understand Kinetics and Dynamics

Develop Time-Resolved APXPS




Apertureless Near-Field IR Microscopy/Spectroscopy


Neaspec Scattering-type Scanning Near-field
Optical Microscopy (NeaSNOM)



Synchrotron Infrared Nano
Spectroscopy (SINS)



H. A. Bechtel et al., *Acad. Sci. USA*, **111**, 7191 (2014).



- BMR Program and LBNL have been pioneering the development and use of IR SNOM techniques to study basic phenomena in energy storage systems.*
- We need to develop in situ nanoscale characterization of liquids and electrochemical interfaces with advanced NFIR techniques*