

Rechargeable Lithium Air Batteries

PIs: Ji-Guang Zhang & Wu Xu
Pacific Northwest National Laboratory

Project ID # BAT443
June 3, 2020

Overview

Timeline

- Project start date: Oct. 1, 2016
- Project end date: Sept. 30, 2020
- Percent complete: 89%

Budget

- Total project funding:
 - DOE Share: 100%
- Funding for FY19: \$200k
- Funding for FY 20: \$200k

Barriers and Technical Targets

- **Short cycle life:** Need functional electrolytes and Li metal protection to stabilize electrode/electrolyte interface.
- **Low coulombic efficiency:** Need functional catalysts and soluble additives to decrease large overpotential during charging.

Partners

- U.S. Army Research Laboratory

Relevance/Objectives

Relevance

Design and understanding of electrolytes and electrode/electrolyte interface in Li-air batteries (LABs) are critical for the development of LAB technology as the next-generation of high energy density battery systems for practical applications.

Objectives

Develop innovative electrolytes and Li metal stabilization concepts for stable cycling of LABs.


- Develop efficient and reliable electrolytes to improve the efficiency and cycle life of LABs.
- Develop promising and facile concept to stabilize Li metal anode and air electrode for long-term cycle life of LABs.

Milestones

Milestone Name/Description	Milestone End Date	Status
Develop stable electrolytes to minimize the parasitic reactions at the electrodes.	12/31/19	Completed
Protect anodes to prevent Li dendrite and LiOH formation.	3/31/20	Completed
Develop stable additives (solid or soluble) or methods for sustainable catalytic effect.	6/30/20	On track
Evaluate cycling performance of Li-O ₂ batteries with optimized cell components and conditions.	9/30/20	On track




Approaches

- Use a localized high-concentration electrolyte (LHCE) to enhance the stability of the electrolyte against singlet oxygen, which is the main cause of parasitic reactions in LABs using conventional typical 1 M Tetraglyme-based electrolyte.
- Investigate fundamental mechanism of LHCE as an effective electrolyte for LABs with comparison to a conventional electrolyte and high-concentration electrolyte (HCE).
- Study effect of different diluents in LHCEs to develop more suitable diluents and electrolytes for LABs.



Technical Accomplishments

Effects of conductivity and viscosity of electrolytes on discharge capacity of Li-O₂ batteries (LOBs)




- Ionic conductivity at 25 °C: 1 M LiTf in G4 > OTE-LHCE > HCE
- Viscosity at 25 °C: 1 M LiTf in G4 < OTE-LHCE <<< HCE
- Discharge capacity at 25 °C: 1 M LiTf in G4 > OTE-LHCE >>> HCE
- **Viscosity of electrolyte is a critical factor for performance of LOBs.**

LiTf: Lithium trifluoromethanesulfonate
G4: Tetraethylene glycol dimethyl ether (Tetraglyme or TEGDME)
OTE: 1H,1H,5H-Octafluoropentyl 1,1,2,2-tetrafluoroethyl ether

Technical Accomplishments




Stability of LHCE against Li metal anode and high oxidation potential



- Oxidation potential: OTE-LHCE > HCE > 1 M LiTf in G4
- Cycle life of Li-Li symmetric cell test: OTE-LHCE >>> 1 M LiTf in G4 > HCE
- LHCE has the highest oxidation potential compared to other electrolytes, which is helpful for stable operation of LOBs and LABs during charging.
- LHCE stabilizes the Li metal anode, which is confirmed by stable stripping and plating processes in Li||Li cells.

Technical Accomplishments


Cycling performance of LOBs using different electrolytes



- Cycle life of Li-O₂ batteries: OTE-LHCE > 1 M LiTf in G4 > HCE
- LOBs using LHCE exhibit better cycling stability than those using other electrolytes.

Technical Accomplishments



Calculation on the stability of electrolytes against singlet oxygen



- Calculated stability of electrolytes against $^1\text{O}_2$: OTE-LHCE > HCE > 1 M LiTf in G4
- **LHCE exhibits the highest stability against singlet oxygen attack.**

Technical Accomplishments


NMR analyses for stability of chemicals against singlet oxygen



- OTE (diluent) is stable against $^1\text{O}_2$, but G4 is decomposed by $^1\text{O}_2$ attack.
- It is consistent with the calculated results on the higher stability of OTE-LHCE than HCE and 1 M LiTf in G4.

Technical Accomplishments



Li metal morphologies after cycling in LOBs



- SEM images show that the Li metal anode is much more stable in LOB using LHCE than those using other electrolytes.

Technical Accomplishments




Effects of O_2 solubility and viscosity of electrolytes on discharge capacity of LABs (21% O_2)



- O_2 solubility at 25 °C: OTE-LHCE \gg 1 M LiTf in G4 $>$ HCE
- Viscosity at 25 °C: 1 M LiTf in G4 $<$ OTE-LHCE \lll HCE
- Discharge capacity at 25 °C: OTE-LHCE \gggg 1 M LiTf in G4 $>$ HCE
- O_2 solubility in electrolyte as well as viscosity of electrolyte become main limiting factors for performance of LABs in ambient air (21% O_2).

Technical Accomplishments


Cycling performance of LABs using different electrolytes



- Cycle life of LABs (21% O₂): OTE-LHCE >>> 1 M LiTf in G4 > HCE
- LABs (21% O₂) with LHCE exhibit much better cycling performance than those using other electrolytes.

Technical Accomplishments



Understand the advantages of LHCE for LOBs and LABs



- ▼ Unstable to Li metal
- ▼ Poor stability to $^1\text{O}_2$
- ▲ Low viscosity, good wetting, low cost

- ▲ Stable to Li metal
- ▲ More stable to $^1\text{O}_2$ than 1M LiTf in G4
- ▼ High viscosity, poor wetting, high cost



- ▲ More stable to $^1\text{O}_2$ and Li than HCE
- ▲ High oxygen solubility
- ▲ Low viscosity, good wetting, low cost



LAB or LOB is much more stable with LHCE electrolyte.

Technical Accomplishments



Temperature dependence of viscosity and conductivity of electrolytes



- Viscosity at 25 °C: TFEO-LHCE < 1 M LiTf in G4 < TTE-LHCE < OTE-LHCE <<< HCE
- Conductivity at 25 °C: TTE-LHCE > TFEO-LHCE > 1 M LiTf in G4 > OTE-LHCE > HCE

Technical Accomplishments



O₂ solubility and volatility of electrolytes



- O₂ solubility: TFEO-LHCE > OTE-LHCE > TTE-LHCE > HCE > 1 M LiTf in G4
- Volatility: HCE ≈ 1 M LiTf in G4 < TFEO-LHCE ≈ OTE-LHCE <<<< TTE-LHCE

Technical Accomplishments


Cycling performance of LOBs using different electrolytes



- Cycle life of LOBs: OTE-LHCE \gg 1 M LiTf in G4 $>$ TTE-LHCE $>$ TFEO-LHCE $>$ HCE
- LOBs using OTE-LHCE exhibit longer cycle life than those using other electrolytes.

Technical Accomplishments

Stability of different diluents against singlet oxygen



Compound	DFT calculation		Molecular weight (mol/g)	Boiling point (°C)	Density (g/ml)
	HOMO (eV)	LUMO (eV)			
TFEO	-8.62	-0.18	310.11	143	1.457
TTE	-9.61	-0.21	232.07	92	1.532
OTE	-10.02	-0.68	332.09	133	1.616

- Calculated stability of chemicals against $^1\text{O}_2$: OTE > TTE > G4 > TFEO
- OTE exhibits the highest stability against singlet oxygen attack.**
- Stability of TFEO is worse than G4, which is the reason for the poor cycle life of LOBs using TFEO-LHCE.**

Responses to Previous Year's Reviewers' Comments

- This project was not reviewed last year.

Collaboration

- Dr. Jeffrey Read (U.S. Army Research Laboratory) for measurements of O₂ solubility in electrolytes and volatility of electrolytes.

Remaining Challenges and Barriers

- Low energy efficiency due to extremely high overpotential during charge.
- The compatibility of LHCE with additives (solid or soluble).
- Evaporation of electrolyte due to relatively high volatility of diluents.

Proposed Future Research

- Suitable additives (solid or soluble) or methods for sustainable catalytic effects should be adapted.
- Optimization of electrolyte components (LHCEs and additives) by evaluation of cycling performance of Li-O₂ batteries.
- Systematical design and synthesis of stable chemicals as solvents and diluents with low vapor pressure, high O₂ solubility, good mixability, and wide electrochemical redox potential.

Any proposed future work is subject to change based on funding levels.

Summary

- LHCEs lead to much longer cycling performance for LOBs and LABs due to their lower viscosity, better stability with Li metal and reactive singlet oxygen, and their higher oxygen solubility.
- OTE is the best diluent for LHCE because of its lower volatility and higher stability against reactive singlet oxygen.
- Stability against singlet oxygen is a critical factor in stability of electrolyte and cyclability of LOBs and LABs.

Acknowledgements

- Financial support from the DOE VTO BMR program is greatly appreciated.
- DOE/BER/EMSL for microscopic and spectroscopic characterizations and computational calculations.
- Team Members: Won-Jin Kwak, Sujong Chae, Hyung-Seok Lim, Ruozhu Feng, Peiyuan Gao, Mark H. Engelhard, Lirong Zhong