# Scale-up and Testing of Advanced Materials from the BATT Program

Vincent Battaglia, Ph.D.

Lawrence Berkeley National Laboratory

May 15, 2013

ES029)

# Overview

#### **Timeline**

Start: 10/2009

End: 9/2013

Percent complete: 87.5

#### **Budget**

Total project funding:

\$760 k

(DOE Share: 100 %)

Funding received in FY12:

\$ 190 k

Funding for FY13:

\$190 k

#### **Barriers**

- Barriers / Targets addressed
  - Cost System = 100 \$/kWh
  - Performance Power: Energy =2:1
  - Life Deep discharge cycles = 750

#### **Partners**

NEI

ANL

Daikin

SNL

Umicore

CWRU

Conoco Phillips

U. Texas

Timcal

Celgard

# Relevance / Objectives

- Objective for 2012-2013:
  - Using high-quality coin cells, evaluate materials as they are developed in the BATT program and compare to an industry standard.
  - Evaluate materials for a baseline LiNi<sub>1/2</sub>Mn<sub>3/2</sub>O<sub>4</sub> system for ABR and BATT.
- Relevance to Vehicle Technology Program:
  - This provides a mechanism for measuring progress within the Program.
  - Both the more applied and more fundamental Programs are interested in high-voltage cathodes to find a path to high energy.
- Impact on barriers:
  - Allows DOE to track progress toward energy density and cycle life goals.

# Milestones

 Test a number of BATT materials and present at the DOE AMR.


 Test a number of materials for the highvoltage cathode system for ABR and BATT and report at DOE AMR.

# Approach/Strategy


- Unique aspects of work:
  - Research focused on making high quality electrodes and cells
  - Ability to assess power capability of material in similar electrodes; determine sources of capacity (side reactions, phase changes, resistance rise) and power (ohmic, kinetic, and mass transfer resistance of cathode and anode) fade.
- Technical barriers addressed
  - Standard electrodes made and rate tested
  - Cycle life measured
- Integration with ABR and BATT
  - Work closely with BATT Pls to identify promising materials
  - Work closely with ABR suppliers to identify nextgeneration materials

#### **Assessing BATT PI Materials**

#### Scherson's nonflammable salt



**Baseline Electrolyte** 




Baseline Electrolyte+ VC + Flame retardant salt

No negative impacts on cycle life; Encouraged to test in large cells for abuse characteristics.

Assessing BATT PI High-Voltage Materials

#### **Baseline Material (NEI)**

w/graphite anode




Half the capacity lost in both cells before C/3 testing; nearly all capacity lost in 100 cycles at 55°C

Assessing BATT PI High-Voltage Materials


#### **Baseline Material (NEI)**

w/graphite anode










Side reaction on anode increases with temp.to *ca*. 0.51 mA/g at 55°C;

Charge limit diving rapidly, initially. Side reaction on anode accelerates at C/3.

Assessing BATT PI High-Voltage Materials

#### **Baseline Material (NEI)**

w/graphite anode




At 30°C the material experiences a phase transformation from a 2-phase material to a single phase material and the cell experiences a high first cycle inefficiency.

One sees the anode marching along while the cathode stays put.

Assessing BATT PI High-Voltage Materials


#### **Baseline Material (NEI)**




At 30°C the transformation appears complete as the rate is increased. With the transition to 55°C the phase transformation is complete after 1 cycle and the cell experiences a second high first cycle inefficiency.

#### Assessing BATT PI Two High-Voltage Materials

#### 2 P.I. Materials @ 55°C






The doped material appears to hold up better through the first 15 cycles; both suffer the same fate upon subsequent cycling.

Assessing BATT PI High-Voltage Materials


#### 2 P.I. Materials @ 55°C



Side reaction on anode *ca*. 1.25 mA/g before it accelerates at 375 hours.

Large capacity drop when rate increased from C/20 to C/10

Large irrev. loss when temperature rose from 30 to 55°C.




Side reaction on anode *ca*. 0.83 mA/g before it accelerates at 375 hours.

Not much loss with switch in cycling rates

Assessing BATT PI High-Voltage Materials


### 2 P.I. Materials @ 55°C




No phase change seen in the voltage curves during the first 10 cycles at 55°C.


Assessing Supplier High-Voltage Materials

C65 New Conductive Additives from Timcal






Super P



These high surface area carbons form chains which are integral to their performance

The Super P consists of the largest particles.

#### Assessing Supplier High-Voltage Materials



#### Carbon's to be tested


- Acetylene black (AB, from Denka - baseline)
- VGCF
- Super P-Li (from Timcal)
- Super C 65 (from Timcal)
- Super C 45 (from Timcal)

#### Baseline cell conditions


- LNMO/Li half-cell
- Cathode: LNMO (NEI #3)/PVDF/ Conductive additive
- LiPF<sub>6</sub>/EC-DEC (Daikin, 1M, 1:2 vol)
- Celgard 2400 separator Test rate: C/10
- Cut-off potential: 4.99V


Large side reaction in the presence of Li counter electrode

Assessing Supplier High-Voltage Materials











All of these carbons show erratic voltage behavior as a result of the production of a gas.


Assessing Supplier High-Voltage Materials












- Lower loading cathodes w/ Super P do not display the erratic voltage behavior.
- This is not seen for the low loading cathodes with C45.
- Lower loadings w/Super P form less CO<sub>2</sub> and can be reduced by the lithium.

#### Assessing Supplier High-Voltage Materials

Celgard 2400

**Alternative Separators** 

- Celgard 2500
- Celgard 3501





Product	Thickness	JIS Gurley	Porosity	TD Shrinkage	Materials
2400	25 μm	620 seconds	Medium	0%	PP
2500	25 μm	200 seconds	High	0%	PP
3501	25 μm	200 seconds	High	0%	PP

#### **Cell Testing Materials and Protocol**


- LNMO/Li half-cell
- LNMO (NEI #3)/PVDF/AB
- LiPF<sub>6</sub>/EC-DEC (Daikin, 1M, 1:2 vol)
- Test rate: C/10
- Cut-off potential: 4.85V

Assessing Supplier High-Voltage Materials









Separator with lower porosity and permeability resolves the erratic voltage issue during charge.

# Collaboration and Coordination with Other Institutions

- NEI
  - Partner, Industry, outside VT, materials
- Daikin
  - Partner, Industry, outside VT, materials
- Umicore
  - Partner, Industry, outside VT, materials
- Conoco Phillips
  - Partner, Industry, outside VT, materials
- Timcal
  - Partner, Industry, outside VT, materials
- Celgard
  - Partner, Industry, outside VT, materials
- Case Western Reserve University
  - Partner, University, within VT, material exchange
- University of Texas
  - Partner, University, within VT, material exchange
- ANL
  - Partner, Federal Lab, within VT, information exchange
- SNL
  - Partner, Federal Lab, within VT, information exchange

# **Future Work**

- Test additional BATT PI materials.
  - Focus on Electrolytes and Anodes the rest of this year
    - Electrolyte additive from ANL is under test.
    - · A cathode material from LBNL is on its way
- Work with others to understand the acceleration of side reactions with cycling at 55°C and screen possible alternative electrolytes.
- Verify the production and composition of a gas in the cell via the use of a mass spec. This may help identify the source of the gas.
- Test a cell where the gas is extracted during testing to see if the erratic cell behavior can be affected.
- Develop advanced electrolytes via the recently announced DOE FOA.

# Summary

- Scherson's flame retardant salt additive shows no measureable negative impacts on cycleability.
- BATT Pl's cathode materials show improvement in phase transition but still suffer at high temperature due to unstable electrolyte.
- The presence of high-surface area conductive carbon contributes to the amount of side reaction in the high voltage cathode.
- Cells with lithium show an erratic voltage during charge. We believe this is due to the formation of gas.
- Super P results in the least amount of erratic behavior.
- Cells of a low loading of 0.6 mAh/cm<sup>2</sup> and Super P cycle without the erratic effect of a gas.
- More porous separators result in more erratic cell behavior.
- Two theories:
  - 1. Products from the anode oxidize in the cathode to form gas (thicker electrodes = more surface area for CO<sub>2</sub> production from oxalate, separator limits oxalate crossover from anode).
  - 2. The gas is formed on the anode by some product produced in the cathode (thicker electrode results in more soluble product formed).
- Gas sampling may help sort this out.