

# High Energy Lithium Batteries for PHEV Applications

*Subramanian Venkatachalam*  
*Envia Systems*

*DOE Vehicle Technologies Program Annual Merit Review*  
*Washington D.C.*  
*June 16–20, 2014*

**Project ID: ES211**

This presentation does not contain any proprietary, confidential, or otherwise restricted information

# Program Overview

---

## Time line

Start Date: Oct. 2013  
End Date: Sept. 2015  
Status: 25% Completed

## Barriers

- Meeting PHEV power specifications
- Loss of power with cycling
- Cycle and Calendar life

## Budget

Total Project Funding  
\$3.79 M  
DOE: 80%  
Cost Share: 20%

## Partners

- Lawrence Berkeley National Laboratory (LBNL)
- General Motors (GM)
- Oak Ridge National Laboratory (ORNL)



Project Lead – Envia Systems



# Project Objectives - Relevance

## Goals

Develop a high capacity cathode, Si-C based anode and integrate them and build high capacity (0.25-40Ah) pouch cells that exceed the ABR minimum target goals for PHEVs

## Relevance

- High DC-Resistance from HCMR™ Li-rich cathodes reduce the power and usable energy of the cell
- Growth in DC-Resistance with cycling reduce the life of the cell



## Project Tasks

- Material development
- Nanocoating engineering
- Atomistic and cell-level modeling
- Material scale-up
- Large cell development
- Large cell testing

## Cell Targets

Characteristics	Unit	PHEV40
Specific Discharge Pulse Power	W/kg	800
Discharge Pulse Power Density	W/L	1600
Specific Regen Pulse Power	W/kg	430
Regen Pulse Power Density	W/L	860
Recharge Rate	NA	C/3
Specific Energy	Wh/kg	200
Energy Density	Wh/L	400
Calendar Life	Years	10+
Cycle Life (at 30° C with C/3 Charge and 1C Discharge rates)	Cycles	5000
Operating Temperature Range	°C	-30 to +52

# HCMR™ Cathode Layered-Layered Structure



Envia has licensed Lithium-rich Layered-Layered  $\text{Li}_2\text{MnO}_3 \cdot \text{LiMO}_2$  composite patents from Argonne National Laboratory

Envia has developed HCMR™ (**H**igh **C**apacity **M**anganese **R**ich) cathodes based on layered-layered composite structures

## Key benefits:

- High Capacity
- Low Cost
- High safety

## Key issues:

- High DC-Resistance
- Voltage fade upon cycling
- Poor durability

## During the First Charge:

(1)  $\text{LiMO}_2 \rightarrow \text{Li}_{1-x}\text{MO}_2 + x\text{Li}^+ + xe^-$  where M = Ni, Co oxidation occurs  $\sim 3.7$  V

*(Classical reaction)*

(2)  $\text{Li}_2\text{MnO}_3 \rightarrow \text{MnO}_2 + 2\text{Li}^+ + 2e^- + 1/2\text{O}_2$  which is irreversible and is limited only to 1<sup>st</sup> charge

*(Typical of HCMR™)*

## During the Discharge:

(3)  $\text{Li}_{1-x}\text{MO}_2 + x\text{Li}^+ + xe^- \rightarrow \text{LiMO}_2$

(4)  $\text{Li}^+ + \text{MnO}_2 + e^- \rightarrow \text{LiMnO}_2$  (Li insertion into  $\text{MnO}_2$ )

# HCMR™ Cathode: Development Status

HEV, PHEV & EVs have different battery requirements ranging from power characteristics to cycle life. Envia solves the problem at the materials level by tailoring the cathode for each application.

## Morphology:



- Particle size, shape, distribution, tap density & porosity

## Composition:

- Ni, Co, Mn ratio, &  $\text{Li}_2\text{MnO}_3$  content
- Dopants concentration

## Nanocoating:

- Chemistry: fluorine, oxide, etc.
- Thickness & uniformity



HCMR™ Type	C/10 Capacity Range mAh/g (4.6V-2.0V)	Status
XP	200 ~ 220	Commercialization
XE	225 ~ 240	R & D
XLE	240 ~ 280	R&D



- In the ABR program, Envia is currently using HCMR™ – XLE cathode
- Detailed cathode specifications are shared with the partners

# PHEV Cell with HCMR™ XP Cathode



107 Wh, 27 Ah Cell  
180 Wh/Kg at 1C  
with graphite anode



HCMR™ XP cells  
show no Voltage Fade




# HCMR™ XLE Cathode – Electrochemical Chemical Performance



- Baseline HCMR™ cathodes shipped to all program partners
- Nano-coating increases specific capacity (~15mAh/g) showing good capacity retention after 50 cycles at C/3
- Pristine material shows ~30mV higher voltage than the nanocoated material at the 1<sup>st</sup> C/3 cycle, however, at the 50<sup>th</sup> cycles both materials show similar average voltage
- Nanocoted cathode has lower voltage fade about 2.8% in a half cell. In a full cell the average voltage stabilizes to 2-3% fade after 150 cycles

# DC-R Improvement by Carbon Coating







# DC-R Impact on Usable Energy and Power

Amount of  $\text{Li}_2\text{MnO}_3$  in HCMR™ cathode materials determine the usable power and energy of the cell

*An increase in DC-R translates to a significant loss of power*

**Discharge DC-R test:**

10 sec, 1C discharge pulse from single-layer pouch-cells



- HCMR™ XLE cathodes show a sharp increase in DC-R starting at 50% SOC which translates to a significant drop in power and lower usable energy
- On the contrary, HCMR™ XP cathodes show a flat DC-R profile from 90% to ~20% SOC translating to higher power and greater usable energy


# DC-R– Models and Approaches for Improvement

## Root cause

## Development Areas

## Team


### Ionic conductivity



- Composition engineering of  $\text{Li}_2\text{MnO}_3$  ----->
- Dopant engineering ----->
- Reduction of particle size (morphology engineering) ----->
- Reduction of  $\text{O}_2$  defects during formation ----->

- Envia
- Envia/LBNL
- Envia
- LBNL/Envia


### Electronic conductivity



- Carbon coatings ----->
- Dopant engineering ----->
- Conducting polymer coatings ----->

- Envia/GM
- Envia/LBNL
- LBNL



### Charge transfer resistance



- LiPON nanocoating optimization (ionic) ----->
- Nanocoating optimization (electronic) ----->

- ORNL
- LBNL/GM/Envia

# Project Development Roadmap











**GOAL:** Develop a **high capacity cathode** and a **Si-C based anode** in order to build high capacity (0.25-40Ah) pouch cells that **exceed the ABR target** goals for PHEV applications.

**CELL INTEGRATION (Envia) & TESTING (All)**



High capacity cells to meet PHEV ABR cell targets



# Nanocoating LiPON via Physical Vapor Deposition



1. Secondary cathode particle aggregates appear to have similar morphology as uncoated or pristine cathode.
2. Shows nitrogen and phosphorus signal indicating homogenous coating
3. No attrition or degradation from grinding powders during deposition



## LiPON

- Stable to 5.5V
- Stable against Li
- Stable in liquid electrolyte
- Grown by vapor deposition in N<sub>2</sub> plasma



Increase in N content with deposition time

# LiPON Coated HCMR™ Materials










- LiPON-coated cathodes show ~50mV higher average voltage than uncoated cathodes after 50 cycles at C/3
- LiPON-coated materials show ~5-10mAh/g higher capacity than uncoated cathodes
- Voltage retention is improved from ~96% (uncoated) to ~97% (LiPON-coated) by LiPON deposition, specially for low deposition times
- Optimal LiPON thickness will be applied to the HCMR™-XLE2 to improve DC-R and high voltage durability (cycle life and calendar life)

*Tested in half cell 4.6V to 2.0V*




# Nanocoating of HCMR™ Materials via ALD Process


**Objectives:** (1) Explore different ALD nanocoatings -  $\text{Al}_2\text{O}_3$ ,  $\text{AlF}_3$ ,  $\text{AlN}$ ,  $\text{ZnO}$ ,  $\text{TiN}$  etc. (2) Optimize the best ALD conditions to get uniform nanocoatings without compromising capacity (3) Investigate the effects of ALD-coated materials on the DC-R of HCMR™ cathode materials



Pristine powder





$\text{AlF}_3$  coated



$\text{Al}_2\text{O}_3$  coated

$\text{AlF}_3$  coatings with a thickness ~10nm are uniformly deposited on the surface of the HCMR™ particles

# ALD Coated HCMR™ Materials



- ALD coated cathodes show capacities similar to pristine cathodes
- ALD coated cathodes improve capacity retention, absolute average voltage and average voltage retention (~1%) when compared to the pristine cathodes
- Optimized ALD nanocoating will be applied to the HCMR™- XLE2 (Envia nanocoated) to improve DC-R and high voltage durability (cycle life and calendar life)

Tested in half cell 4.6V to 2.0V


# Material Challenges and Diagnostic Tools

## Material Challenges

- DC-R
- DC-R growth with cycling
- Capacity fade
- Possible side reactions
- Possible structural transformation

## Full suite of tools

- EIS (Deeper insight in DC-R)
- HPPC (Standard test of DC-R)
- SEM/TEM (Morphology changes)
- EDX (Elemental analysis)
- XRD (Bulk structural changes)
- FT-IR (Chemical bonding changes)
- Raman (Chemical bonding changes)
- Model system (Carbon and binder free)



**Goal: Correlate electrochemical changes to their physical location in the cell to determine cause of these phenomena**




# Characterization Approach

## Laminate Cathode Electrode

- Cathode powder is laminated & calendared with additives (binder and carbons) into an Al current collector
- Testing in coin cell setup

### Advantages:

- Approach reflects actual cell application
- Testing matches DOE standards
- HPPC Testing




## Carbon and Binder Free Electrode

- Pressing pure 100% cathode powder on Al foil
- Ideal (Model) system
- Testing in coin cell setup


### Advantages:

- Signal is only from active cathode material
- Easier for characterizing degradation mechanisms




# HPPC – Laminate vs. Binder/Carbon Free Electrode

## Laminate Cathode Electrode



## Carbon and Binder Free Electrode




Source: LBNL




- DC-R **drops** with cycling < 30% SOC
- DC-R **rises** with cycling 30% to 90% SOC
- Voltage Fade < 70% SOC

# Impedance for Insight into DC-R at 40% SOC

## Laminate Cathode Electrode



## Carbon and Binder Free Electrode




Source: LBNL

- Cycling increases low frequency semicircle
- DC-R growth because of slow time constant process (Slower than typical charge transfer process)

# Theoretical Modeling – DC-R and Phase Change

- ✓ Stable intermediate states as a function of SOC (while keeping the layered structure) were predicted




## □ At each stable intermediate state,

- Energy barrier calculation for Li hopping to a nearby site: **Li ionic conductivity**
- Density of states calculation to get the band gap: **Electronic conductivity**

## ✓ Phase Transformation mechanism was revealed

- Mn-migration to the Li-layer, occurring at high charge (instantaneous at  $x < 0.5$ , sluggish at  $0.5 < x < 1$ ), is a key factor resulting the phase transformation to spinel-like structures




## □ How to prevent it?


In BATT program, effect of doping on the voltage fade has been explored. In the ABR project we are looking at stabilizing the structure via doping to eliminate the DC-R growth with respect to cycling

- Partially dope for Li to decrease the tendency for Mn migration
- Partially dope for Mn and increase the Mn-migration barriers


# Si-C Anode Development




- Envia has developed an anode powder synthesis process using low cost precursors like  $\text{SiO}_x$  and graphite
- Composition is proprietary ( $\text{Si-SiO}_x\text{-Graphene}$ ) and patents have been filed
- Process is cheap, scalable and available in kg quantities



TEM/SEM analysis of  $\text{Si-SiO}_x\text{-graphite}$  anodes:





*Embedded  $\text{SiO}_x$  and Si particles between graphene sheets enhances mechanical stability and resistance against pulverization due to the large Si volume expansion explaining the improved cycle life*



Envia's anode material will be paired with LBNL's conductive binder to enable long cycle and calendar life meeting ABR PHEV goals

Source: LBNL

# ABR Baseline Cell



- 930mAh capacity ABR baseline cells have been assembled and electrochemical performance (capacity & HPPC) is being tested and validated
- 12 ABR baseline cells were shipped to INL in April 2014 and testing protocols have been finalized
- DC-R measurements for the HCMR™/Si-C baseline cells show similar on-set as the Graphite cells
- Energy and power density evaluations, as well as, cycle life and calendar life are underway



# Summary and Future Work

---

## Summary:

- Conducting carbon coatings on cathode have reduced the DC-Resistance
- LiPON coatings on cathode have improved average voltage without compromising specific capacity
- ALD coatings on cathode have improved capacity retention, absolute average voltage and average voltage retention
- Phase transition mechanisms have been revealed by Atomistic modeling suggesting Mn migration to the Li layer

## Future Work:

- Understand the root cause of DC-R and DC-R growth in HCMR™ cathodes using atomistic modeling and diagnostic tools
- Develop a cathode with low DC-R by optimizing the composition, dopants, nanocoating and synthesis conditions
- For LiPON coated HCMR™ materials (i) structural investigations using neutron diffraction & aberration corrected electron microscopy and (ii) metal ion dissolution and oxygen loss will be studied
- Taylor unique conducting binders to improve the cycle life of Si-C based anodes
- Optimize the integration of HCMR™ cathodes and Si-C anodes in a PHEV cell

# Acknowledgements

---

- Pedro Hernandez
- Shabab Amiruddin
- Bing Li
- Charan Masarapu
- Herman Lopez
- Sujeet Kumar
- Michael Sinkula
- Jim Buckley
- Envia Technical Team



- Bob Powell
- Xingcheng Xiao
- Mei Cai
- K. Raghunathan



- Robert Kostecki
- Vincent Battaglia
- Guoying Chen
- Gao Liu
- Kristin Persson
- Daniel Membreno
- Lydia Terborg
- Eunseok Lee
- Alpesh K. Shukla



- Jagjit Nanda
- Nancy Dudley
- Gabrielle Veith








---

# Technical Back up Slides




# Baseline HCMR™-XLE Cathode Materials

## HCMR™ – XLE #1 (Uncoated)



Measurement	Value
Primary Particle (nm)	201±26
D50 (μm)	8.44
FWHM (μm)	8.18
BET (m <sup>2</sup> /g)	1.44
Tap Density (g/cc)	1.68
pH (Powder)	10.74
1st C/10 Charge (mAh/g)	289
1st C/10 Discharge (mAh/g)	225
Average Voltage at C/10 (V)	3.73


## HCMR™ – XLE #2 (Envia Nanocoated)




Measurement	Value
Primary Particle (nm)	217±17
D50 (μm)	8.27
FWHM (μm)	8.11
BET (m <sup>2</sup> /g)	2.60
Tap Density (g/cc)	1.65
pH (Powder)	10.80
1st C/10 Charge (mAh/g)	284
1st C/10 Discharge (mAh/g)	238
Average Voltage at C/10 (V)	3.69

# HCMR™ XP vs. XLE - dQ/dV Analysis

HCMR™-XLE cathode material shows Mn activity upon repeated cycling



HCMR-XP cathode material showing no Mn activity with cycling



Data from full cell: HCMR™-XP/XLE vs Graphite

# DCR Measurement Protocol

