

Next Generation SCR-Dosing System Investigation

Abhi Karkamkar and Chinmay
Deshmane
Institute for Integrated Catalysis
Pacific Northwest National Laboratory

USCAR POC

Yong Miao
General Motors

Zafar Shaikh
Ford Motors

Mike Zammit
Chrysler

Program Managers: **Ken Howden**

**The work was funded by the U.S.
Department of Energy (DOE) Office
of Vehicle Technologies.**

June 9, 2016

**This presentation does not contain
any proprietary, confidential, or
otherwise restricted information.**

Timeline

- Start – Oct 2014
- End – Sept 18

Budget

- Matched 80/20 by USCAR as per CRADA agreement
- DOE funding for FY16: \$200K;

Barriers


Addressed in next slide

Partners

- Pacific Northwest National Laboratory
- USCAR

- Selective Catalytic Removal of NO_x:
$$4 \text{ NO} + 4 \text{ NH}_3 + \text{O}_2 \rightarrow 6 \text{ N}_2 + 6 \text{ H}_2\text{O}$$
- SCR makes engines more efficient
- NO_x reduction systems (SCR) will require **improved ammonia storage and low temperature delivery.**
- Needed for diesel and lean-burn engines
- Challenge: Safe and efficient ammonia storage and delivery
 - Urea solution (DEFBlue or Adblue®) [Urea+ ~70% water] mitigates most issues
- New materials as needed to solve issues with aqueous urea
- Compact NH₃ storage coupled with long driving range will help minimize fuel consumption




NOx tail-pipe emission and USCAR FTP cycle



	USCAR FTP cycle
Total NH3	4.8 g
Avg. mass flow	3.1 mg/s
Peal flow	22.6 mg/s
Cycle length	1399 sec

Opportunity: Explore fuel economy improvement enabled by low-temperature dosing of ammonia gas.

Item	Unit	20 °C	-7 °C	-15 °C
Start time	sec	<90	<123	<152
Total energy requirement	kJ	64	98	107
Peak power requirement	kW	0.2/0.3	0.2/0.3	0.2/0.3



Direct NH_3 -dosing enables good SCR performance during urban driving without deposit risk.

* NH_3 -SCR efficiency: W. Tang et al. BASF, DOE-DEER conference, October 4th 2011, p.3

- NO_x reduction under all conditions

- Low/medium engine load; low ambient temperature

- Works when the SCR catalyst is active

- Low impact on fuel economy

- No need to inject extra fuel for exhaust temperature management

- Easy & flexible exhaust interface


- Simple interface & no injector

- No risk of deposits


- Close-coupled gas/gas mixing possible

- No shelf life issues for NO_x reductant

- No degradation or freezing; unlimited shelf life



- A flexible and compact exhaust system



- Monthly updates and teleconference with USCAR PI
- Quarterly teleconference with USCAR SCR team
- Bi-annual F2F meeting with USCAR SCR team

Goals and Objectives

- Develop alternative ammonia carrier materials for low temperature NH_3 dosing system
- 32.5 wt% aqueous Urea contains 17wt% NH_3 (gravimetric) and 200 kg/m^3 (volumetric): Any proposed materials should exceed these targets.
- Help develop the next generation SCR dosing system for improved low-temperature performance
- Convenient handling and distribution of ammonia carriers, and reduced overall system volume, weight, and cost



FEV solid SCR system:
Ammonium carbamate



Liquid urea (DEF)



- Project needs to consider non-chlorine materials that will not produce hydrogen chloride (HCl)
- Expressed a consideration that conference calls every two or three months to be very low collaboration, and suggested it is an industrial's dream.
- Downgrading carbamate as a urea replacement, because it yields CO₂ as a decomposition product, is not appropriate





Figure 4-19 Thermally Stable Ultra Low-Temperature Oxidation Catalysts Abhijeet Karkamkar (Pacific Northwest National Laboratory) - Advanced Combustion Engines

- HCl: We quantified HCl, developed pathways to mitigate HCl
- Limited communications: We have increased communication with USCAR to address this comment
- Down-selection criterion: Deposition of ammonium carbamate was identified by USCAR as a serious issue

- Evaluate existing materials based on USCAR recommendations
- Synthesize new materials and composites to improve on existing materials

Develop testing protocol to:

- Determine ammonia storage capacity: wt.%/vol. %
- Determine ammonia release: temp, rate, energy requirement
- Solid material volume change during charge/discharge
- Stability and Safety: volatility under storage & handling conditions extended temp.
- Utilize expertise and state-of-the-art characterization and testing facilities at PNNL to address structure/function and performance
 - XRD, NMR, NH_3 TPD, DSC-TGA with MS
 - Time resolved FTIR studies for kinetics
 - Calorimetric studies for thermodynamics
 - Volumetric gas analyzer for vapor pressure studies




DEFBlue™

- 30% Urea +70% Water
- 200 kg NH_3/m^3
- 17 wt% NH_3 (on composition basis)
- Convenient
- Freezing
- Solid deposits
- Lowering of exhaust temp due to water

$\text{MgCl}_2 \cdot 6\text{NH}_3$

- ~ 600 kg NH_3/m^3
- 50 wt% NH_3 (on composition basis)
- Multi-step decomposition
- No complex chemistry
- Easily available MgCl_2 (10% of sea salt) and NH_3
- Freezing a non-issue


We will use DEF to benchmark our materials




- Existing materials have limitations
- New materials and composites are needed to address these limitations
- Synthesis of Eutectics and double salts
 - Ammonia Absorption into Alkaline Earth Metal Halide Mixtures as an Ammonia Storage Material [Chun Yi Liu and Ken-ichi Aika Ind. Eng. Chem. Res. 2004, 43, 7484-7491](#)
- Development of new additives to enhance kinetics, thermodynamics and stability
 - Ammonia Adsorption on Ion Exchanged Y-zeolites as Ammonia Storage Material [Chun Yi Liu and Ken-ichi Aika Journal of the Japan Petroleum Institute, 46, \(5\), 301-307 \(2003\)](#)
- Theory can help identify potential systems
 - Designing mixed metal halide amines for ammonia storage using density functional theory and genetic algorithms [Peter Bjerre Jensen, Steen Lysgaard, Ulrich J. Quaade and Tejs Vegge, Phys.Chem.Chem.Phys., 2014, 16, 19732—19740](#)

- Completed the large scale (5-25 g scale) loading of NH_3 on anhydrous .
- Completed the synthesis and evaluation of 10% NiCl_2 on MgCl_2 and 10% CoCl_2 on MgCl_2 via aqueous solution method.
- Characterize and Study the NH_3 uptake capacity of the Eutectic salts.
- Quantify and Minimize volume expansion upon NH_3 uptake
- Evaluated ammonia storage capacity of oxide based materials
- Nano-encapsulation studies of MgCl_2 in high surface area and porous supports
- Identify and quantify and mitigate HCl being released
- Underway
 - Effect of CO_2 on material performance
 - Kinetics of NH_3 release from composites
 - Effect of NO_x , H_2O , CO on material performance

Effect of NH_3 on pellets



- Pellet- MgCl_2
- Before NH_3 adsorption
- Wt.=0.205 g
- Dia.= 9 mm
- Height = 0.05 mm




- Pellet- MgCl_2
- After NH_3 adsorption
- Wt.=0.4 g

- Loses engineered form ✗
- Only NH_3 released ✓
- > 50 wt% gravimetric capacity ✓
- Reversible ✓

New additives are needed to retain engineered form

Volume Expansion Measurements




MgCl₂

CaCl₂

SrCl₂

LiCl



MnCl₂

CoCl₂

NiCl₂

CuCl₂

Material	Weight (g)	Volume (cc)	Density (g/cc)	Volume change (%)
MgCl ₂	0.200	0.22	0.91	-
Mg(NH ₃) ₆ Cl ₂	0.3622	0.80	0.45	264
CaCl ₂	0.202	0.22	0.92	-
Ca(NH ₃) ₈ Cl ₂	0.4212	1.00	0.42	354
SrCl ₂	0.203	0.22	0.92	-
Sr(NH ₃) ₈ Cl ₂	0.3697	0.80	0.46	264
LiCl	0.200	0.18	1.11	-
Li(NH ₃) _x Cl	0.3212	0.40	0.80	122

Material	Weight (g)	Volume (cc)	Density (g/cc)	Volume change (%)
MnCl ₂	0.202	0.17	1.19	-
Mn(NH ₃) ₆ Cl ₂	0.346	0.80	0.43	370
CoCl ₂	0.205	0.20	1.02	-
Co(NH ₃) ₆ Cl ₂	0.355	0.80	0.44	300
NiCl ₂	0.200	0.20	1.00	-
Ni(NH ₃) _x Cl ₂	0.314	0.30	1.05	50
CuCl ₂	0.200	0.11	1.82	-
Cu(NH ₃) _x Cl ₂	0.322	0.45	0.72	310

Large volume expansion upon addition of NH₃ is a big problem

Transition metal ammine complexes



MnCl_2





CoCl_2



NiCl_2

Material	Weight (g)	Volume (cc)	Density (g/cc)
MnCl_2	0.202	0.17	1.19
$\text{Mn}(\text{NH}_3)_6\text{Cl}_2$	0.346	0.80	0.43
CoCl_2	0.205	0.20	1.02
$\text{Co}(\text{NH}_3)_6\text{Cl}_2$	0.355	0.80	0.44
NiCl_2	0.200	0.20	1.00
$\text{Ni}(\text{NH}_3)_x\text{Cl}_2$	0.314	0.30	1.05

Transition metal ammines provide a pathway to tune acidity
hence tune thermodynamics



• Weight Loss = 42.5%


Pacific Northwest
NATIONAL LABORATORY

Proudly Operated by Battelle Since 1965

• $\text{Co}(\text{NH}_3)_6\text{Cl}_2$
Institute for
INTEGRATED
CATALYSIS

High Surface Area Supports: MCM-41


Vehicle Technologies Office



1:1 2:1 3:1



1:1 2:1 3:1



Material	Weight (g)	Volume (cc)	Density (g/cc)	Volume Change (%)
MgCl ₂ :MCM41 (1:1)	0.207	0.42	0.49	-
Mg(NH ₃) ₆ Cl ₂ :MCM41 (1:1)	0.265	0.49	0.54	16.7
MgCl ₂ :MCM41 (2:1)	0.200	0.34	0.59	-
Mg(NH ₃) ₆ Cl ₂ :MCM41 (2:1)	0.28	0.44	0.64	29.4
MgCl ₂ :MCM41 (3:1)	0.15	0.25	0.60	-
Mg(NH ₃) ₆ Cl ₂ :MCM41 (3:1)	0.22	0.33	0.67	32.0


- ❑ MgCl₂ was impregnated on the high surface area MCM-41.
- ❑ Higher amounts of MgCl₂ loading does not improve the NH₃ capacity.
- ❑ **MCM41 support provides relatively better mechanical stability.**

Activated Carbon as nano-encapsulation material

Vehicle Technologies Office

Material	Surface Area (m ² /g)	Pore Volume (cc/g)
Activated Carbon	450.1	1.31
AC:MgCl ₂ (1:1)	107.7	0.35
AC:MgCl ₂ (1:2)	81	0.33
AC:MgCl ₂ (1:3)	97.3	0.38
AC-KB-B100	1321	1.38
MgCl ₂ :AC (1:1)	140.7	0.20
MgCl ₂ :AC (2:1)	81.5	0.14
MgCl ₂ :AC (3:1)	164.5	0.32

Developed an optimized method of incorporation of MgCl₂ in porous, high surface area materials



Material	Weight (g)	Volume (cc)	Density (g/cc)
AC:MgCl ₂ 1:1	0.104	0.18	0.58
AC:Mg(NH ₃) ₆ Cl ₂ 1:1	0.142	0.23	0.62
AC:MgCl ₂ 1:2	0.104	0.17	0.61
AC:Mg(NH ₃) ₆ Cl ₂ 1:2	0.151	0.25	0.60

Pacific Northwest
NATIONAL LABORATORY

Institute for
INTEGRATED
CATALYSIS

Proudly Operated by Battelle Since 1965

High Surface Area Supports: Activated Carbon

Vehicle Technologies Office

Material	Surface Area (m ² /g)	Pore Volume (cc/g)
Activated Carbon	450.1	1.31
AC:MgCl ₂ (1:1)	107.7	0.35
AC:MgCl ₂ (1:2)	81	0.33
AC:MgCl ₂ (1:3)	97.3	0.38

Material	Weight (g)	Volume (cc)	Density (g/cc)	Volume Change (%)
AC:MgCl ₂ 1:1	0.15	0.38	0.39	-
AC:Mg(NH ₃) ₆ Cl ₂ 1:1	0.19	0.49	0.39	28.9
AC:MgCl ₂ 1:2	0.15	0.38	0.39	-
AC:Mg(NH ₃) ₆ Cl ₂ 1:2	0.20	0.51	0.39	34.2
AC:MgCl ₂ 1:3	0.15	0.38	0.39	-
AC:Mg(NH ₃) ₆ Cl ₂ 1:3	0.22	0.58	0.38	52.6



1:1

2:1

3:1


Volume expansion minimized with minimal loss of NH₃ storage capacity

High Surface Area Supports: KBB-100

Vehicle Technologies Office

Material	Surface Area (m ² /g)	Pore Volume (cc/g)
KBB-100	1321	1.38
MgCl ₂ :KBB100 (50%)	140.7	0.20
MgCl ₂ :KBB100 (70%)	81.5	0.14
MgCl ₂ :KBB100 (100%)	164.5	0.32

Material	Weight (g)	Volume (cc)	Density (g/cc)	Volume Change (%)
MgCl ₂ -KBB100 (50%)	0.20	0.50	0.40	-
Mg(NH ₃) ₆ Cl ₂ -KBB100 (50%)	0.24	0.71	0.34	42.0
MgCl ₂ -KBB100 (70%)	0.20	0.50	0.40	-
Mg(NH ₃) ₆ Cl ₂ -KBB100 (70%)	0.27	0.72	0.37	44.0
MgCl ₂ -KBB100 (100%)	0.20	0.50	0.40	-
Mg(NH ₃) ₆ Cl ₂ -KBB100 (100%)	0.30	0.80	0.37	60.0



1:1








2:1

3:1

Volume expansion minimized with minimal loss of NH₃ storage capacity


NH₃ Storage on Double Salts

Vehicle Technologies Office



The Mechanical stability of the double salt is better in comparison to MgCl_2 .
The NH_3 capacity of these double salts is comparable to Magnesium Ammine Chloride.

High Temperature Powder XRD Patterns: Mg-Ammine Complex




- ❑ The powder XRD pattern reveals that we have a mixture of Mg-ammine complex and ammonium chloride.
- ❑ The decomposition of the ammine complex starts at room temperature due to the release of physisorbed ammonia.
- ❑ As the temperature is increased we observe complete release of ammonia and after 300°C we are left with amorphous material..

Impurity Quantification and Mitigation: HCl Measurements

Vehicle Technologies Office

Material (Quantity, g)	Time (hr)	Temperature * (°C)	Amount of HCl (ppm)
MgCl ₂	3	400	~550
MgCl ₂	24	400	>600
MgCl ₂	24	400	>600
MgCl ₂	100	400	>600
MgCl ₂	24	400	~580
Mg(NH ₃) ₆ Cl ₂	24	250	20
MgCl ₂ :AC (2:1)	24	600	>600
Mg(NH ₃) ₆ Cl ₂ :AC (1:1)	24	400	No HCl
Mg(NH ₃) ₆ Cl ₂ :AC (1:1)	24	400	No HCl
Mg(NH ₃) ₆ Cl ₂ :AC (2:1)	24	250	No HCl
Mg(NH ₃) ₆ Cl ₂ :KBB (3:1)	24	250	No HCl



**Successful mitigation of HCl by
development of composites**

- Completed the synthesis and evaluation of several Eutectic and double salts.
- Characterize and Study the NH_3 uptake capacity of the Eutectic salts.
- Quantified and Minimized volume expansion upon NH_3 uptake (from 300% to 30%)
- Evaluated ammonia storage capacity of oxide based materials
- Nano-encapsulation studies of MgCl_2 in high surface area and porous supports for mitigation of volume expansion and HCl formation
- Identify, quantify and mitigate impurities. (HCl >600 ppm to <1 ppm)
- Underway
 - Effect of CO_2 on material performance
 - Kinetics of NH_3 release from composites
 - Effect of NO_x , H_2O , CO on material performance

1. **Composites, Double Salts and Eutectics:** Studies will be especially focused on mechanisms/limitations for low temperature performance. Some specific questions:

- How will additives alter capacity?
- Gravimetric and volumetric
- How will additives impact thermodynamics and kinetics?
Energy requirements and HCl
- How additives help retain engineered form?



2. **NH₃ Adsorption Materials:**

- Finish stability testing of existing materials
- Pathways to mitigate HCl (Oxide materials)

3. **Material Cost analysis**