












ACTIVE PARTICLE STUDIES

Silicon Deep Dive



20

30

BARIS KEY

U.S. DEPARTMENT OF ENERGY VEHICLE TECHNOLOGIES OFFICE 2018 ANNUAL MERIT REVIEW **Project ID BAT351**

⁷Li shift in ppm

10

This presentation does not contain any proprietary, confidential, or otherwise restricted information

OVERVIEW

Timeline

- Start: October 1, 2015
 - Reset: October 1, 2017
- End: September 30, 2020
- Percent Complete: 55%

Budget

- Total project funding:
 - FY18 \$3600K
- Presentations: BAT349, BAT350, BAT351, BAT352, and BAT353

Barriers

- Development of PHEV and EV batteries that meet or exceed DOE and USABC goals
 - Cost, Performance, and Safety

Partners

- Sandia National Laboratories
- Pacific Northwest National Laboratory
- Oak Ridge National Laboratory
- National Renewable Energy Laboratory
- Lawrence Berkeley National Laboratory
- Argonne National Laboratory













RELEVANCE

- Objectives: Stabilize the SEI Stabilize the electrode
- Overall focus on insights into and advancement of siliconbased materials, electrodes, and cells.
- Advancements verified on life and performance of full cells using standardized testing protocols.

Program Directly Addresses Cost and Performance Barriers and Quantifies Safety

- Elemental silicon can theoretically store >3500 mAh/g.
- Battery Performance and Cost (BatPaC) Model indicates a silicon based anode coupled with a high capacity cathode lithium-ion technology presents a pathway to less than \$125/kWh_{use}
- BatPaC also used to relate pack level benefits to program goals.
- Benefits reach diminishing returns after **1000 mAh/cm³** (electrode basis) for both cost and energy density.
- Silicon with <75 wt% graphite can achieve target.













MILESTONES AND ACTIVITIES

- The program has more than twenty milestones related to the broad range of integrated activities listed below.
- Generally, milestones are either completed or on schedule.
- Extensive electrochemical and analytical diagnostic studies.
- Facilities supporting program through a wide range of studies.
 - Battery Abuse Testing Laboratory (BATLab); Battery Manufacturing Facility (BMF); Cell Analysis, Modeling, and Prototyping (CAMP) Facility; Materials Engineering Research Facility (MERF); Post-Test Facility (PTF)
- Development and testing of coatings and additives designed to modify and stabilize the interface.
- Develop and analyze polymer binders designed to accommodate volume changes, increase conductivity, and improve adherence.
- Active material development.
 - Explore lithium inventory strategies.
 - Study alternative high-energy metals.

For reviewers, a detailed list of the milestones and progress is supplied in the reviewers only slides.













APPROACH

Use local structure probes (NMR, FTIR, Raman) along with diffraction to study commercial silicon powders and model compound reactions

- Probe amorphous and crystalline components of commercial silicon powders and their structure activity relationships
 - Effects of processing
 - Heat treatments pre-electrochemistry
 - Correlating changes in surface terminations
- Probe major reactions that may cause coulombic inefficiencies and selfdischarge, study the best representative model compounds of Li-Si system:
 - Li₇Si₃ ← current focus
 - $\text{Li}_{13}\text{Si}_4 + \text{Li}_{15+x}\text{Si}_4$: future work
 - Study the reactivity of lithium silicides, Li_xSi_y, with different electrolyte components and binders to understand the reaction mechanism that Sibased anodes may undergo.














PROBING BULK AND SURFACE CHEMISTRY OF **SILICON**


ACS Applied Materials & Interfaces, 9 (38), 32727-32736

Quantification of amorphous SiO₂ content with NMR

See BAT352

²⁹Si direct observe MAS NMR at 7.04T













PROBING BULK AND SURFACE CHEMISTRY OF

SILICON

Bulk and surface structure effects of processing conditions






Water processed commercial Si powder amorphous SiO₂ shell thickness increase of 7.5nm captured directly via ²⁹Si NMR

■ The ¹H and ¹H-²9Si cross polarization MAS NMR displays the transition of Si-H, geminal (Q₂), and siloxane (Q₄) sites to silanol sites (Q₃). This likely occurs when water oxidizes the Si-H sites to Q₃ sites

Hays et al., submitted to JPC, 2018
















PROBING BULK AND SURFACE CHEMISTRY OF SILICON

Not all commercial silicon powders are created equal: HydroQuebec vs. Aldrich vs. NanoAmor vs. Paraclete

See BAT349 and 350

- Powders with smaller average particle sizes contain more amorphous SiO₂ content
- Paraclete powder was found to contain a significant amorphous-Si and Si-C/H content when compared to similar particle sized NanoAmor powders.
- An organic coating detected for both Paraclete and NanoAmor powders and none for HydroQuebec powder.
 - The chemistry of the coatings are different for different manufacturers with different functional groups: Generates processing and e-chem differences




Proudly Operated by Battelle Since 1965

APPROACH

Study reactions that may cause coulombic inefficiencies and self-discharge, study the best representative model compounds of Li-Si system: Highly charged silicon anions

- Expose the Li-Si model compounds to:
 - Binders
 - LiPAA (stable)
 - PVDF (unstable)
 - Electrolyte components
 - EC
 - EMC
 - FEC
 - Glymes
 - Other solvents
















⁷Li MAS NMR and XRD of Li₇Si₃: Stability in zirconia rotor

Li₇Si₃ Si-Si dumbbells

Pristine Li₇Si₃ reacts even with the ZrO₂ high precision ceramic rotor with Li loss as a function of time.


Highlights the reactivity challenges associated with freshly synthesized lithium silicides





Li₇Si₃ REACTIVITY - BINDERS


When binders are physically mixed with Li₇Si₃ in inert conditions (Ar): PVDF binder aliphatic carbons react while no defluorination via LiF formation was observed.


- Li₇Si₃ model compound has been shown to react;
 - Extensively with PVDF
 - ⁷Li NMR suggests significant loss of Li and Formation of diamagnetic Li salts
 - ¹⁹F NMR detects change in binder fluorine groups while no LiF was detected
 - ¹H and ¹³C NMR shows formation of new aliphatic functionalities
 - Minor reaction with LiPAA


























Li₇Si₃ REACTIVITY - BINDERS

Minimal changes observed for the active material in LiPAA case.

- Li₇Si₃ model compound has been shown to react;
 - Extensively with PVDF
 - ⁷Li NMR shows significant loss of Li and formation of diamagnetic Li salts
 - Minor reaction with LiPAA
 - ²⁹Si, ⁷Li NMR and XRD shows slight Li loss and formation of Li₁₂Si₇













Proudly Operated by Battelle Since 1965










RAMAN SPECTRA: THE LI₇SI₃ PHASE AND ITS MIXTURE WITH PVDF AND LIPAA

Mixtures consisting of 70 wt. % Li₇Si₃ powder and 30 wt. % of binder. Delithiation and formation of Si-F bands were detected for PVDF mixture. Minor changes for LiPAA.



Li₇Si₃ + LiPAA 416 40000 Li₇Si₃ + LiPAA Intensity (counts) Li₇Si₃ 30000 LiPAA 432 20000 10000 500 1500 2000 1000 Raman shift (cm⁻¹)

The vibrations of the "Li₇Si₃+PVDF" mixture mainly combine those observed for PVDF and Si-related species. In certain areas however the Li_7Si_3 seems to evolve to the delithiated $\text{Li}_{12}\text{Si}_7$, as the band at 362 cm⁻¹ suggests. In the mixture, the formation of Si-F compounds is also observed at 840 cm⁻¹ ($\text{v}_{\text{a. Si-F}}$).





Pacific Northwest

NATIONAL LABORATORY


Proudly Operated by Battelle Since 1965

In the "Li₇Si₃+LiPAA" mixture, the vibrations of Li₇Si₃ are commonly hidden by the intensity of LiPAA bands making the analysis challenging. Overall only slight changes were detected. Depending on the region: i) no band shifting is observed for Li₇Si₃; ii) Li₇Si₃ becomes amorphous (see a-Si band at ca. 470 cm⁻¹) iii) the presence of some Li₁₂Si₇ (360 and 416 cm⁻¹) was observed.

In-situ ⁷Li MAS NMR of Li₇Si₃+EC



When mixed Li₇Si₃ with solid EC, the main peak shifted by +2.2 ppm When heated up to 325 K, the main peak shifted by +3.9 ppm When cooled back to 298 K, the main peak shifted by +2.6 ppm

















⁷Li MAS NMR of Li₇Si₃ + EMC and XRD (postevaporation of EMC in Ar-glovebox)

When soaked in EMC, the main peak shifted by +1.1 ppm.

Only subtle changes can be observed in XRD after mixing with EMC, increase in Li₁₂Si₇

Minor delithiation and bulk changes observed



















⁷Li and ¹⁹F MAS NMR of Li₇Si₃ + FEC

When soaked in FEC, the main peak shifted by +0.7 ppm. No LiF formation detected.

Passivation in electrochemical setting could be different...

Minor delithiation and bulk changes observed



















⁷Li MAS NMR of Li₇Si₃ + Triglyme and XRD (post evaporation of Triglyme in Ar-glovebox)

When soaked in Triglyme, the main peak shifted only by +0.2 ppm.

Minimal phase changes in XRD.

No changes in bulk and Li content. Results consistent with relative inertness of glymes.


















⁷Li MAS NMR Comparison

Li₇Si₃ + Triglyme leads to the least peak shift and found to be quite inert. EMC and FEC was also remarkably inert against the model compound.

 $Li_7Si_3 + EC$ leads to the most peak shift.

Test with Gen2 electrolyte yields result similar to EC case.
















²⁹Si MAS NMR Comparison

After reaction with EC, the main peak shifted by +12.5 ppm with a new peak formed at 180 ppm.

With Triglyme/EMC/FEC, the peak shifted only by +2.6/+1.9/+0.3 ppm, confirming ⁷Li NMR results.
















Electrochemical Test with a Triglyme based Electrolyte vs. Baseline (1st cycle)

Very few reports in literature on use of glymes for silicon: *Energy Environ. Sci.*, 2016, 9, 3262 – promising results

Much higher initial charge/discharge capacity was observed using a triglyme based electrolyte consistent with a hypothesis of inhibited capacity loss (self-discharge)

















60%wt Si + 40wt% hard C drop-cast electrodes vs. Li

Electrochemical Test with Triglyme Electrolyte Capacities and Efficiencies

Trigiyme leads to fast capacity fading, lower coulombic efficiency and lower initial capacities with FEC. Suggests non-passivation.



















SUMMARY

- An NMR methodology was developed to quantify and study amorphous SiO₂ shells and coatings in commercial silicon powders
 - Effect of heat treatments and electrode processing investigated
 - · Gassing reactions and effects on silicon surfaces and terminations identified
 - Silicates on commercial powders improved performance with annealing
 - Different "coatings" and Si:SiO₂ ratios characterized on commercial sources leading to differences in processing (former) and electrochemical performance (both)
- The reactivity of the Li₇Si₃ with PVDF and LiPAA has been studied:
 - Minimal reaction detected for LiPAA case
 - Significant delithiation detected for PVDF case
 - Li₁₂Si₇ and an amorphous Li-salt formation in the bulk is accompanied with changes in C-H moieties in the binder while some Si-F band formation without any LiF formation was observed
- In-situ MAS NMR results show that Li₇Si₃ model compound react the most with EC, less with FEC/EMC/triglyme. Reactions result in bulk delithiation.
- Using triglyme electrolyte leads to much higher capacity which is consistent with model reactivity work but with lower coulumbic efficiency and poor capacity retention; could be indicative of non-passivating behavior
- Simply adding FEC to triglyme electrolyte does not help to improve the cyclability;
 highlights the need to characterize and understand the new SEI or lack thereof in a new chemistry













FUTURE STUDY

Short term:

- Post electrochemistry characterizations on triglyme cell Li and Si electrodes
- Full-cell tests with triglyme electrolyte
- Li₁₃Si₄ reactivity test with electrolyte components
 - Probe reaction with FEC and formation of LiF at lower voltage model system
- Speciation of organic decomposition products on model compounds from reactivity studies

Long term:

- Work with electrolyte teams to explore opportunities in identifying new electrolyte formulations in both carbonate and non-carbonate chemistries guided by model compound reactivity studies
- Work with SEISta fundamental questions on silicon corrosion/side reactions (tied to model compound reactivity studies) and role and evolution of silicates and lithium silicates (tied to quantification of a-SiO₂)

Any proposed future work is subject to change based on funding levels.













RESPONSES TO PREVIOUS YEAR REVIEWERS' COMMENTS

Last year two poster presentations covered all the project. The two posters were each reviewed by eight reviewers. We thank the reviewers for their thoughtful comments. Selected excerpts are given below.

- Many of the reviewers' comments were generally positive.
 - "applauded the excellent, thorough approach"
 - "very ambitious program to assess advantages, disadvantages and solutions for Si anode materials"
 - "very nice intra-laboratory coordination"
- One reviewer thought we could further enhance the program by bringing in experts in mechanical stresses. We conduct limited mechanical measurements and have relied on literature to establish a stable particle size, but in general we agree more in-depth studies could improve the program.
- One reviewer suggested that our commitment to openness limits our ability to examine proprietary materials. We agree totally and recognize the limitation. However, we consider that the work we are doing is addressing the fundamental issues with silicon materials and will benefit the entire community.













REMAINING CHALLENGES AND BARRIERS

- Several key challenges remain that limit integration of silicon into graphitic negative electrodes, mostly related to the large crystallographic expansion of silicon (>300%) upon lithiation.
 - SEI stability issues, which affect cycling efficiency.
 - Electrode stability issues that include particle isolation, accommodating volume changes, and adherence.

COLLABORATION AND COORDINATION WITH OTHER INSTITUTIONS

- Six National Laboratories have teamed to form this integrated effort focused on gaining insights into and advancement of silicon-based materials, electrodes, and cells.
- This effort has strong interactions with the Silicon Electrolyte Interface Stabilization (SEI-Sta) project (BAT344, BAT345, BAT346, BAT347, and BAT348).
- Paraclete Energy is suppling baseline silicon materials.













CONTRIBUTORS AND ACKNOWLEDGMENT

Research Facilities

- Post-Test Facility (PTF)
- Materials Engineering Research Facility (MERF)
- Cell Analysis, Modeling, and Prototyping (CAMP)
- Battery Manufacturing Facility (BMF)
- Battery Abuse Testing Laboratory (BATLab)

Contributors

- Daniel Abraham
- Eric Allcorn
- Seong Jin An
- Beth Armstrong
- Chunmei Ban
- Javier Bareno
- Ira Bloom
- Anthony Burrell
- Peng-Fei Cao
- Yang-Tse Cheng
- Claus Daniel
- Dennis Dees
- Fulya Dogan Key
- Wesley Dose
- Zhijia Du
- Alison Dunlop
- Trevor Dzwiniel
- Kyle Fenton

- Steve George
- Jinghua Guo
- Binghong Han
- Atetegeb Meazah

Haregewoin

- Kevin Hays
- Bin Hu
- Andrew Jansen
- Gerald Jeka
- Sisi Jiang
- Christopher Johnson
- Kaushik Kalaga
- Baris Key
- Joel Kirner
- Robert Kostecki
- Gregory Krumdick
- Jianlin Li
- Xiaolin Li
- Chen Liao

- Min Ling
- Gao Liu
- Wenquan Lu
- Maria Jose Piernas Muñoz
 Lydia Terborg
- Jagjit Nanda
- Kaigi Nie
- Ganesan Nagasubramanian
 Jack Vaughey
- Christopher Orendorff
- Bryant Polzin
- Krzysztof Pupek
- Marco-Tulio F. Rodrigues
 Koffi Pierre Claver Yao
- Philip Ross
- Rose Ruther
- Niya Sa
- Robert Sacci
- Tomonori Saito
- Yangping Sheng
- Youngho Shin
- Ilya A. Shkrob

- Seoung-Bum Son
- Caleb Stetson
- Robert Tenent
- Wei Tong
- Stephen Trask
- Gabriel Veith
- David Wood
- Yimin Wu
- Taeho Yoon
- Ji-Guang Zhang
- Liang Zhang
- Linghong Zhang
- Lu Zhang
- Zhengcheng Zhang
- Tianyue Zheng

Support for this work from Battery R&D, Office of Vehicle Technologies, DOE-EERE, is gratefully acknowledged – Brian Cunningham, Steven Boyd, and David Howell













TECHNICAL BACKUP SLIDES

[maximum of five]. These back-up technical slides will be available for your presentation and will be included in the web PDF files released to the public.)















INFRARED SPECTRA: THE LI₇SI₃ PHASE AND ITS REACTION WITH PVDF AND LIPAA

Mixtures consisting of 70 wt. % Li₇Si₃ powder and 30 wt. % of the corresponding binder were examined





No IR activity is observed in Li_7Si_3 , as expected. The Li_7Si_3 + PVDF mixture solely shows the signals associated to the binder, although these are extremely attenuated and detailed analysis is challenging.

Similarly to the results with PVDF, the blend of Li₇Si₃ with LiPAA basically reflects the vibrations corresponding to the binder.














RAMAN SPECTRA: THE LI₇SI₃ PHASE

Measurement conditions: 10s, 5% laser power, 20 acc (for each point)

Area analyzed: 80 µm x 80 µm





Almost all the spectra displayed:

- The a-Si scattering band (at 160 cm⁻¹)
- The two characteristic bands of Li₇Si₃ at ca. 397 and 437 cm⁻¹.

In addition, some other vibrations associated with Si are observed (TA mode of a-Si at 300 cm⁻¹).

In some spectra, the presence of c-Si (unreacted) is also seen.











