# Multifunctional, Self-Healing Polyelectrolyte Gels for Long-Cycle-Life, High-Capacity Sulfur Cathodes in Li-S Batteries

Alex K.-Y. Jen and Jihui Yang
Department of Materials Science and Engineering
University of Washington

2018 DOE Vehicle Technologies Office Review Meeting June 20th, 2018



Project ID bat320

This presentation does not contain any proprietary, confidential, or otherwise restricted information

### Overview

### **Timeline**

- Project start date Oct. 2016
- Project end date Sept. 2019
- Percent complete 49%

### **Budget**

- Total project funding
  - DOE share: \$1.25 M
  - Contractor share: \$138,888
- Funding received in FY 2017 \$416,667
- Funding for FY 2018 \$416,667

### **Barriers**

- Cost: Reduce \$/kWh of EV batteries using high-energydensity, low-cost Li-S chemistry
- Performance: Double the energy density of state-of-the-art Li-ion batteries using Li metal anode
- Life: Mitigate capacity loss mechanisms in Li-S cells for improved cycle life

#### **Partners**

- Project Lead: University of Washington
- Interactions/collaborations:
   Pacific Northwest National Lab

### Relevance

 Overall Objective: Develop high-performance Li-S cells, based on self-healing and polysulfide-trapping polyelectrolyte gels containing solvate ionic liquid (SIL). The Li-S battery design will be capable of achieving gravimetric and volumetric energy densities of ≥800 Wh/kg and ≥1000 Wh/L, respectively.

### Objectives this period

- Demonstrate gel electrolytes with ionic conductivity > 1mS/cm
- Demonstrate polymers with tunable self-healing temperature (close to room temperature) and mechanical property
- Design and demonstrate surface modification for mesoporous carbon to achieve improved capacity retention

### Impact


 Li-S batteries has the potential of achieving the DOE goal of \$100/kWh for battery pack usable energy

### Milestones

Date	Milestone or Go/No-Go Decision	Status	
	Go/No-Go Decision		
June 2018	Selection of Gel Structure for Device Optimization	On track.	
Dec 2018	Milestone	On track.	
	Intermediate Cell Degradation Update		
Mar 2019	Milestone		
	Intermediate Cell Performance Update (Practical Cells)	On track.	
Sep 2019	Milestone		
	Optimized Cell Degradation Update	On track.	

# Approach/Strategy

Multifunctional Polyelectrolyte Gels for Long-Cycle-Life, High-Capacity Li-S Batteries



### Approach/Strategy

### Carbon/Sulfur Composite

- Mesoporous carbon provides conductivity and physical containment of Li<sub>2</sub>S<sub>x</sub>
- Platform to add targeted chemical functionality for performance enhancement

### Solvate Ionic Liquid + Polyelectrolyte Gel

- IL electrolyte suppresses Li<sub>2</sub>S<sub>x</sub> dissolution and inhibits Li dendrite growth while providing conductivity similar to organic electrolytes
- Gel creates mechanical toughness without sacrificing much conductivity

### Trapping of Polysulfide Species

 Containment of Li<sub>2</sub>S<sub>x</sub> species *via* physical or chemical interaction eliminates redox shuttle effect and improves capacity retention

### Self-Healing through Reversible Noncovalent Interactions

- Interaction of electron-rich (pyrene or "Py") and electron-poor (naphthalene diimide or "NDI") aromatic groups allows tunable, reversible binding
- Introduction of reversible noncovalent binding induces self-healing, suppressing capacity loss due to mechanical degradation of cathode

### Fabrication of High-Conductivity Ionogels




#	PEGDMA	<u>PyrTFSIMA</u>	<u>TEGMA</u>	Li(G4)TFSI	<u>1,4-diox</u>	<u>σ</u> (10 <sup>-3</sup> S/cm)
1	20%*	0%	0%	80%	0%	0.73
2	20%†	0%	0%	80%	0%	<u>1.05</u>
3	10% <sup>†</sup>	0%	10%	80%	0%	<u>0.92</u>
4	10% <sup>†</sup>	10%	0%	80%	0%	<u>1.07</u>
5	20%†	0%	0%	66.6%	13.3%	<u>2.15</u>

 $^{*}M_{n}=750Da, ^{\dagger}M_{n}=3500Da$ 


- Reliable one-pot fabrication method produces thin ionogel films with remarkably high conductivity at 23° C
- Effect of both polymer and liquid composition on conductivity investigated to inform selection of formula for later cell optimization

**Ionogel Compatibility w/ Li Metal** 




 Ionogel separators allow Li|Li symmetric cells to cycle stably (±0.1mA/cm²) for over 600 hours at low overpotentials


**Self-Healing Material Tunability** 



- depend on ratio of concentration
- Small-molecule dopants adjust ratios without altering polymer, allowing for tunable properties
- Elastic modulus: 63-250MPa



Influence of Temperature on PP Materials



10


Healed diPP-1

diPP-1


PP-1


 Polymer acts as solid-state electrolyte w/ LiTFSI doping, recovers conductivity upon healing


Interaction of Thiol Surface with Li<sub>2</sub>S<sub>x</sub>, Electrolyte




- Diazonium chemistry used to attach phenylthiol groups onto surface of mesoporous carbon host used for sulfur
- XPS of cycled cathodes shows covalent attachment of Li<sub>2</sub>S<sub>x</sub>
- <sup>7</sup>Li NMR shows increased electrolyte presence







### **Enhanced Practical Cell Performance**



- High-loading cathodes (4 mg<sub>S</sub>/cm<sup>2</sup>) fabricated with carbons of varying modifier concentration (as measured by weight loss during TGA)
- Discharge capacity and retention (C/10) increases with thiol loading, demonstrating beneficial effect of modified surface

12

# Responses to Previous Year Reviewers' Comments

This project was not reviewed at last year's AMR.

# Collaboration and Coordination with Other Institutions

- The project is carried out by the Jen and Yang groups at the University of Washington
  - Jen: design and characterization of ionogel electrolytes, design and characterization of self-healing materials, surface modification of mesoporous carbon, electrochemical characterization of concept cells
  - Yang: carbon/sulfur composite characterization, surface modification of mesoporous carbon, design and electrochemical characterization of practical cells
- FY 18 Collaborator Pacific Northwest National Laboratory
  - 7Li NMR
  - Electron microscopy of carbon/sulfur composites

# Remaining Challenges and Barriers

- We must continue to develop and optimize our procedure for curing ionogels in-situ around carbon/sulfur composite particles, effecting a gel cathode as initially proposed.
- The effect of our self-healing polymer system on a functioning sulfur cathode must be demonstrated using cell data.
- Quantitive demonstration of polysulfide trapping by gel functionality must be shown. We are in the final stages of developing a novel, generalized method to determine polysulfide concentration and average chain length in solutions.
- Sulfur/carbon composite design, including surface functionality, must be optimized appropriately for an ionogel electrolyte system.
- The predominant cell degradation mechanisms in gel cathode systems must be identified, and steps taken to mitigate them.

### Proposed Future Research

#### Immediate Future

- Further characterize electrochemical and mechanical properties of our gel formulations
- Characterize interpenetrated gels containing PP self-healing polymer
- Quantify polysulfide trapping in our materials using novel fast determination method
- Demonstrate Li-S cells with gel cathodes
- Select set of gel components to continue optimizing around for best cell performance

#### Before March 2019

- Develop optimized ionogel electrolytes with very high conductivity and controllable polysulfide solubility/transport
- Demonstrate significantly improved capacity retention and Coulombic efficiency in gel cathodes, compared to cathodes with traditional electrolyte systems
- Demonstrate self-healing behavior in a functioning cell
- Identify prominent performance degradation pathways in Li-S cells with gel cathodes using a combination of microscopy, spectroscopy, and electrochemical behavior

# Summary

#### Relevance

 Rational molecular design has potential to systematically address Li-S cell performance issues, leading to a battery system with 2x energy density compared to Li-ion and high capacity retention

#### Approach

- Mesoporous carbon with attached chemical functionality for improved utilization/retention of sulfur
- IL-based polyelectrolyte gels for Li metal compatibility, reduced polysulfide solubility
- Polysulfide "trapping" through interaction with designed molecular components to retain and utilize sulfur in cathode
- Self-healing materials based on NDI/Py to heal mechanical damage from cell operation

#### Technical Progress


- High conductivity demonstrated for initial range of freestanding gel electrolyte designs
- Excellent long-term compatibility of ionogels with Li metal demonstrated
- Chemical insight into NDI/Py interaction used to develop self-healing polymer system with widely tunable properties
- Solid-state ion transport and compatibility with IL demonstrated for self-healing materials
- Mesoporous carbons with thiol functionality developed and characterized as advanced sulfur hosts
- Functionalized carbon host shown to improve capacity and retention of high-loading sulfur cathodes

#### Future Work


- Develop and characterize gel cathodes with improved performance using in-situ curing of precursors
- Select specific material system for continued development with and optimize for cell performance
- Identify and mitigate degradation pathways in our novel cell designs


# Technical Back-Up Slides

### NDI/Py Interaction Modes




- UV-Vis analysis of dbNDI:Py mixtures indicates two interaction modes
  - 1:1 NDI:Py, 500nm abs, -8.2 kJ/mol,
  - 2:1 NDI:Py, 514nm abs, -16.5 kJ/mol






# NDI/Py Interaction Modes




 <sup>1</sup>H peak splitting for dbNDI:Py mixtures also indicates concentration-dependent binding

### Modified Carbon Characterization




 XPS, TGA, BET isotherms, SEM, and TEM confirm successful thiol functionalization of carbon


### Modified Carbon Characterization



 Varying thiol concentration on carbon (measured as %wt loss in TGA relative to baseline) confirmed by XPS and BET isotherms

## EIS Analysis of S Cathodes





- Impedance spectra of pristine (left) vs thiolmodified (right) carbon/sulfur cathodes at varying cycle and discharge state
- Larger mid-frequency semicircle in modified samples suggests charge-transfer resistance as origin of increased overpotential