



Brief Overview of Fluorescent Dimming Ballast Technology

Dec 6, 2016




Dimming has been saving energy for 40 years

- Intensity of light emitted by fluorescent lamp is related to current through the lamp
- Dimming ballasts are current sources, the current through the lamp is tightly controlled
- Dimming is accomplished by changing the operating frequency of the ballast, changes lamp current and lamp power
- Dimming ballasts must properly heat the lamp filaments to preserve lamp life




Light output follows lamp current

Normalized Luminous Intensity VS Lamp Current & Voltage






Light output follows lamp current






Simplified Dimming Ballast Schematic





Frequency Shift Dimming





It's all about the filaments



**Lamp operated at
full bright**



**Lamp operated at
minimum bright**



Filament heating

Filaments are heated by discharge current and filament current

The filament heating current must be increased as the lamp is dimmed to maintain proper filament temperature




Fig.1. Schematic presentation of an electrode




NEMA LL-9

- Filaments are heated by discharge current and filament current
- At full power, discharge current may be sufficient to heat filaments
- Filament voltage (and power) is increased to maintain filament temperature while dimming
- Lamp life is preserved by following LL-9 guidance
- LL-9 is the result of 20,000 hour life test between June 2005 and 2007
- Life test was collaborative effort between lamp and ballast manufacturers, LRC, and DOE



LL-9 Safe operating area



See NEMA LSD-73 for additional information