

Transitioning From Fuel Cells to Redox Flow Cells

T. Zawodzinski and Matt Mench
University of Tennessee and ORNL



Managed by UT-Battelle
for the Department of Energy



Acknowledgments

\$\$

DOE-OE

EPRI

GCEP

NSF EPSCOR (TN SCORE)

UTK Governor's Chair Fund

Partner in Crime

Matt Mench



Managed by UT-Battelle
for the Department of Energy




2



'Peeling the Onion' Personalized History of PEM Fuel Cells

We May Recapitulate This for RFBs



Transitioning to RFBs

What Could Remain the Same

1. Materials

- Membranes, diffusion media, electrodes, hardware

2. Diagnostics

- Flow batteries are a lot like fuel cells
- Polarization curves, ASR, segmented cells
 - This is NOT the way battery people test!



Managed by UT-Battelle
for the Department of Energy



Transitioning to RFBs

What is Different

1. Battery Chemistry

- Many different chemistries
- Multiple components
- Different reactivity challenges

2. Need to account for state of charge

3. Energy density, power density concerns different

4. Cost drivers different



Managed by UT-Battelle
for the Department of Energy



Membranes from Fuel Cells to RFBs

1. The Good

- Many different membranes available
 - PFSA, Hydrocarbons

2. The Not so Good

- Starting over to understand durability; multiple chemistries to take into account
- **Cross-over is more prevalent and a big issue; lots of water pumping as well**

3. The Ugly

- Multiple components lead to complex transport

4. The Just Plain Different



Both membranes and porous separators used

Transitioning Electrodes to RFBs

1. The Good

- Many different porous carbon materials for electrodes
- Don't always have catalysis

2. The Not so Good

- Transport issues are rather different
- **Need to sort out the loss mechanisms**

3. The Ugly

- Air electrodes are real issues

4. The Just Plain Different

- All phases used; concentration polarization



Transitioning Cells and Stacks to RFBs

1. The Ugly

- Typical flow cell design has horrible performance characteristics

2. The Good

- Flow-by cells (typical fuel cell architecture) works
 - Bipolar plates?

3. The Not so Good

- Need to deal with shunt currents
- **Multiple phases?**



Managed by UT-Battelle
for the Department of Energy



Diagnostics for RFBs

1. The Good

- Many standard approaches for battery testing

2. The Not so Good

- This has fuel cell characteristics and these FC test methods yield more information
- **Significant need to transfer from FCs**

3. The Ugly

- Simple descriptions often do not exist


4. The Just Plain Different

- Complex electrolytes and transport issues



Performance in Flow Systems: Polarization Curves

not normally used in battery work!



We separate and measure (both charge, discharge):

- **Electrode polarization for each electrode**
- **Membrane resistance**
- **Electrode ionic/reagent mass transport resistance**
- **GDL mass transport resistance**



Augmented by impedance tests as well as ex situ component tests

Needed Improvements and Measurements

We separate and measure (both charge, discharge):

- **Electrode polarization for each electrode**
 - Reference electrode
- **Membrane resistance**
 - High frequency resistance at each pol curve point; conductivity
- **Electrode ionic/reagent mass transport resistance**
 - Analysis of IR-corrected pol curve; impedance
- **GDL mass transport resistance**
 - Analysis of IR-corrected pol curve; impedance
- **PLUS: cross-over measurements, membrane transport studies of all species**



Missing Diagnostics that we enjoy in fuel cells

- **ESA measurements**
- **Detailed understanding of flow and current distribution**
- **Detailed descriptions of what goes where and how fast**
- **Life testing/durability methods**
- **And one other thing: patience!**




Managed by UT-Battelle
for the Department of Energy




 OAK
RIDGE
National Laboratory

Asymmetric Electrode Polarization

Discharging polarization curve



“Kinetic region”




- The V 3/2 electrode also dominated overpotential for a discharging polarization curve.
- Kinetic losses not large...



Reference electrodes

Dynamic hydrogen electrode

- Connected two Pt wires to a 9 V battery and a $\sim 1.5 \text{ M}\Omega$ resistor, resulting in $\sim 6 \mu\text{A}$ of current flowing*
- The “working electrode” of the DHE formed a layer of hydrogen bubbles at very little overpotential
- DHE is sandwiched between two N11




Also tested a commercially-supplied FlexRef DryRef reference electrode, but found vanadium infiltrated the DryRef

- 1/8” PTFE tube filled with proprietary gel and a silver wire



KONBO liquid junction

Conductivity of Membrane Equilibrated in Sulfuric Acid Solutions



Highly concentrated sulfuric acid solutions reduce membrane conductivities



Managed by UT-Battelle
for the Department of Energy




OAK
RIDGE
National Laboratory

Membranes in Contact with Strong Acid Solution

The HCl Case

Comparison of Conductivity of Nafion 117 Equilibrated with HCl solutions, Water



Managed by UT-Battelle
for the Department of Energy









OAK
RIDGE
National Laboratory

Vanadium Electron Paramagnetic Resonance

Vanadium

$$I_{\text{vanadium}} = 7/2$$




Electron configuration:






Dry: $R_V = 2.6 \times 10^8 \text{ s}^{-1}$

Wet: $R_V = 8.4 \times 10^8 \text{ s}^{-1}$


Crossover in Vanadium Redox Flow Batteries (measurements under way)







Oxygen crossover from Positive electrolyte solution





V^{2+} reacts quickly with oxygen. The negative side is kept under nitrogen to prevent that. If O_2 crosses the membrane from the positive side:





UV-Vis Spectrometry

Vanadium ions in solution have different colors and distinct UV-VIS spectra



1M Vanadium in aqueous H₂SO₄ solutions / 5M total sulfate

0.5 mm lightpath

ALS SEC2000 spectrometer






Managed by UT-Battelle
for the Department of Energy





OAK
RIDGE
National Laboratory

Excess Absorption Suggests a Third Species

$$ExcessAbsorbance = S_{meas} - \alpha S(VO_2^+) + (1 - \alpha)S(VO^{2+})$$



1:1 Complexes Have Been Observed in $\text{VO}^{2+}/\text{VO}_2^+$ Solutions in HClO_4



- ▶ The peak in excess absorbance near 0.5 SOC suggests a 1:1 complex, $\text{VO}^{2+} + \text{VO}_2^+ \rightarrow \text{V}_2\text{O}_3^{3+}$

- ▶ Also inferred from broadening of ^{51}V NMR peaks*

* (Okamoto, K. Woo-Sik, J. Tomiyasu, H.; Fukutomi, H. *Inorganica Chimica Acta*. 1988, 143, 217-221.)




Managed by UT-Battelle
for the Department of Energy



OAK
RIDGE
National Laboratory

Absorbance of V^{2+}/V^{3+} in an Operating VRFB



1M Vanadium, 5M sulfate


0.5mm light path

Spectrometer on flow cell bypass

Parallel chronoamperometry on 25 cm² battery




Managed by UT-Battelle for the Department of Energy



Dramatically Increased Performance

Increased VRB Max Power Density by ~10x



Comparison to literature reports of performance




Managed by UT-Battelle
for the Department of Energy



OAK
RIDGE
National Laboratory



Performance gain obtained using new architecture, materials



Peak Power density $\sim 800 mW/cm^2$



Managed by UT-Battelle
for the Department of Energy



Core Issues

It will eventually come back to the membrane!

Cost Modeling is tricky.

As we increase power density/current density, membrane resistance will become limiting again



Managed by UT-Battelle
for the Department of Energy

