

# SCR Performance Optimization Through Advancements in Aftertreatment Packaging

Jared Blaisdell, Andrew Gilb, Phebe Preethi, Joe  
Sweeney, Karthik Viswanathan, Paul Way,  
Nathan Zambon


DEER 2008



# Outline

## Optimization Through Aftertreatment Packaging

- Urea Doser Integration
  - Urea deposit formation & chemistry
  - Eliminating deposit formation
- Urea Preparation
  - Mixer design & simulation
  - Urea solution vaporization
  - Flow distribution
  - Urea distribution & mixing
- Single & Dual Wall Packaging
  - NO<sub>x</sub> reduction impact
  - Skin temperature
- Summary





# Doser Integration


## What Are Deposits?

Step 1 (Vaporization): Water evaporates from spray droplet

Step 2 (Decomposition): Urea thermolysis & hydrolysis reaction




**Incomplete decomposition results in deposit formation**



# Doser Integration

## Understanding Deposit Chemistry




### High Performance Liquid Chromatography

Confirms composition of collected deposits:

- Urea
- Melamine
- Cyanuric acid
- Biuret


### Thermogravimetric Analysis

- Deposit decomposition requires significant energy & time
- Prevention through proper doser integration & urea preparation



# Urea Doser Integration

## Deposit Formation & Root Cause





- Deposits form in three areas:
  - Injector location (spray tip/boss)
    - Cool tip/boss temperatures, direct spray impingement, spray recirculation
  - Interior wetted walls
    - Direct spray impingement on cool wall surface
  - Catalyst surface
    - “Wet” urea contacting catalyst surface (poor urea mixing/preparation)



# Urea Doser Integration

## Eliminating Deposits

- Eliminated wall wetting at injection location and pipe walls (CFD)
- Eliminated flow recirculation zone (CFD)
- Incorporate Wire-mesh “accumulator”
  - Direct spray impingement
  - Eliminates wall wetting
  - Re-directs urea spray



# Urea Preparation

## Mixer Design and Simulation


- What is the “best” mixer type?

- In-pipe mixers
- In-body mixers
- Multiple injection locations
- Multiple mixer variations

- Water injection used to simulate urea

- Model Outputs:

- % Vaporization
- H<sub>2</sub>O vapor uniformity ( $\gamma_{H_2O}$ )
- Velocity uniformity ( $\gamma_{Vel}$ )
- Backpressure penalty



- Simulation/Test Modes:

- 332g/s @ 500°C exh (high flow)
- 151g/s @ 290°C exh (low flow)

# Urea Preparation

## Mixer Design and Simulation

	BP (kPa)	$Y_{H_2O}$ High Flow	$Y_{H_2O}$ Low Flow	$Y_{Vel}$ High Flow	$Y_{Vel}$ Low Flow			
In-Body	A – Continuous Body & On-Mixer Doser	2.2	0.77	0.90	0.95	0.98		
	B – DPF Outlet Mixer & On-Mixer Doser	2.0	0.97	0.98	0.96	0.99		
	C – SCR Inlet Mixer & On-Pipe Doser	2.6	0.87	0.92	0.94	0.97		
	D – SCR Inlet Mixer & On-Mixer Doser	1.6	0.82	0.93	0.94	0.98		
In-Pipe →	E – In Pipe Vortex & On-Pipe Doser	1.9	Incomplete vaporization at SCR face		0.96	0.87	0.97	0.99

- Ideal mixer determined to be in-body design
  - Low backpressure penalty
  - Maximum mixing/vaporization
  - Maximum injection location flexibility




# Urea Preparation

## Simulation Validation

Empty Inlet  
(normally DOC + DPF)

Urea Injection/Mixer

Single 10.5" x 6" SCR  
promotes ammonia slip for  
distribution measurement



- In-body mixer refined via simulation
- Simulation results compared against engine test:
  - 15 liter, Cummins ISX 500
  - 342 g/s @ ~477 C 1,616 ml/hr injection
  - 190 g/s @ ~429 C 638 ml/hr injection
  - 224 g/s @ ~204 C 1,741 ml/hr injection
- Baseline (no mixer) compared to with-mixer case




# Urea Preparation

## Simulation Validation

### Baseline Simulation Results



- Linear flow with some turbulence (limited vaporization time)
- > 75% of urea impacts core face as liquid
- Poor reactant distribution at the SCR core face





Pathlines Colored by Velocity Magnitude (m/s)

Jun 11, 2007  
FLUENT 6.3 (3d, dp, pbns, spe, RSM)



### Mode 1



### Mode 2



### Mode 3



Contours of Mass fraction of h2o

Jun 11, 2007  
FLUENT 6.3 (3d, dp, pbns, spe, RSM)

Contours of Mass fraction of h2o

Jun 11, 2007  
FLUENT 6.3 (3d, dp, pbns, spe, RSM)

Contours of Mass fraction of h2o


Jun 11, 2007  
FLUENT 6.3 (3d, dp, pbns, spe, RSM)

# Urea Preparation

## Simulation Validation


### Mixer Simulation Results

- Strong vortex = increase vaporization time
- No liquid urea escapes
- Uniform distribution




Pathlines Colored by Velocity Magnitude (m/s) Jun 11, 2007  
FLUENT 6.3 (3d, dp, pbns, spe, RSM)


### Mode 1



### Mode 2



### Mode 3



Contours of Mass fraction of h2o Jun 11, 2007  
FLUENT 6.3 (3d, dp, pbns, spe, RSM)

Contours of Mass fraction of h2o Jun 11, 2007  
FLUENT 6.3 (3d, dp, pbns, spe, RSM)

Contours of Mass fraction of h2o Jun 11, 2007  
FLUENT 6.3 (3d, dp, pbns, spe, RSM)

# Urea Preparation




## Measured Ammonia Slip Distribution

Mode 1

Mode 2




Mode 3

Baseline



Significant Urea Pooling

With Mixer



No Pooling = Increased Slip  
Compared to Baseline




# Urea Preparation

## On-Engine Performance Evaluation



- 2004 CAT C7
- 600 HP eddy-current dynamometer
- Pseudo FTP cycle
  - Cold start transient (duration: 20 min)
  - 20 min hot soak
  - Hot start transient (duration: 20 min)
- 3 steady-state SET modes
  - 1901 RPM, 175 ft-lb (B25)
  - 1901 RPM, 525 ft-lb (B75)
  - 2240 RPM, 611 ft-lb (C100)




- Alpha =  $\text{NH}_3:\text{NO}_x = 1.0$   
exhaust  $> 200^\circ\text{C}$

# Urea Preparation

## On-Engine Performance Evaluation

FTP NO <sub>x</sub> Red	No Mixer	With Mixer
No Accumulator	<b>47.2 %</b> 442ppm NH <sub>3</sub>	<b>74.9 %</b> 15ppm NH <sub>3</sub>
With Accumulator	<b>62.5 %</b> 132ppm NH <sub>3</sub>	<b>81.9 %</b> 15ppm NH <sub>3</sub>








# Packaging Style

## Dual or Single Wall?

- Single or dual wall drivers:
  - Skin temperature: dual wall has lower skin temperature
  - Heat retention: improved cold start NOx reduction
  - Cost: dual wall is higher cost
- Performance tested
  - Cold start + hot start FTP
  - Steady state, ~ 480°C exhaust gas temperature




Test System

# Test Cell Evaluation

## Impact of Dual Walled Packaging – NO<sub>x</sub> Reduction

FTP %NO <sub>x</sub> Reduction	
Dual Wall (System)	77.2%
Single Wall (SCR only)	75.7%



# Summary

- Doser integration priorities
  - Zero wall wetting
  - Zero recirculation
  - In-pipe accumulator reduces deposits
- Urea preparation significantly impacts system performance
  - In-pipe mixers require long pipe lengths for full vaporization
  - In-body swirl mixer provides the best performance:
    - 100% vaporization
    - excellent flow distribution
    - 6” package space, doser flexibility
  - Combination of in-body mixer with in-pipe accumulator offers performance and deposit advantages
- Single or dual wall packaging?
  - Little to no impact on NOx reduction over cold + hot FTP
  - Skin temperature, cost - primary drivers
  - Impact on deposit formation needs to be evaluated

