



TRAIN THE TRAINER

Blower Door Basics

WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010

Learning Objectives

BLOWER DOOR BASICS

- Name and understand the natural driving forces that cause pressure differences.
- Understand units of pressure and the measurement of air leakage.
- Be able to set up and operate a blower door to measure air leakage and conduct zone pressure diagnostics.
- Understand the meaning and importance of minimum ventilation requirements (MVR).
- Be able to convert blower door readings to the total size of opening in square inches, and to cubic feet per minute (CFM) of air leakage under natural conditions.
- Understand the relationship between CFM_{50} , $CFM_{natural}$ and air changes per hour (ACH).

By attending this session, participants will:

- Name and understand the natural driving forces that cause pressure differences.
- Understand units of pressure and the measurement of air leakage.
- Be able to set up and operate a blower door to measure air leakage and conduct zonal pressure diagnostics.
- Understand the meaning and importance of minimum ventilation requirements (MVR).
- Be able to convert blower door readings to the total size of an opening in square inches, and to cubic feet per minute (CFM) of air leakage under natural conditions.
- Understand the relationship between CFM_{50} , $CFM_{natural}$, and air changes per hour (ACH).

Blower Door Testing

U.S. DEPARTMENT OF **ENERGY** | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS

Blower door testing is used to quantify and locate air leakage by using a calibrated fan to depressurize a house.



Photo courtesy of NRCERT

3 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010 eere.energy.gov

- Blower door testing locates and quantifies air leakage by using a calibrated fan to depressurize a house.

This photo is of a Minneapolis Blower Door manufactured by the Energy Conservatory in Minneapolis, MN.

Ask students what types of blower door they are familiar with.

Point out the fan rings in the right photo.

Does anyone still use magnahelic gauges?

Measuring Building Air Leakage

U.S. DEPARTMENT OF
ENERGY

Energy Efficiency &
Renewable Energy

BLOWER DOOR BASICS

Natural driving forces

Pressure differences too small to measure reliably.

Blower Door

Exaggerates pressure differences so they can be measured reliably and the results are repeatable.

Exaggerated air leakage measured with the blower door gives us an idea of the amount of air leakage that would occur under natural conditions.

4 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010

eere.energy.gov

- Natural driving forces – Pressure differences caused by natural driving forces of **wind effect**, **stack effect**, and combustion and ventilation are too small to measure reliably. These naturally occurring pressure differences change with the wind and temperature, and are not repeatable.
- Blower door – This controlled driving force exaggerates pressure differences so they can be measured reliably and the results are repeatable. With this tool, we can measure leakage from a standard baseline.

We can convert the exaggerated air leakage measured with the blower door to air leakage that would occur under natural conditions.

Ask students to name the natural driving forces.

Measuring Building Air Leakage

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency &
Renewable Energy

BLOWER DOOR BASICS

- Air leakage measured by the blower door is proportional to the size of the holes in the house between inside and outside.
- Can conduct blower tests before and after air-sealing work to determine the effectiveness of our work.
- Can use blower door testing to tell us which houses have the most potential for energy savings through air sealing.

5 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010

eere.energy.gov

- The standard baseline for blower door reading is a pressure of -50 *pascals* (Pa) in the home ***with reference to (WRT)*** the outside.
- Air leakage measured by the blower door is proportional to the size of the holes in the house between inside and outside. Air leakage is measured in ***cubic feet per minute*** at -50 Pa, also written as ***CFM₅₀***. To convert the blower door reading at CFM₅₀ to the total size (in square inches) of the holes between the inside and outside of the home, divide the blower door reading at CFM₅₀ by 10.
- Conducting blower tests before and after air sealing helps determine the effectiveness of our work. Post-testing reveals whether any big leaks were missed while air sealing.
- Blower door testing tells us which houses have the most potential for energy savings through air sealing. If the house is already fairly tight, it isn't cost-effective to spend hours finding and sealing tiny leaks. In these homes, concentrate time and effort on installing insulation, base load, and mechanical measures. In this way, the blower door helps develop an effective work scope.

Measuring Pressure & Airflow

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency &
Renewable Energy

BLOWER DOOR BASICS

- We don't measure total pressure, but the pressure difference between one space and another.
- Always one pressure with reference to (WRT) another.
- Sometimes we measure pressures under controlled, artificial conditions, sometimes under normal operating conditions.

6 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010

eere.energy.gov

- Measure pressure difference between one space and another, not total pressure.
- Always measure one pressure with reference to another – You would never simply say the attic is at 50 Pa.
- Sometimes measure pressure under controlled, artificial conditions, and sometimes under normal operating conditions.

Q: Besides the blower door, can anyone name another controlled, artificial condition we create to test pressure?

A: Worst-case draft combustion appliance zone (CAZ) testing.

Measuring Pressure Difference


U.S. DEPARTMENT OF
ENERGY

Energy Efficiency &
Renewable Energy

BLOWER DOOR BASICS

Pascal (metric standard)

- 1 Pascal = weight of one Post-It note
- 249 Pascals = 1 inch water column (American standard)
- 1" water column = pressure required to suck 1" of water up a straw



7 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010

eere.energy.gov

Units for measuring pressure difference:

- Pascal is the metric standard and the standard in building science. Some HVAC technicians use the American standard, inches of water column.
- 1 Pa = approximately the weight of one Post-It note.
- 249 Pa = 1 inch of water column.
- 1" water column = pressure required to suck 1" of water up a straw.

Ask if there are any in the class from the HVAC industry. What do they use the metric inches of water column for?

Units for Measuring Airflow

U.S. DEPARTMENT OF
ENERGY
Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS

Cubic Feet per Minute (CFM)

- Rate of airflow.
- Based on the size of a home and the number of occupants, a home should have a certain amount of fresh air when the home is closed up.

CFM₅₀ (standard for blower door)

- Blower door measures the rate of airflow in CFM when the pressure difference between the inside of the house with reference to outside is -50 Pascals.

8 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010
eere.energy.gov

Cubic feet per minute.

- Rate of airflow – A cubic foot of air is about the amount in a basketball. When we measure CFMs, we're determining how many basketballs per minute leak into and out of the home.

The ***minimum ventilation requirement (MVR)*** is the amount of fresh air a home requires when it is closed up to maintain healthy indoor air quality based on the size of the home and the number of occupants. MVR is the target number of CFMs not to go below when air sealing the home.

CFM₅₀ (standard for blower door).

- A blower door measures the rate of airflow in CFM when the pressure inside of the house is -50 Pa with reference to outside. The exaggerated pressure difference is reliably measurable and repeatable.

Blower Door Components

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS

- Fan
- Frame
- Speed controller
- Manometer – the pressure gauge
- Hoses



Photo courtesy of PA Weatherization Training Center (WTC)

9 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010


eere.energy.gov

- Fan
- Frame
- Speed controller
- **Manometer** – the pressure gauge
- Hoses

Blower Door Fans

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS



10 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010


eere.energy.gov

- Left photo – Minneapolis Brand from the Energy Conservatory.
- Right photo – Retro-Tech, originated in Europe and focused on commercial buildings.
- A third manufacturer, Infiltech, is not pictured here. Its blower door fans are blue.

Blower Door Frame

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency &
Renewable Energy

BLOWER DOOR BASICS



All images courtesy of the Energy Conservatory

11 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010

eere.energy.gov

Photo of adjustable frame and case from the Energy Conservatory.

- These frames are quick to assemble and disassemble. Installers have probably seen this type of frame.

Blower Door Frame

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency &
Renewable Energy

BLOWER DOOR BASICS



Minneapolis Blower Door
installed in exterior door.

12 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010

eere.energy.gov

Photo of the Energy Conservatory's Minneapolis Blower Door set up in an exterior door.

- Fan hangs on the cross member.
- Mounting place for the manometer and fan speed control.
- It is wise to keep controls off the ground to avoid accidental damage.

Some of the Retro-Tech doors have hard panels instead of fabric.

Manometers & Gauges

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS



Magnahelic
Gauges
(US Dept. of Energy)



DG-700
(Energy Conservatory)



DM-2
(Retrotec)

13 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010

eere.energy.gov

Devices used to measure pressure differences:

- Magnahelic gauges – These are largely relics now.
- DG-700 – The Energy Conservatory. Many installers are familiar with the DG-2, DG-3, or the newest DG-700 pictured here.
- DM-2 – Retro-Tech.

Blower Door Setup

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS

- Set up blower door in an exterior door.
- Put house in winter mode by closing all exterior doors and windows and opening all interior doors.
- Turn off heating/cooling system and fuel-fired water heaters.
- Close fireplace dampers.
- No wood stoves in use!
- Remove ashes or cover with wet newspaper.

14 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010
eere.energy.gov

- Set up blower door in an exterior door – Indicate which door you install the blower door in on your data sheets. This helps ensure repeatable results during monitoring.
- Put the house in **winter mode** by closing all exterior doors and windows and opening all interior doors.
- Turn off heating and cooling systems and fuel-fired water heaters – There are two reasons for turning off all combustion appliances:
 - Most importantly, so dangerous combustion gasses don't get sucked down the flue into the house.
 - So the air handler is not fighting with the blower door.
- Close fireplace dampers.
- No wood stoves in use! Call ahead to make sure residents don't use the wood stove for at least 24 hours before the visit.
- Remove ashes or cover with wet newspaper. There are many stories about forgetting to cover the ashes. Statistically, this happens most often in homes with white carpeting. You only do that once.

Anecdote: One client ignored the auditor's request and used the wood stove the day before the auditor came. There were ashes in the stove, so the energy auditor and helper decided to pressurize the house (instead of normal depressurization) so they wouldn't suck ashes out of the wood stove. After a while, they heard a roar that had been covered up by the sound of the blower door fan. By pressurizing the house, they had basically created a blast furnace in the wood stove. They rushed outside to see the stove flue glowing red! Luckily, no permanent damage was done.

Remember to turn the appliances back on before you leave. An old energy auditor trick is to leave your truck keys on the water heater so you remember to turn the water heater and furnace back on. It's unfortunate to be 50 miles away when you get the call from the client that the hot water heater stopped working.

Things to Know

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS

- Low-flow rings (for tighter homes).
- Can't reach fifty (CRF).
- Check flow sensors.
- Hose to outside – end should be at least 5 feet on one side of fan or the other (not in front of fan).

15 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010
 eere.energy.gov

- Low-flow rings** (for tighter homes) – In tight homes, you need to use low-flow rings so air rushes past the sensors fast enough to give you a reliable reading. The hose takes a reading from the fan by converting the amount of air rushing past the four sensors to CFM₅₀. If the house is really tight, a low fan speed is needed to create -50 pascals of pressure in the home. This leaves the air flowing past the sensors too slowly to get a reliable reading. Adding rings creates a smaller hole, which equals faster flow.
- Can't reach fifty** (CRF) – In very leaky homes, it is sometimes impossible to depressurize the home to -50 pascals because air rushes in too fast. In this case, digital manometers will read CRF. Since most standards and calculations are based on achieving a blower door reading of CFM₅₀, new sensors automatically calculate what the leakage would be at this rate. Older sensors come with tables of multipliers that allow auditors to put readings in context of CFM₅₀.
- Check flow sensors – If readings seem unusual, make sure the flow sensors aren't blocked.
- Hose to outside – The end should be at least 5 feet on one side of the fan or the other (not in front of the fan). If the end of the hose that is taking the outside reading is too close to the fan, the reading will not be accurate. Also keep the hoses clear of the fan on the inside so they aren't sucked up into the fan.


Blower Door Setup: Air Leakage

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS


Channel A

measures pressure difference of the inside of the house with reference to *outside*.




Channel B

measures pressure difference of the fan with reference to *inside*.



Hose to Outside



Hose to Fan

16 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010 eere.energy.gov


Always set up the manometer the same way so it becomes automatic to you.

When measuring whole home air leakage:

- Channel A measures the pressure difference of the inside of the house with reference to outside – Adjust rings and/or fan speed until the reading on this channel is -50.
- Channel B measures the pressure difference of the fan with reference to inside – This tells you the leakiness of the building or can be converted to pressure.

Fan Pressure

BLOWER DOOR BASICS



The diagram shows a red blower door with a white fan wheel. A red tube connects the fan's hub to a manometer. A blue arrow points from the right towards the fan wheel, labeled "Direction of Airflow".

- Airflow across the sensor in the hub of the fan causes air pressure.
- The manometer compares this fan pressure to the pressure inside the house and . . .
- Converts the pressure difference to a rate of airflow.

Direction of Airflow


17 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010 eere.energy.gov

- Airflow across the sensor in the hub of the fan causes air pressure.
- The manometer compares this fan pressure to the pressure inside the house and converts the pressure difference to a rate of airflow.
- Airflow induced by the fan creates a pressure difference between the inside and outside of the house. The manometer uses this pressure difference to calculate a rate of airflow.

Fan Pressure

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS



The flow sensor is just a plastic ring with four holes in the outer circumference.

An airtight tunnel inside the sensor connects the holes to the hose coming out of the sensor. This hose connects to a tap mounted on the top of the fan.

When you set up the blower door, you connect a hose from this tap to the manometer.

18 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010

eere.energy.gov

- The flow sensor is a plastic ring with four holes in the outer circumference.
- An airtight tunnel inside the sensor connects the holes to the hose coming out of the sensor.
- This hose connects to a tap mounted on the top of the fan.
- A hose connects this tap to the manometer.

Older blower doors had channels to the sensors that were caulked. That seal failed and leaked occasionally. With an older blower door, test this seal by putting your fingers over the holes. With fingers in place, suck on the tube. It should stick to your tongue.

Blower Door Setup

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS

Check upper left portion of screen to ensure correct device is displayed. If not, toggle **DEVICE** button.

DEVICE

Check upper right portion of screen to ensure the correct flow ring is displayed. If not, toggle **CONFIG** button.

CONFIG

19 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010
eere.energy.gov

- Check upper left portion of screen to ensure correct DEVICE is displayed. If not, toggle DEVICE button until it indicates Blower Door (BD).
- Check upper right portion of screen to ensure the correct flow ring is displayed. If not, toggle the CONFIG button. This reads OPEN, indicating there are no flow rings to restrict flow.

Blower Door Setup

U.S. DEPARTMENT OF **ENERGY** | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS

Check lower left portion of screen to ensure correct mode is displayed. If not, toggle **MODE** button.

Lower right portion of screen displays time average setting. Toggle **TIME AVG** button to desired setting.

20 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010

eere.energy.gov

- Check the lower left portion of screen to ensure correct MODE is displayed. If not, toggle MODE button – Typical mode is PR/FL@50, flow at 50 Pa pressure difference.
- Lower right portion of screen displays time average setting – Toggle TIME AVG button to desired setting. Options on this model are 5 seconds, 10 seconds, or long term. The manometer takes around 40 measurements per second, so in 5-second mode, the readout is an average of hundreds of readings taken over 5 seconds. Longer TIME AVG settings can help correct for fluctuating readings on windy days.

Q: What does the PR/50 in the lower left window indicate?

A: PR/50 in the lower left window means the manometer does the CRF calculations automatically when the house can't reach -50 pascals.

Blower Door Setup

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS

In typical **PR/FL@50** mode, left portion of screen displays the pressure of the house with reference to outside . . .

Hose to Outside

And right portion of screen displays house air leakage at -50 Pa, CFM₅₀.

Hose to Fan

21 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010
eere.energy.gov

- In typical PR/FL@50 mode, the left portion of the screen displays the pressure of the house with reference to outside.
- The right portion of screen displays house air leakage in cubic feet per minute at -50 Pa, CFM₅₀.

Blower Door Setup

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS

To set up in typical **PR/FL@50** mode, **TURN ON** DG-700 and then press **MODE** button twice.

Then, with fan cover on, calibrate the manometer to account for the baseline house pressure with reference to outside by pressing **BASELINE** then **START**. After 30 seconds or when the pressure reading is steady, press **ENTER**.

22 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010
eere.energy.gov

- To set up in typical PR/FL@50 mode, turn on DG–700 and press MODE button twice.
- With fan cover on, calibrate the manometer to account for the baseline house pressure with reference to outside by pressing BASELINE then START. After 30 seconds, or when the pressure reading is steady, press ENTER.

Set mode before baseline. Setting mode second wipes out the baseline.

Blower Door Test

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency &
Renewable Energy

BLOWER DOOR BASICS

- Remove fan cover.
- Turn blower door on and slowly increase speed to achieve a pressure difference between the house with reference to outside of -50 pascals (Channel A).
- Read whole-house infiltration rate on Channel B.

23 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010

eere.energy.gov

Run the blower door test:

- Remove the fan cover.
- Turn the blower door on and slowly increase speed to achieve a pressure difference between the house with reference to outside of -50 pascals (Channel A).
- Read the whole-house infiltration rate on Channel B.

CFM₅₀ vs CFM_{natural}

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS

- **CFM₅₀** = Air leakage with blower door.
- **CFM_{natural}** = Natural (everyday) air leakage.
- **CFM₅₀ / “N” factor** = CFM_{natural}.
- **N-factor** depends on climate, building height, and shielding from wind; assumes random holes.
- **N** ranges from 9.8 to 29.4, but typically averages 20.
- *Example:* 4,000 CFM₅₀/20 = 200 CFM_{natural}.

24 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010

eere.energy.gov

CFM₅₀ refers to the amount of air leakage measured while running the blower door – There is no direct, constant ratio between this number and the amount of air leakage that occurs in the home under natural conditions.

CFM_{natural} is the amount of air leakage under natural conditions.

CFM₅₀/N-factor = CFM_{natural} – To determine the amount of air leakage that occurs naturally, divide the reading attained at CFM₅₀ by the **N-factor**.

- The N-factor depends on climate, building height, and shielding from wind.
- N ranges from 9.8 to 29.4, but typically averages about 20 – A higher N-factor means the blower door is creating more exaggerated conditions. A lower N-factor means the blower door reading is closer to the natural leakiness of the home.
- Example: 4,000 CFM₅₀/20 = 200 CFM_{natural} – In this case, a blower door reading of 4,000 cubic feet per minute air leakage translates into 200 cubic feet per minute of air leakage under natural conditions.

Approximate Leakage Area

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS




Photo courtesy of NRCERT

- Divide CFM₅₀ by 10
- For example:
 $5,000 \text{ CFM}_{50} / 10 = 500 \text{ in.}^2$

25 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010
eere.energy.gov

Calculating the approximate leakage area is a good way to think about the overall leakiness of the home and to express that leakiness to clients.

Divide CFM₅₀ by 10 to determine approximate square inches of holes in the home.

$5,000 \text{ CFM}_{50} / 10 = 500$ square inches.

This simple equation indicates that starting with the equivalent of a 500-square-inch hole, air sealing reduced the size of the hole to only 150 square inches.

Q: If the pre-air-sealing reading were 5,000 CFM₅₀, what post-air-sealing blower-door reading would indicate a reduction of 350 square inches of leakage area?

A: 1,500 CFM₅₀.

Air Changes

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS

Air Changes per Hour at 50 Pascals (ACH₅₀)

- 4,000 CFM₅₀ is leaky for a small house, but may be pretty tight for a larger house.
- ACH₅₀ takes the size of the house into account.
- CFM₅₀ x 60 min/hr ÷ house volume = ACH₅₀.
- New houses: ACH₅₀ = 5 to 10.
- Older houses: ACH₅₀ = 11 to 15.
- Some weatherization-eligible houses have ACH₅₀ up to **30**.

26 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010
eere.energy.gov

Air changes per hour (ACH) refers to how often the air in the home is refreshed. ACH₅₀ refers to how often the air is refreshed when the pressure difference is 50 Pa. This puts blower door readings in context with the size of the home.

Air changes per hour at 50 Pa (ACH₅₀):

- 4,000 CFM₅₀ is leaky for a small house, but may be tight for a larger house – A reading that shows a small home is quite leaky might indicate that a much larger house barely meets minimum ventilation requirements (MVR).
- ACH₅₀ takes the size of the house into account.
- CFM₅₀ x 60 min/hr/house volume = ACH₅₀.
- New houses: ACH₅₀ = 5 to 10.
- Older houses: ACH₅₀ = 11 to 15.

Some weatherization-eligible houses have ACH₅₀ of up to 30, meaning if you run the blower door for one hour, all the air in the house is changed 30 times within that hour!

The old ASHRAE standard 62.1989 requires 0.35 ACH_{natural} per person.

Air Changes per Hour

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy


BLOWER DOOR BASICS

Air Changes per Hour at 50 Pascals (ACH₅₀)

- House volume = length x width x height
- Conditioned space only

Example:

- House dimensions:
40' long, 28' wide, 8' high
- Blower door reading = 4,500 CFM₅₀
- ACH₅₀ = CFM₅₀ x 60 min/hr ÷ house volume
 = 4500 x 60 ÷ (40 x 28 x 8)
 = 4500 x 60 ÷ 8960 = **30 ACH₅₀**



27 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010
eere.energy.gov

A sample calculation to convert a blower door reading of CFM₅₀ to ACH₅₀:

- House volume = length x width x height.
- Conditioned space only.
- House dimensions: 40' long, 28' wide, 8' high.
- Blower door reading = 4,500 CFM₅₀.

ACH₅₀ = CFM₅₀ x 60 min/hr/house volume.

The sample house is a simple rectangle: 40 feet long, 28 feet wide, with 8-foot ceilings throughout. Only air within the conditioned space is measured for this calculation. The unconditioned attic and basement are not included.

To figure out the ACH₅₀, first multiply the blower door reading at CFM₅₀ times 60 to convert minutes to hours and determine the volume of air being moved every hour.

Divide that number by the volume of the home. The result is how many times all the air in the house is refreshed each hour:

- 30 ACH at 50 Pa.

Q: Do you think that's a leaky house or a tight house?

A: If our N-factor is 20, we could divide 30 by 20 to get an ACH_{natural} of more than 1. That's pretty leaky.

Minimum Ventilation Requirement

U.S. DEPARTMENT OF
ENERGY

Energy Efficiency &
Renewable Energy

BLOWER DOOR BASICS

- Also called building tightness limit (BTL).
- Amount of natural ventilation for adequate indoor air quality.
- If blower door reading is below MVR, mechanical ventilation must be added.
- **MVR can be computed with:**
 - ASHRAE 62-1989.
 - ASHRAE 62.2.

28 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010

eere.energy.gov

- Also called *building tightness limit (BTL)*.
- Amount of natural ventilation for adequate indoor air quality – MVR is a “fresh air” target. Sealing a home tighter than the MVR results in indoor air quality that is no longer healthy for residents.
- If the blower door reading is below MVR, mechanical ventilation must be added.
- MVR can be computed with:
 - ASHRAE 62-1989
 - ASHRAE 62.2

ASHRAE Standard 62-1989

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS

Natural ventilation shall be the higher of:

15 CFM per person	15 CFM per (bedroom + 1)	0.35 air changes per hour
----------------------	-----------------------------	------------------------------

EXAMPLE:

- 5 occupants, 3 bedrooms, 8,960 ft³ volume
- 15 CFM x 5 people = 75 CFM_{natural}
- 15 CFM x (3 bedrooms + 1) = 60 CFM_{natural}
- 0.35 ACH x 8,960 ft³ ÷ 60 min/hr = 52.3 CFM_{natural}
- MVR is 75 CFM_{natural} since it is highest

$$75 \text{ CFM}_{\text{natural}} \times n = \text{CFM}_{50}$$

$$75 \text{ CFM}_{\text{natural}} \times 20 = 1,500 \text{ CFM}_{50} = \text{MVR}$$

29 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010
eere.energy.gov

ASHRAE Standard 62-1989 states that natural ventilation shall be the higher of:

- 15 CFM per person.
- 15 CFM per (bedroom + 1).
- 0.35 air changes per hour.

The standard requires you to work each of these three calculations. The one with the highest result is the MVR.

ASHRAE Standard 62-1989 – Sample Calculation

In this example, five people live in a three-bedroom home with a volume of 8,960 cubic feet.

- 5 occupants.
- 3 bedrooms.
- 8,960 ft³ volume.

Using the calculation based on number of occupants, MVR is 75 CFM_{natural}

$$15 \text{ CFM} \times 5 \text{ people} = 75 \text{ CFM}_{\text{natural}}$$

MVR using the bedroom-based calculation is 60 CFM_{natural}

$$15 \text{ CFM} \times (3 \text{ bedrooms} + 1) = 60 \text{ CFM}_{\text{natural}}$$

Based on minimum air changes per hour, MVR is 52.3 CFM_{natural}

$$0.35 \text{ ACH} \times 8,960 \text{ ft}^3 / 60 \text{ min/hr} = 52.3 \text{ CFM}_{\text{natural}}$$

MVR in this example is 75 CFM_{natural}, the highest of the three results. This number is the basis of the post-air-sealing blower door target.

Use the N-factor to convert the MVR under natural conditions into the target blower door reading, under which the indoor air quality is unhealthy:

$$75 \text{ CFM}_{\text{natural}} \times N = \text{CFM}_{50}$$

$$75 \text{ CFM}_{\text{natural}} \times 20 = 1,500 \text{ CFM}_{50} = \text{MVR}$$

In this example, if post-testing blower door results are lower than 1,500 CFM₅₀, mechanical ventilation must be added.

Air Sealing Target

U.S. DEPARTMENT OF
ENERGY | Energy Efficiency & Renewable Energy

BLOWER DOOR BASICS

- Usually somewhere between pre-weatherization blower door reading and MVR.
- Different program determine air sealing target differently.
- Some programs require a reduction in CFM₅₀ of:
 - 40% for leaky houses.
 - 20% for somewhat tighter houses.
 - 0% for substantially tight houses.

30 | WEATHERIZATION ASSISTANCE PROGRAM STANDARDIZED CURRICULUM – August 2010

eere.energy.gov

The air sealing target must be at or above the MVR, but programs have flexibility determining their own targets.

- Usually somewhere between pre-weatherization blower door reading and MVR.
- Different programs determine air-sealing target differently.
- Some programs require a reduction in CFM₅₀ of:
 - 40% for leaky houses.
 - 20% for somewhat tighter houses.
 - 0% for substantially tight houses.

Ask students if they have air sealing target tables in their programs.

Summary

BLOWER DOOR BASICS

- The blower door is a controlled driving force used to quantify air leakage.
- Air leakage is measured in cubic feet per minute at a pressure difference of 50 pascals with reference to another space.
- Minimum ventilation requirements assure adequate fresh air.
- Air changes per hour relate air leakage to building size.
- Blower door readings can be converted to air leakage under natural conditions, total size of opening, and ACH.

- The blower door is a controlled driving force used to quantify air leakage.
- Air leakage is measured in cubic feet per minute at a pressure difference of 50 pascals with reference to another space.
- Minimum ventilation requirements assure adequate fresh air.
- Air changes per hour relate air leakage to building size.
- Blower door readings can be converted to air leakage under natural conditions, total size of opening, and ACH.